


Multi-Pointer Gage Type PG



WARNING

DO NOT INSTALL MAINTAIN OR OPERATE THIS EQUIPMENT WITHOUT READING UNDERSTANDING AND FOLLOWING PROPER **Bailey Babcock & Wilcox** INSTRUCTIONS AND MANUALS OTHERWISE INJURY OR DAMAGE MAY RESULT

INDEX

INSTALLATION	4
ROUTINE MAINTENANCE	8
CORRECTIVE MAINTENANCE	8
ADJUSTMENT AND CALIBRATION	13
DESCRIPTION OF OPERATION	18
EXPLANATION OF NOMENCLATURE	20
SPECIFICATIONS	22
REPLACEMENT PARTS	23

NOTE Many references are made throughout this instruction to Model designations. Recent PG gages have been supplied with the new nomenclature. Refer to the tables following.

<p>TYPE PG □ □ □ □</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">1 2 3</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">A B</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">0 1 2 4</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">F S V T</p>	<p>Multipointer gage with 7" vertical scale</p> <p>Indicators one two one indicator one pneumatic transmitter*</p> <p>Illumination Standard 118 V ac 50/60 Hz No illumination</p> <p>Trim Color Black Slate gray Moss green Patent</p> <p>Mounting Flush indoor installation Semiflush, indoor installation Flush outdoor installation Semiflush, outdoor installation</p>
---	--

*Standard outdoor installation on gages (Types PG3A□V and PG3A□T) a way-in-cable transmitter in the right-hand position actuated by the mechanism in the left-hand position. Right-hand scale is blank without pointer.

Model □□□□ □□□□ Two four character alphanumeric sets chosen from Tables 1 through 4. The first set represents the left side of the gage, and the second set represents the right side of the gage.

Older Model	Newer Model	Mechanism
AA	W	bellows (pneumatic receiver)
AB	V	
AD	E	bellows pressure, evacuated vacuum)
B1	F	
DA	L	Bourdon tube (pressure)
DB	H	
DC	J	diaphragm (draft or pressure)
DD	K	
PA	R	diaphragm differential pressure)
PB	S	
NO	Z	empty

Type PG Multi-Pointer Gage

STANDARD RANGES & MODELS TABLE II
(Bourdon Tube Mechanism)

PRESSURE		MODEL*
Scale Range psi	Barylum Copper Bourdon Tube	
0 to 30	B 415	
0 to 40	B 5 4	
0 to 50	B1515	
0 to 60	B1516	
0 to 70	B1517	
0 to 80	B 5 B	
0 to 90	B1520	
0 to 150	B 52	
0 to 200	B1522	
0 to 300	B1523	
0 to 400	B 524	
0 to 500	B1525	
0 to 600	B1526	
0 to 800	B1528	
0 to 1000	B1530	
0 to 200	B1532	
0 to 1500	B 535	
0 to 2000	B 540	
20 to 40	B 554	
20 to 50	B1555	
20 to 80	B1558	
50 to 50	B166	
50 to 400	B1664	
200 to 500	B1665	
200 to 700	B1667	
300 to 600	B 666	
300 to 800	B 668	
300 to 1 00	B1671	
401 to 1200	B1673	

*Suff x must be added to MODEL designation to indicate scale color. White B blue G-green N-orange R-red Y yellow

STANDARD RANGES & MODELS TABLE IV
(Pneumatic Transmitter)

Transmitter Range (psig)	MODEL
3 27	PA100
3 5	PB 00

STANDARD RANGES AND MODELS
(Diaphragm Mechanism)

DRAFT		PRESSURE	
Scale Range	MODEL*	Scale Range	MODEL*
Scale Range H ₂ O		Scale Range H ₂ O	
-0.2 to -0.3	DA 0	0 to +0.5	DA210
-0.5 to 0.0	DA1 1	0 to +0.6	DA21
0 to +0.1	DA112	0 to +0.8	DA212
-0.5 to +0.3	DA1 3	0 to +1.0	DA2 3
-0.5 to +0.5	DA1 4	-0.5 to + 0	DA* 4
0.6 to 0.0	DA 15	0 to +1.5	DA2 5
0.6 to +0.2	DA116	0 to +2.0	DA2 6
-0.8 to +0.7	DA117	-0.5 to +2	DA2 7
1.0 to 0	DA118	0 to +3	DA2 8
1.0 to +0.1	DA 19	0.5 to +3	DA2 9
1.0 to +0.5	DA120	0 to +4	DA2* 0
1.0 to +1.0	DA121	0 to +6	DA2* 25
5 to 0	DA 22	0 to +5	DA2* 2
2 to 0	DA123	0 to +6	DA2* 3
2 to +2	DA124	1 to +6	DA2* 4
3 to +1	DA 25	0 to +8	DA2* 75
3 to +0	DA126	0 to +8	DA2* 6
4 to 0	DA 27	0 to +12	DA2* 77
4 to +0	DA128	0 to +15	DA2* 28
5 to 0	DA129	0 to +20	DA2* 29
6 to 0	DA 30	0 to +30	DA2* 30
8 to 0	DA 31	0 to +40	DA2* 3
10 to 0	DA 32	0 to +50	DA2* 32
2 to 0	DA133	0 to +60	DA2* 33
15 to 0	DA134	0 to +80	DA2* 34
20 to 0	DA135	0 to +100	DA2* 35
30 to 0	DA136		
Scale Range mm H ₂ O		Scale Range psi	
15 to 0	DA160	0 to +2	DA250
20 to 0	DA 61	0 to +3	DA251
25 to 0	DA162	0 to +4	DA252
30 to 0	DA 63		
40 to 0	DA 64		
50 to 0	DA165		
60 to 0	DA166		
80 to 0	DA168		
100 to 0	DA170		
150 to 0	DA 7		
200 to 0	DA172		
250 to 0	DA181		
300 to 0	DA173		
-400 to 0	DA174		
-500 to 0	DA175		
600 to 0	DA176		
800 to 0	DA 78		
10 to +5	DA188		
15 to -15	DA 90		
25 to +25	DA 92		
50 to +50	DA194		
700 to +50	DA 97		
150 to +50	DA 98		
100 to +100	DA199		

TABLE III

DIFFERENTIAL PRESSURE	
Scale Range	MODEL*
Scale Range H ₂ O	
0 to 0.5	DC3 0
0 to 0.6	DC311*
0 to 0.8	DC312
0 to 1.0	DC313
0 to 1.5	DC315
0 to 2	DC316
0 to 3	DC318
0 to 4	DC320
0 to 5	DC322
0 to 6	DC323
0 to 8	DC325
0 to 10	DC326
0 to 12	DC327
0 to 15	DC328
0 to 20	DC329
0 to 30	DC330
0 to 40	DC331
0 to 50	DC332
0 to 60	DC333
0 to 80	DC334
0 to 100	DC335
Scale Range mm H ₂ O	
0 to 5	DC360*
0 to 7.5	DC361
0 to 25	DC362
0 to 30	DC363
0 to 40	DC364
0 to 50	DC365
0 to 60	DC366
0 to 80	DC368
0 to 100	DC370
0 to 150	DC37
0 to 200	DC377
0 to 250	DC381
0 to 300	DC373
0 to 400	DC374
0 to 500	DC375
0 to 600	DC376
0 to 800	DC378
0 to 1000	DC380

* Not for use with pneumatic transmitter

STANDARD RANGES AND MODELS
(Bellows Mechanism)

PRESSURE		PRESSURE		LEVEL		PNEUMATIC RECEIVER	
Scale Range	MODEL*	Scale Range	MODEL*	Scale Range	MODEL*	Scale Range	MODEL*
Scale Range Psi		Scale Range Psi to psig		Scale Range H ₂ O		Scale Range 3.27 psig 3.15 psig	
0 to 5	AD4 0	5 to +5	AD440	0 to 15	AD402	0 to 00	
0 to 0	AD4	5 to +0	AD44	0 to 20	AD403	area ca e	AA 01 AB 0
0 to 5	AD417	5 to +15	AD44*	0 to 75	AD404		
0 to 20	AD4 3	5 to +30	AD443	0 to 30	AD405	0 to 100%	
0 to 75	AD414	5 to +25	AD444	0 to 40	AD406	square root	AA10*
0 to 30	AD4 5	0 to +5	AD445	0 to 50	AD407	linear	AB102
		1 to + 1	AD446	0 to 60	AD408		
		0 to + 5	AD447			Any other	
		0 to +20	AD448			red	
		0 to +25	AD449			Tab or V	
		5 to +5	AD450			V to V	AA AB
		5 to +0	AD45				
		15 to +15	AD452				
		5 to +20	AD453				
		20 to +5	AD454				
		20 to +15	AD455				
		20 to +20	AD456				
		25 to +5	AD457				
		25 to +10	AD458				
		25 to +10	AD459				
		25 to +15	AD460				
		30 to +5	AD46				
		30 to +0	AD462				
		30 to + 5	AD463				

PRESSURE		LEVEL		PNEUMATIC RECEIVER	
Scale Range	MODEL*	Scale Range	MODEL*	Scale Range	MODEL*
Scale Range Hg		Scale Range H ₂ O		Scale Range 3.27 psig 3.15 psig	
0 to 10	AD42	0 to 15	AD402	0 to 00	
0 to 15	AD42*	0 to 20	AD403	area ca e	AA 01 AB 0
0 to 20	AD423	0 to 75	AD404		
0 to 25	AD424	0 to 30	AD405	0 to 100%	
0 to 30	AD425	0 to 40	AD406	square root	AA10*
0 to 35	AD426	0 to 50	AD407	linear	AB102
0 to 35	AD426	0 to 60	AD408		
0 to 0	AD431			Any other	
5 to 0	AD432			red	
20 to 0	AD433			Tab or V	
25 to 0	AD434			V to V	AA AB
30 to 0	AD435				

*Suff x must be added to MODEL designation to indicate scale color. White B blue G-green N-orange R-red Y yellow

**The last fourth and fifth characters in MODEL designation are a 3 digit code number identifying the scale range. See Tab or V V and V.




FIGURE 1 Mounting Dimensions for Flush Mounted Type PG Gage

INSTALLATION

UNPACKING

1 Remove all packing from shipping carton. Remove Type PG Multi Pointer Gage from carton.

2 Check for any obvious damage to carton or contents (see inside front cover).

3 **NOTE** If a bench test of the Type PG Multi Pointer Gage is desired before installation, refer to "Adjustment and Calibration".

MOUNTING

1 Make panel cutout in accordance with Figure 1 or 2 for flush or semi flush mounting, respectively.

2 Assemble left and right side plates (shown in Figure 12 or 13) to Gage with their screws and

lockwashers (Note that side plates for semi flush mounted Gages are not interchangeable).

3 For semi flush mounting, assemble dust cover to top of Gage.

4 Insert Gage in cutout from front of panel.

5 For semi flush mounting, assemble mounting support to top of Gage unit.

6 Place mounting caps over cup washers, then tighten mounting screws. Tighten locknut to secure clip screw (refer to Figure 12 or 13).

7 Remove protective tape from scale cover. Clean cover with soap and water or "Plastar" plastic cleaner and polish to obtainable from Bailey Meter Company in 10 ounce jars - specify Pt. No.

to open the instrument to atmosphere when blowing compressed air back toward pressure or draft source

4 Check connecting piping for leakage while under pressure with a leak-detecting solution

INTERNAL ILLUMINATION

1 Refer to Figure 1³ or 13 Make wiring connection from power source (115v AC, 50HZ or 60HZ) to lamp socket at bottom of Gage

2 To remove lamp unit for servicing, remove rear cover and slide lamp assembly out rear of

Gage When replacing lamp in Gage make certain slide assembly makes complete contact with socket at front of Gage

PLACING IN SERVICE

1 For Model □ instruments refer to Table I for required supply pressure to Booster Relay Turn ON supply pressure to Booster Gage should respond immediately

2 For all other models, Gage should respond immediately when tubing and piping connections are made to measured pressure source




FIGURE 3 Recommended Connecting Piping Arrangement for Diaphragm Mechanism Mode. □

ROUTINE MAINTENANCE

PERIODICALLY

1 Periodically blow down connecting piping as follows

a For direct connected bellows (Model AD) and Bourdon tube (Model B1) mechanisms, blow down connecting piping as outlined in Instruction Section G181

b For diaphragm (Model D□) mechanism, disconnect piping and blow compressed air back toward pressure or draft source (See Figure 5. Also see step 3 under "Connecting Piping" in "Installation" section)

c Periodically clean Gage scale cover or window as outlined under "Mounting", step 7

To remove scale cover or window, refer to "Removing Gage Window or Scale"




FIGURE 5 Four Way Blowdown Valve for Diaphragm Mechanism

NOTE Do not oil moving parts. Oil, instead of being beneficial, tends to collect dirt which interferes with operation.

CORRECTIVE MAINTENANCE

If Multi Pointer Gage fails to operate correctly after performing the applicable adjustments outlined under "Adjustment and Calibration", check for broken or damaged parts. If parts have become damaged and must be replaced, refer to applicable mechanism listed below for correct disassembly procedures. For a pneumatic transmitter, check operation of the Booster Relay as outlined under "Corrective Maintenance" in Instruction Section P997

BELLOWS MECHANISM DISASSEMBLY AND PRE-CALIBRATION

1 Remove Gage from panel (see "Removing Multi Pointer Gage"). Then remove window and side scale holder (see "Removing Gage Window or Scale"). Remove mechanism from case.

2 Refer to Figure 14. Remove screw (14), and nut and washer (16 and 9). Unscrew elastic stop nut (15) above bellows. Remove overtravel stop (3).

3 Remove nuts (13) and lockwashers (28). Then remove two screws (76) and lockwashers (27) and remove pad (6) holding bellows beam assembly (17).

4 Remove hex nut (13) and pivot (24) (using drift and hammer) to remove spring adjustment arm (25).

5 Remove screws (10). Then remove three screws (29) and bellows and piping assembly (4).

6 To reassemble mechanism, follow the reverse order of above "Disassembly". Before reattaching bellows mechanism to case (step 1), however, make the following pre calibration adjustments. Refer to Figure 6.

NOTE When making these adjustments, mount mechanism in suitable calibration fixture to simulate the case (such as a cut away case) and mount fixture at same angle as case will be mounted in panel.

a Adjust counterweight so it drives the pointer upward.

b Loosen overtravel stop screws so stop does not interfere with bellows motion.

c Apply midrange pressure to bellows connection. Turn spring adjustment screw until bellows beam is parallel to base.

d Apply maximum range pressure plus 0.2 psig to mechanism. Turn maximum stop screw in until it rests against bellows frame. Tighten elastic stop nut against overtravel stop.

e Apply minimum range pressure minus 0.2 psig (for suppressed ranges only) to mechanism. Turn minimum stop screw in until head rests against overtravel stop. Tighten hex nut against bellows frame.

f Loosen two screws on pointer drive arm and position drive arm parallel to bellows beam.

g Check calibration as outlined under "Bellows Mechanism" before placing in service.

BOURDON TUBE MECHANISM DISASSEMBLY AND PRE-CALIBRATION

1 Remove Gage from panel (see "Removing Multi-Pointer Gage"). Then remove window and side scale holder (see "Removing Gage Window or Scale").

2 Refer to Figure 15. Remove three screws (17) and remove mechanism from case.

3 Detach connecting link (3) at pivot (9).

4 Loosen locknuts (6) and back off jeweled bearings (5) from support (1). Then remove pointer assembly (4).

5 Remove screws and washers (15 and 16) and dismount stop support assembly (14) from Bourdon tube assembly.

6 Remove screws (17), disengage Bourdon tube mounting support (1) from base.

7 Remove screws (7) and detach Bourdon tube mounting support (1) from Bourdon tube assembly.

8 To reassemble mechanism, follow the reverse order of above "Disassembly." Before returning Bourdon tube mechanism to case (step 2), however, make the following pre calibration adjustments. Refer to Figure 7.

NOTE When making these adjustments, mount mechanism in suitable calibrat on fixture to simulate case (such as a cut away case) and mount fixture at same angle as case will be mounted in panel.

a Adjust counterweight so it drives the pointer upward.

b Loosen minimum and maximum stops.

c Apply maximum range pressure plus 0.2 psig to mechanism. Then tighten maximum stop nut.

d Apply minimum range pressure minus 0.2 psig to mechanism. Then adjust minimum stop screw.

e Check calibration as outlined under "Bourdon Tube Mechanism" before placing in service.

DIAPHRAGM MECHANISM DISASSEMBLY AND PRE-CALIBRATION

Replacing Diaphragm in Diaphragm Mechanism

1 Remove Gage from panel (see "Removing Multi-Pointer Gage"). Then remove window and side scale holder (see "Removing Gage Window or Scale").

2 Refer to Figure 16. Remove four screws (51) and lift mechanism from case.

3 Remove screws (21) from housing bottom (7). Separate housing bottom from housing spacer (8) (tap lightly with rubber mallet).

4 Refer to Figure 17. Firmly hold diaphragm center plates and remove screw (2) from diaphragm assembly (1). Avoid bending push rod (3) at pivot point. Pull diaphragm assembly away from housing spacer.

5 Position replacement diaphragm assembly (1) on housing spacer. DO NOT USE SEALING COMPOUND. Attach replacement diaphragm assembly on push rod (3) and secure with screw (2).

CAUTION Make certain flat end of push rod is perpendicular to pivot (Item 11, Figure 16) and push rod moves freely.

6 Refer to Figure 16. Align housing bottom (7), diaphragm assembly (48 or 49), and housing spacer (8) and secure with screws (21). Test for leakage at 8 psi static pressure. For differential instruments, (Models DC and DD), loosen magnet

clamp screw and deflect external magnet arm so that magnet touches cover clamp (24). Insert 0.075 inch non magnetic feeler gage between cover plate (25) and external magnet. Tighten magnet clamp screw. Pre calibrate replacement diaphragm assembly as outlined in steps below.

Models DA and DB Only

7 Install diaphragm mechanism and scale holder temporarily in Gage case (see steps 2 and 1 above). PLACE GAGE ON TEST BENCH AT SAME ANGLE AS WHEN PANEL MOUNTED.

8 Remove plug button (Item 55, Figure 17 or 13), screw (4), and washer (3) from housing bottom (7), and replace screw (4) only. Do not use washer. (See Figure 16.)

9 Using calibration setup as described under "Diaphragm Mechanism", apply midrange pressure to mechanism (connection A or C), and turn pointer zero adjustment screw (Figure 8) until indicating pointer is on midscale.

10 Turn front zero adjustment (Figure 8) counterclockwise until pointer just stops moving, indicating diaphragm has reached its mid position. Pointer should move downward when turning front zero adjustment counterclockwise. If not, turn front zero adjustment clockwise until upward motion of pointer is noted. Then turn counterclockwise until pointer just stops moving.

11 With midrange pressure applied to unit, loosen two screws on drive arm (Figure 8) to obtain a right angle relationship between connecting link and range arm (Angle "A" equals 90°).

12 Remove diaphragm mechanism from Gage, remove screw (4) and replace washer (3) and screw (4).

13 Before returning diaphragm mechanism to case (step 7), adjust counterweight (Figure 5) so it drives pointer upward with no input pressure applied.

14 Return diaphragm mechanism and plug button (Item 55, Figure 17 or 13) to case and mount case in Gage (see step 1).

15 Check calibration as outlined under "Diaphragm Mechanism" before placing in service.

Models DC and DD Only

16 Mount mechanism in suitable calibration fixture to simulate case (such as a cut away case). PLACE GAGE OR TEST FIXTURE ON TEST BENCH AT SAME ANGLE AS WHEN PANEL MOUNTED.

17 Refer to Figure 16. Remove screw (45) and nut (44). Replace with 10.375 x 3/16 screw tightened against bottom of diaphragm housing.

18 Using calibration setup as described under "Diaphragm Mechanism", apply midrange pressure to mechanism (connection A or C), and turn pointer zero adjustment screw (Figure 8) until indicating pointer is on midscale.

19 Turn front zero adjustment (Figure 8) counterclockwise until pointer just stops moving, indicating diaphragm has reached its mid position. (The pointer should move downward when front zero adjustment is turned counterclockwise. If not, turn front zero adjustment clockwise until pointer begins to move upward. Then turn counterclockwise until pointer just stops moving.)

20 With midrange pressure applied to unit, loosen two screws on drive arm (Figure 8) to obtain a right angle relationship between connecting link and range arm (Angle "A" equals 90°).

21 Remove 10.375 x 3/16 screw and replace with screw (45) and nut (44) removed in step 17.

22 Make the following pre calibration adjustments:

23 Set maximum and minimum stops as outlined in steps 23a, 23b and 23c below (refer to Figure 16).

(a) Apply pressure so pointer goes to top of scale holder. Then turn maximum stop screw (46) clockwise until pointer is just touching case. Lock screw with nut (44).

(b) Remove pressure from instrument.

(c) Turn front zero adjustment (Figure 8) counterclockwise until pointer rests at bottom of scale holder. Then turn minimum stop screw (45) clockwise until pointer is just touching case. Lock screw with nut (44). Turn front zero adjustment

CLOCKWISE to place pointer on minimum scale line

24 Return diaphragm mechanism and plug button (Item 55, Figure 12 or 13) to Gage case

25 Check calibration as outlined under "Diaphragm Mechanism" before placing in service

Replacing Range Spring in Diaphragm Mechanism

1 Remove diaphragm mechanism from case (see steps 1 and 2 under "Replacing Diaphragm")

2 Refer to Figure 16. Remove upper screws (21) and lift off top cover (connecting linkage arm and top cover will come off together on differential unit)

3 Remove two screws (20) and loosen two clamping screws (14). Then remove four screws (43) and lockwashers (32)

4 Remove spring and replace with new spring

5 To reassemble perform above steps in reverse order

6 Check calibration as outlined under "Diaphragm Mechanism" before placing in service

Disassembly of Magnet Assembly,

Model DC and DD

1 Remove diaphragm mechanism (Model DC or DD) from case (see steps 1 and 2 under "Replacing Diaphragm")

2 Refer to Figure 16. Remove screw (23), cover clamp (24), cover plate (25), and cover gasket (26)

3 Remove two screws (21) from follower arm hinge (29) and lift off magnet arm assembly

4 Remove screw (4) and washer (3) then loosen magnet clamp screw and remove internal magnet

5 Assemble magnet assembly as follows

a Insert internal magnet in range arm assembly (37) and position by holding flat, soft iron plate against face of casting and allowing magnet to draw itself against casting. Tighten magnet clamp (27.) Leave plate in place

b Slide magnet clamp and range arm tip on magnet assembly (27) to respective midpositions. Secure resulting assembly to housing cover with screws (21)

c Counterbalance arm (37) to cause magnet to balance 1/6 inch below center of opening if diaphragm assembly is mounted in lower position or 1/16 inch above center of opening if diaphragm assembly is mounted in upper position. Remove iron plate from front of internal magnet

d To reassemble mechanism, follow the reverse of above "Disassembly"

e Apply 8 psi static pressure and test for leakage

6 Perform steps 16 thru 25 under "Replacing Diaphragm"

Changing Range of Diaphragm Mechanism

Refer to Figure 16. After making any change as listed below, recalibrate mechanism as outlined under "Diaphragm Mechanism"

1 RANGE SCREW ADJUSTMENT Under table heading "RANGE SPAN" are minimum and maximum range values. For changes within the limits shown, recalibrate mechanism as outlined under "Adjustment and Calibration"

2 CLAMP POSITION Under table heading "Position" are position numbers. If change in range is great enough to necessitate a clamp position change, remove diaphragm mechanism top cover, and screws (14) and slide beam clamp (15) and spacer (16) to new position. Replace screws (14) and top cover

3 RANGE SPRING Under table heading "Item 38", are part numbers of range springs. If change in range necessitates a range spring change, follow procedure under "Replacing Range Spring in Diaphragm Mechanism", above

4 DIAPHRAGM ASSEMBLY Refer to Items 48 and 49 in the "List of Parts" for part numbers of Diaphragm Assemblies. If a change in range requires a diaphragm change follow procedure under "Replacing Diaphragm in Diaphragm Mechanism", this section

PNEUMATIC TRANSMITTER DISASSEMBLY AND PRE-CALIBRATION

1 Remove Gage from panel (see "Removing Multi Pointer Gage", below)

2 Refer to Figure 18. Detach link (10) from adjustable end (3). Remove screws (6) to separate transmitter mechanism from Gage case.

3 Refer to Figure 19. To replace O rings (11), remove screws (38) and lockwashers (39) and separate Relay (14) from transmitter mechanism support block (75). Remove one O ring (11) from counterbore in support block and two O rings from Relay. To disassemble Booster Relay, refer to Instruction Section P99.7.

4 Remove screw (19) to separate connector assembly (21) from support block (75), remove O ring (13).

5 Remove nut (36), lockwasher (35), screw (40), and lockwasher (41).

6 Remove link (10) between vane assembly (3) and offset drive arm (9).

7 Remove four screws (22) from tapped pads (16) and remove the following items from support block (25) as a complete assembly: bellows assembly (2), bellows beam (20), bellows beam hinge spring (15), nozzle assembly (4), and clamp block (17).

8 Turn bellows assembly (2) counterclockwise to remove it from support block (25). Remove O ring (12) from counterbore on support block.

9 Remove two screws (78) and lockwashers (34). Remove pivot (27) (using drift and hammer). Then lift out spring support (8).

10 To reassemble mechanism, follow reverse order of above "Disassembly". Before returning transmitter mechanism to case (step 1), however, make the following pre-calibration adjustments:

a Make certain that link (Item 10 Figure 19) is positioned in holes furthest from nozzle for direct loading operation or in holes closest to nozzle for reverse loading operation.

b Apply normal supply pressure (see Table 1) with suitable calibration device and cycle output thru full range ten times by moving drive arm (Item 9 Figure 19) by hand.

c Refer to Figure 9. Rotate range arm to obtain midrange output pressure (9 psig for Model PB or 15 psig for Model PA). With midrange pressure applied to mechanism, turn beam adjustment screw until bellows beam is parallel with transmitter base.

d Loosen nozzle clamp screw and position nozzle (maintaining midrange pressure) so vane is parallel with bellows beam.

11 With midrange pressure applied to transmitter, turn vane adjustment screw until vane connecting link forms right angles with vane drive arm and vane (see Angle "A" Figure 11).

12 Install transmitter in Gage case (step 2).

13 Check calibration as outlined under "Pneumatic Transmitter" before placing in service.

REMOVING MULTI POINTER GAGE

To remove a single Gage from the panel, proceed as follows. Refer to Figure 1 or 2.

1 Close valves in pressure line before disconnecting tubing.

2 Tag connecting tubing to identify correct connections when Gage is removed. When more than one Gage is removed, note position of each Gage in bank of Gages.

3 Unplug supply power line from connector at bottom of Gage.

4 Loosen locknuts on top and bottom mounting screws; loosen screws several turns.

5 Push mounting clips forward and remove mounting clip washers.

- 6 Remove Gage thru front of panel
- 7 To remount Gage, perform steps 1 thru 6 in reverse order

REMOVING GAGE WINDOW OR SCALE

To remove Gage window or vertical scale for cleaning, replacement, or to free indicating pointer for Gage mechanism removal, proceed as follows. Refer to Figure 12 or 13.

- 1 Hold lower trim cover (3) and top trim cover (33) open with cover catches (5)
- 2 Remove Gage window (2) by loosening four retaining screws until screws are free of housing (1)
- 3 Remove scale holder (36) by removing two screws (Item 35, Figure 12 or Item 11 Figure 13)
- 4 Slide scale (37) and color shield (43) out of scale holder

ADJUSTMENT AND CALIBRATION

Measuring or transmitting mechanisms included in the Multi Pointer Gage are factory calibrated and should require no further adjustment. Before placing in service, however, check applicable measuring or transmitting mechanism calibration as outlined below. (Note that scale rests correctly on scale holder as shown in Figure 12 or 13 to assure accurate readings.)

NOTE: If Gage is to be removed from panel for testing, refer to "Removing Multi Pointer Gage" POSITION GAGE ON BENCH AT SAME ANGLE AS WHEN PANEL MOUNTED.

BELLOWS MECHANISM MODEL A□

- 1 Check installation while under pressure for leakage.
- 2 If bellows mechanism operates a pneumatic transmitter, check transmitter calibration as outlined under "Pneumatic Transmitter", this section, before proceeding.
- 3 Refer to Figure 6. Connect suitable calibrating device (such as mercury column or test




FIGURE 6 Adjustments for Bellows Mechanism, Model A□




FIGURE 7 Adjustments for Bourdon Tube Mechanism, Model B1

gage) to bellows mechanism pressure connection. Refer to "Explanation of Nomenclature" for applicable measured range and output pressure range.

4 Apply minimum measured range pressure to bellows mechanism. If indicating pointer does not read minimum scale, turn zero adjustment screw (Figure 6) to obtain correct readings.

5 Apply maximum measured range or output pressure. If indicating pointer does not read maximum scale, turn range adjustment screw to obtain correct reading.

6 Repeat steps 4 and 5 until correct minimum and maximum scale readings are obtained.

7 Apply midrange pressure to bellows mechanism. If pointer motion is non-linear, (pointer motion above and below midscale is not equal) and

a pointer reads low at midscale, loosen two screws on pointer drive arm and rotate arm to decrease angle "A" (see Figure 6),

b pointer reads high at midscale, loosen two screws on pointer drive arm and rotate arm to increase angle "A"

8 Repeat steps 4 thru 7 until correct minimum, maximum and midrange scale readings are

obtained for applied measured or output pressure values.

9 If correct readings cannot be obtained, refer to "Corrective Maintenance"

BOURDON TUBE MECHANISM MODEL B1

1 Check installation while under pressure for leakage.

2 Refer to Figure 7. Connect suitable calibrating device (such as a dead weight tester) to Bourdon tube mechanism pressure connection.

3 Apply midrange pressure to Bourdon tube mechanism. If indicating pointer does not read midscale, turn zero adjustment screw clockwise to increase or counterclockwise to decrease reading.

4 Apply minimum and maximum measured pressure to Bourdon tube and note pointer readings. If pointer does not read minimum and maximum scale, respectively, turn range adjustment screw clockwise to increase or counterclockwise to decrease pointer travel.

5 If pointer motion is non-linear (pointer motion above and below midscale is not equal) and




FIGURE 8 Adjustments for Diaphragm Mechanism Model DD

a pointer reads low at midscale, loosen connecting link screw and shorten link

b pointer reads high at midscale, loosen connecting link screw and lengthen link

6 Repeat steps 3 thru 5 until correct minimum, maximum, and midrange scale readings are obtained for applied measured pressure

7 If correct readings cannot be obtained, refer to "Corrective Maintenance"

**DIAPHRAGM MECHANISM
MODEL DD**

1 Check installation while under pressure for leakage

2 If diaphragm mechanism operates a pneumatic transmitter, check transmitter calibration as outlined under "Pneumatic Transmitter" before proceeding

NOTE When calibrating a Type PG□3, Model DC and DD mechanisms, make certain that supply pressure is maintained to the pneumatic transmitter mechanism. Transmitter must be operating when calibration is being checked

3 Refer to Figure 8. Connect suitable calibrating device (such as inclined manometer for very low draft, differential, or pressure ranges) or a mercury or vertical water monometer (for high ranges) to diaphragm mechanism

4 Apply minimum range draft or pressure to diaphragm mechanism. For differential pressure measurement, apply minimum differential to "A" or "C" connection (see table in Figure 1 or 2) leaving "B" or "D" connection open to atmosphere. If indicating pointer does not read minimum scale, turn front zero adjustment (for Model DA and DB instruments) or pointer zero adjustment screw (for Model DC and DD instruments). Refer to Figure 8. If step 4 must be repeated as a

rest of adjustments in the following steps. **CORRECT FOR ZERO ERRORS WITH THE POINTER ZERO ADJUSTMENT SCREW FOR ALL MODELS**

NOTE Model DC and DD diaphragm mechanisms for differential measurement are equipped with minimum and maximum stops. Use pointer zero adjustment screw to correct for zero errors (to avoid the necessity of resetting the stops) **DO NOT USE FRONT ZERO ADJUSTMENT FOR THIS PURPOSE**

5 Apply maximum draft or pressure to mechanism. If indicating pointer does not read maximum scale, turn range adjustment screw clockwise to increase or counterclockwise to decrease range.

6 Repeat step 4 (using pointer zero adjustment screw) and step 5 until correct minimum and maximum scale readings are obtained.

7 Apply midrange draft or pressure to diaphragm mechanism. If pointer reads high at midscale, loosen two screws on pointer drive arm and move arm toward pointer assembly slightly. If pointer reads low at midscale, move arm away from pointer assembly.

8 Repeat steps 4 thru 7 until correct minimum, maximum, and midrange scale readings are obtained for applied draft or pressure values.

9 If correct readings cannot be obtained, refer to "Corrective Maintenance"

PNEUMATIC TRANSMITTER MODEL PA

The pneumatic transmitter is factory calibrated for either direct or reverse loading operation. For direct loading, transmitter output pressure increases as measured variable increases (link in hole furthest from nozzle). For reverse loading transmitter output decreases as measured variable increases (link in hole closest to nozzle). Refer to Figure 19.

1 Refer to Figures 1 and 2. Attach an accurate, laboratory type gage to transmitter output connection "D". Apply normal supply pressure to connection "C" (see Table I).

TABLE I

Model	Output Pressure Range	Supply Pressure
PA	3.77 psig	30 psig
PB	3.15 psig	18 psig




FIGURE 9 Adjustments for Pneumatic Transmitter Model PA

Type PG Multi Pointer Gage

2 Refer to Figure 9. Disconnect connecting link between measuring mechanism and pointer assembly so pointer may be moved freely by hand.

3 Hold pointer on minimum scale. If output pressure gage does not read 3 psig (or, for reverse loading, 27 and 15 psig for Model PA and PB respectively), turn transmitter zero adjustment to obtain correct output pressure.

4 Hold pointer on maximum scale. If output pressure gage does not read 27 and 15 psig for Model PA and PB respectively (or, for reverse loading, 3 psig), loosen screw on range arm and shorten range arm to increase or lengthen arm to decrease output pressure.

5 Repeat steps 3 and 4 until correct minimum and maximum output pressures are obtained.

6 Hold pointer at midscale. If output pressure is high, turn vane adjustment screw counter clockwise. If output pressure is low, turn screw clockwise to correct reading.

7 Repeat steps 3 thru 6 until transmitter output pressure corresponds to indicating pointer readings at minimum, maximum and midscale.

NOTE: If it appears that the Booster Relay operation is faulty, refer to Instruction Section P99 7.

8 Reconnect link between measuring mechanism and pointer assembly, then check measuring mechanism calibration as outlined under applicable calibration instructions.




FIGURE 10 Diaphragm Mechanism, Model D□




FIGURE 11 Pneumatic Transmitter, Model PQ

DESCRIPTION OF OPERATION

BELLOWS MECHANISM MODEL A□

Refer to Figure 6 The bellows mechanism consists of a bellows connected by a spring loaded bellows beam to the pointer drive arm. Increases and decreases in measured pressure expand and contract the bellows, producing movement of the bellows beam. This motion is transmitted thru the pointer drive arm and connecting linkage to produce proportional movement of the indicating pointer.

BOURDON TUBE MECHANISM MODEL B□

Refer to Figure 7 The Bourdon tube mechanism for pressure measurement consists of a Bourdon tube connected to a pressure source and to connecting linkage which positions an indicating pointer. An increase or decrease in pressure applied to the Bourdon tube causes the tube to move. Motion of the tube end is transmitted thru connecting linkage to produce proportional movement of the indicating pointer.

DIAPHRAGM MECHANISM MODEL D□

Refer to Figure 10 The Model DA or DB mechanism for draft or pressure measurement consists of a diaphragm connected by a push rod range spring, and connecting linkage to an indicating pointer. An increase or decrease in measured draft or pressure, applied to the bottom of the diaphragm, causes the diaphragm to move. This motion is transmitted thru the push rod, range spring, and connecting linkage to produce proportional movement of the indicating pointer.

The Model DC or DD mechanism for differential pressure measurement consists of a diaphragm connected by a push rod range spring magnetic coupling, and connecting linkage to an indicating pointer. (The magnetic coupling is formed between the inside and outside of the diaphragm housing by two permanent magnets, one attached to the range spring and the other to the magnetic arm assembly.) High pressure is applied to the bottom of the diaphragm and low pressure to the

top. An increase or decrease in applied differential pressure causes the diaphragm to move. This motion is transmitted thru the push rod, range spring, magnet assembly, and connecting linkage to produce proportional movement of the indicating pointer.

PNEUMATIC TRANSMITTER
MODEL PC

Refer to Figure 1. The pneumatic transmitter transmits an output pressure proportional to a measured variable. This transmitter is always


mounted in the upper (right side) position in the Gage and is operated by a measuring mechanism mounted in the lower (left side) position.

An increase or decrease in the measured variable causes the measuring mechanism to move. This motion is transmitted thru the pointer assembly and connecting linkage to the vane drive arm. Rotation of the vane drive arm repositions the vane in relation to the nozzle to produce a proportional change in output pressure transmitted by the Booster Relay. (For operation of the Booster Relay, refer to Instruction Section P99-7.)

EXPLANATION OF NOMENCLATURE

Nomenclature consists of TYPE and MODEL, such as TYPE PG 100FA, MODEL DA110W DC310R. Basic enclosure details are covered by TYPE designation. Left and right gage details (mechanism and range), in that order are covered by MODEL designation.

NOTE Three digit code number 100 in MODEL designation indicates a blank scale. Three digit code number 900 in MODEL designation indicates a scale for ranges other than the standard ranges shown in Tables II, III, IV and V.



*Viewed from front of Gage

**When installed in a pressurized panel board for the measurement of draft or low pressure a Model DC or DD Diaphragm Unit is used. The measured medium is connected to one inlet and the other inlet is connected to tubing open to atmosphere outside the pressurized panel.

***Right Side Only

†GP General Purpose NEMA I

†WP Weatherproof NEMA III (Type PG13 Only)

Refer to the nameplate on the bottom of the Type PG Multi Pointer Gage for the Nomenclature designation. An 'X' in any Nomenclature position indicates that the variation is special. An 'X' as a suffix to either Type or Model Nomenclature indicates that the Gage includes a special feature not covered by Nomenclature.

SPECIFICATIONS

Standard ranges	See Tables thru V
Accuracy*	Direct Pressure or Draft $\pm 1\%$ of span Pneumatic Receiver $\pm 1/2\%$ of span Pneumatic Transmitter $\pm 1/2\%$ of span
Construction	Enclosure High impact zinc Provides space for two indicators or one indicator and one pneumatic transmitter Weather proofing similar to NEMA Type 3 standard on units equipped with pneumatic transmitter and saveable on indicator gages Mechanism See Normicature Spring Constant modulus alloy Pivots Stainless steel Scale cover Clear molded plastic
Mounting	Flush or semi flush Each unit mounts separately regardless of number mounted in a single panel cutout
Indicating scale	Scales constructed in two parts graduated units and range figures on clear polystyrene in front; polystyrene cover shield in rear. Color shield available in white, blue, green, orange, red, or yellow. Standard scales have back figures and letters with 4, 5, 6, 8, or 10 major divisions and 20, 25, 30, 40, or 20 minor divisions respectively. Maximum number of range figures is 7. Each range figure is limited to a maximum of 3 characters. Numerals and decimal point are 1/2 characters.
Service legend	Located below indicator Two lines with maximum of 12 characters and spaces per line
Transmitter air requirements	30 psig for 3-27 psig range 18 psig for 3-15 psig range Air consumption less than 0.10 scfm at balance on dead-end service
External connections	1/4" 18NPT female
Electrical supply (internal illumination)	Standard 118v AC, 60/60Hz Internal illumination on standard on units

*As defined by SAMA Standard PMC20

NOTE SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE.

REPLACEMENT PARTS

SPARE PARTS KITS

The Spare Parts Kits shown in Figures 12 thru 19 should be carried in stock. Specify the Spare Parts Kit part number to order a complete kit.

ORDERING INDIVIDUAL PARTS

Figures 12 thru 19 are Parts Drawings of the Type PG Multi Pointer Gage. Normally, these drawings will apply to the Gages furnished. However, there may be individual differences in specific Gages because of

1. Design changes made since the printing of this Instruction Section, or

2. Special design of equipment furnished to make it suitable for a specific application.

Therefore, when ordering individual parts, assure receipt of correct replacements by specifying on order

a. Complete nomenclature code number, part number, series label number and S.O. number of equipment for which parts are desired, and

b. The Parts Drawing Number on which each part is illustrated (The Parts Drawing Number is given in the Figure caption.)




FIGURE 1' Parts Drawing M42 25, Case and Pointer Assembly




TABLE A

TYPE	MODEL	ITEM 19	ITEM 25	ITEM 29	ITEM 42	ITEM 53	ITEM 54	ITEM 66	ITEM 69	ITEM 73
PG13CVA	A & DC	2	451880 1	0	0	0	0	0	2	10 32x3 8 FLAT HEAD SCREW
	B1		452064 1							
PG13GTA	A & DC	1	451880 1	2	1	1	1	2	0	452219 5
	B1		452064 1							

TABLE C

ITEM 43	COLOR
451996 1	WHITE
451996 2	GREEN
451996 3	BLUE
451996 4	PINK
451996 5	ORANGE
451996 6	YELLOW

TABLE D (ITEM 75)

MODEL	PORTS A & B	PORTS C & D
DA DB	A	C
DC DD	A & B	C & D

SPARE PARTS KIT

SPARE PARTS KIT PART NUMBER 250001 1	
QUANTITY	ITEM NUMBER
1 EACH OF	21 & 23

FIGURE 13 Parts Drawing M4 23 Case and Pointer Assembly for


Type PG Multi Pointer Gage

ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	45185	1 HOUSING	29	10 32 x 1 4	FLAT HD STN STL MACH SCREW - SEE TABLE A	52	R9023 0122	NO .2 B MCO INS TUBING 7 8 LG 4 REQD
2	451914	1 WINDOW	30	45191	1 BALLAST & SLIDE ASSY INCLUDES	53	SEE TABLE B	BUST COV SEE TABLE A
3	SEE TABLE A	LOWER TRIM COVER	30B	194783	1 BALLAST	54	SEE TABLE B	SEMI FLUSH MTG SPT SEE TABLE A INCLUDES
4	451943	1 COVER SPRING 2 REQD	30C	1941497	1 POLARIZED SOCKET	54A	35325	1 MOUNTING CLIP WASHER
5	451994	1 COVER CATCH 2 REQD	31	451928	1 TOP SUPPORT	54B	10 32 x 1 2	FLAT HEAD SCREW
6	451938	□ LEGEND 2 REQD SPECIFY ENGRAVING	32	451993	1 SHOULDERED SCR 2 REQD	55	19981	4 PLUG BUTTON
	5 32	PUSH ON TYPE SPEED NUT	33	SEE TABLE B	TOP TRIM COVER	56	452261	1 WEATHERPROOF SOCKET ASSY
8	4 40x1 2	PAN HD STN STL MACH SCREW 4 REQD	34	3 48 x 1 4	FLAT HD STN STL MACH SCREW 2 REQD	57	452148	1 SUPPORT PLATE
9	19"24"	4 RETAINING RING 4 REQD	35	451936	1 HI PLANK SCALE	58	197496	6 NO 8 NYLON SEALING WASHER 5 REQD
10	451927	1 BOTTOM SUPPORT	36	451925	1 SCALE HOLDER 2 REQD	59	452215	1 RUBBER PLUG 2 REQD
11	6 32x3 16	PAN HEAD CD PL STL SEMSEXT 11 REQD	3	452012	□ SCALE (SPECIFY ENGRAVING)	60	197496	4 NO 4 NYLON SEALING WASHER 2 REQD
11A	6 32x5 16	PAN HD CD PL STL SEMS EXT	38	451929	2 SCALE MASK	61	49126	8 SCREW
12	451939	1 MTG CLIP WASH 2 REQD	39	451929	1 SCALE MASK	61	49126	8 SCREW
13	10 32 x 1 2	FLAT HD STN STL MACH SCREW	40	452226	1 REAR COVER ASSY	62	5324438	1 SCALE RET CLIP 2 REQD
14	451940	1 SPECIAL NUT 2 REQD	41	R9410 0011	NO 4108 1 8 THICK X 1 4 WIDE POLYURETHANE FOAM WITH ADH BACK 25	63	197495	1 SEALING LOCKNUT 4 REQD
15	452262	1 PLUG	42	452256	1 BOTTOM MTG CLIP ASSY	64	6 32	STN STL HEX NUT
16	452021	1 GASKET 2 REQD	42A	4814 14 01	SHKPF DISH TOOTHED PERIPHERY LOCKWASHER	65	51106	00 STN STL SHAEPROOF LOCKWASHER
17	452049	1 COVER AS REQD	43	SEE TABLE C	COLOR SHIELD 2 REQD	66	197496	11 NO 10 NYLON SEALING WASHER SEE TABLE A
18	35652	1 MOUNTING CLIP ASSY SEE TABLE A INCLUDES ITEMS 19A 19B 19C & 19D	44	SEE TABLE B	LEFT SIDE PLATE	67	452216	1 RUBBER SEALING PLUG 8 REQD
19A	35426	1 MOUNTING CLIP	45	SEE TABLE B	RIGHT SIDE PLATE	68	452262	3 GASKETS 161 D2 REQD
19B	4 20	HEX NUT	46	R9410 0011	NO 4108 1 8 THICK X 1 4 WIDE POLYURETHANE FOAM WITH ADHESIVE BACK 22	69	452219	2 10 32 x 3 8 SEALING SCR SEE TABLE A
19C	197255	1 MOUNTING SCREW	47	4 40x1 4	FLAT HD STN STL MACH SCREW 2 REQD	70	197496	8 NO 8 NYLON SEALING WASHER 2 REQD
19D	4914 14 01	SHKPF PYRAMIDAL LOCKWASHER	48	0 x 1 8	RD HD STN STL THREAD FRMG SCR TYPE 1 2 REQD	71	452219	1 8 32 x 1 2 SEALING SCR 6 REQD
20	451918	1 LAMP SLIDE ASSY	49	1961400	1 NAMEPLATE	72	8 32 x 1 2	FLAT HEAD STN STL MACHINE SCR 2 REQD
21	194634	2 STARTER	50	6 32 x 3 8	FLAT HD STN STL MACH SCREW 6 REQD	73	SEE TABLE A	STN STL MACH SCR R941 1016NO 4108 1 8 THICK X 1 4 WIDE POLYURETHANE FOAM AS REQD
22	681"19	2 WIRE CLAMP	51	R2041 0030	NO 8 B MCO LEADWIRE WHT 42 REQD	74	452150	1 SRFG DAMP PLUG SEE TABLE D
23	194156	1 FLUORESCENT LAMP						
24	452148	1 COVER SCREW 2 RFQD						
25	SEE TABLE A	POINTER ASSY (LEFT SIDE MECHANISM*)						
26	1941566	1 SOLDERLESS WIRE CONNECTOR						
27	452219	2 10 32 x 3 8 SEALING SCR 4 REQD						
28	452218	1 GASKET						

*AS VIEWED FROM FRONT OF GAGE
 **TO SEAL UNITS WHEN MOUNTED SIDE BY SIDE APPLY SEALANT PT NO 1951188 1 TO TAPPED HOLES AND ADD ITEM 74 SEAL SIDE PLATE ITEMS 44 AND 45 WITH SEALANT PT NO 1951189 1 AND ITEM 27
 ***APPLY SEALANT PT NO 1951183 1 TO HOLE AND PRESS PLUG IN REMOVE EXCESS WHEN DRY

TABLE B

COLOR	ITEM 3	ITEM 33	ITEM 44*		ITEM 45*		ITEM 53	ITEM 54
			FLUSH MTG	SEMI FLUSH MTG	FLUSH MTG	SEMI FLUSH MTG		
BLACK	451934 1	451933 1	451969 1	451992 1	451969 1	451992 1	452149 1	451989 1
GRAY	451934 2	451933 2	451969 2	451992 2	451969 2	451992 2	452149 2	451989 2
GREEN	451934 3	451933 3	451969 3	451992 3	451969 3	451992 3	452149 3	451989 3
PLATINUM (BMCO USA)	451934 9	451933 5	451969 5	451992 10	451969 5	451992 9	452149 5	451989 5
PLATINUM (BMCO CANADA)	451934 10	451933 5	451969 5	451992 10	451969 5	451992 9	452149 5	451989 5



SPARE PARTS KITS											
SPARE PARTS KIT PART NO 25460 1				SPARE PARTS KIT PART NO 254060 2				SPARE PARTS KIT PART NO 254060 3			
MODEL	RANGE	QTY	ITEM	MODEL	RANGE	QTY	ITEM	MODEL	RANGE	QTY	ITEM
AA	3 27 PSIG	1 EACH	4 22 33 & SPRING ASSY 452255 1	AB	3 15 PSIG	1 EACH	4 22 33 & SPRING ASSY 683080 1	AD	6 5 PSIG	1 EACH	4 22 33 & SPRING ASSY 682586 1
AD	30 PSIG MAX SPAN			AD	15 PSIG MAX SPAN			AD	MAX SPAN		

FIGURE 14 Parts Drawing M4² : 1 Bellows Mechanism

Type PG Multi Pointer Gage


ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1		CODE LABEL SPECIFY NO WHEN ORDERING PARTS	17	197132 4	PAL NUT 2 REQD	34	197496 8	NO 8 NYLON SEALING WASHER, AS REQD
2		SEE TABLE SPRING ASSEMBLY**	18	451850 1	JEWELLED BRG, 2 REQD	35	8 32x1 2	PLT HD SST MACH SCR AS REQD
3	452263 1	OVERTRAVEL STOP	19	452154 1	MANIFOLD CLAMP			
4	452156 1	BELLOWS & PIPING ASSY	20	49128 1	SPECIAL SCREW 2 REQD	36	8 32x1 2	PLT HD CD PL STL MACH SCR, AS REQD
5	68820 1	BELLOWS BEAM HINGE	21	68507 1	SPECIAL WASH 2 REQD	37	452216 1	RUBBER PLLG, AS REQD
6	68824 1	TAPPED PAD 2 REQD	22	531428 10	O RING	38	19981 10	PLUG BUTTON AS REQD
8	6 32x5 8	PAN HD CD PL STL MACH SCR	23	452027 1	OFFSET DRIVE ARM	39	452219 1	SEALING SCR AS REQD
9	1106 00	CD PL STL SHKPRF LKWASH	24	68411 1	PIVOT			
10	6 32x1 4	PAN HD CD PL STL EXT SEMS	25	683108 1	SPRING ADJ ARM			
11	452029 1	RECEIVER MTG SUPPORT FOR TYPE PGD / (GP)	26	3 48x1 4	PAN HD CD PL STL MACH SCR 4 REQD			
	452221 1	RECEIVER MTG SUPPORT FOR TYPE PGK (WP)	27	1103 00	CD PL STL SHKPRF LKWASH 4 REQD			
12	68823 1	BELLOWS BEAM ASSY	28	1108 00	CD PL STL SHKPRF LKWASH			
13	8 32	CD PL STL HEX NUT 4 REQD	29	4 40x5 16	PAN HD CD PL STL EXT SEMS 3 REQD			
14	6 32x7 8	PAN HD CD PL STL MACH SCR	30	8 32x1 1 4	HDL SLOTT CD PL STL CUP PT SET SCR			
15	19"120 3	ELASTIC STOP NUT, 2 REQD	31		SEE TABLE RECEIVER ASSY*			
16	6 32	CD PL STL HEX NUT	32		POINTER ASSY, SEE PTS DWG M42 25			
			33	452026 1	LINK 1 REQD FOR TYPE PG10 & PG13, 2 REQD FOR TYPE PG20			

*ITEM 31 INCLUDES ITEMS 1 THRU 30

**SPRINGS FOR CODE LABEL 003 ASSEMBLIES MAY BE USED FOR REPLACEMENT IN CODE LABEL 002 ASSEMBLIES

TABLE						
TYPE	MODEL	RANGE			ITEM 2	ITEM 31
PG0000A	AA	3 2" PSIG			452255 1	452028 1
	AB	3 15 PSIG			683080 1	452028 2
	AD	RANGE SPAN	RANGE LIMIT			
			MIN	MAX		
30 PSIG 15 PSIG 6 5 PSIG		15 PSIG 15 PSIG 6 5 PSIG	-30 PSIG +15 PSIG +6 5 PSIG	452255 1 683080 1 682586 1	452028 1 452028 2 452028 3	
PG1300A	AA	3 27 PSIG			452255 1	452028 4
	AB	3 15 PSIG			683080 1	452028 5
	AD	RANGE SPAN	RANGE LIMIT			
			MIN	MAX		
30 PSIG 15 PSIG 6 5 PSIG		15 PSIG 15 PSIG 6 5 PSIG	-30 PSIG +15 PSIG +6 5 PSIG	452255 1 683080 1 682586 1	452028 4 452028 5 452028 6	

for Type PG Multi Pointer Gage, Model A□




ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	452058 1	MOUNTING SUPPORT	11	19"12 5	ELASTIC STOP NUT	20	452116 1	RUBBER PLUG SEE TABLE
2	8 32x3 8	FLAT HEAD CD PL STL MACHINE SCREW SEE TABLE	12	10 32x1 5	8 PAN HEAD CD PL STL MACHINE SCREW	21	14 496 8	NYLON SEALING WASHER SEE TABLE
3	452070 1	CONN LINK ASSY	13	452139 □	BOURDON TUBE ASSY SEE NOTE 2	22	8 37x3 8	FLAT HEAD STN STL MACHINE SCREW SEE TABLE
4	452084 □	POINTER ASSY SEE NOTE 1	14	452111 1	STOP SUPPORT ASSY			
5	451850 1	JEWELLED BRG 2 REQD	15	10 32x3 8	HEX SOC HEAD CD PL STL CAP SCREW 3 REQD			
6	197132 4	PAL NUT 2 REQD	16	NO 10	CD PL STL RES SPRING LOCK WASHER 3 REQD			
7	10 32x3 8	PAN HD CD PL STL EXT SEMS 2 REQD	17	8 32x5 10	PAN HD CD PL STL EXT SEMS SFF TARI F			
8	10 32x3 4	PAN HEAD CD PL STL MACHINE SCREW	18	452219 4	8 32x5 15 SEALING SCR, SEE TABLE			
9	4021084 1	CONN LINK PIVOT	19	29981 10	PLUG BIT SEE TABLE			
10	2 56x1 8	PAN HEAD CD PL STL EXT SEMS 2 REQD						

- NOTES 1 FOR CASE PARTS INCLUDING POINTER ASSY SEE PARTS DRAWING M42 25 & M42 23
2 BOURDON TUBE CAN BE REPLACED ONLY AS AN ASSEMBLY SPECIFY COMPLETE NOMENCLATURE AND SERIAL NUMBER STAMPED ON GAGE NAMEPLATE


SPARE PARTS KIT
PART NO 254058 1
1 EACH OF ITEMS 3 & 9

TYPE	TABLE							
	ITEM 2	ITEM 11	ITEM 18	ITEM 19	ITEM 20	ITEM 21	ITEM 22	
PG10 (GP)	2	2	0	8	0	0	0	
PG20 (GP)	2	4	0	6	0	0	0	
PG10 (WP)	0	0	2	0	9	1	1	
PG13 (WP)	0	0	5	J	5	2	2	
PG20 (WP)	0	0	4	0	8	2	2	

FIGURE 15 Parts Drawing M42 29, Bourdon Tube Mechanism for Type PG Multi Pointer Gage Model B1



HIGH RANGE DIAPHRAGM ASSY, PART NO 45 1978-1



LOW RANGE DIAPHRAGM ASSY, PART NO 45 1979-1

TEM	PART NO	NAME	TEM	PART NO	NAME
1	SEE TABLE	DAPH & GSKT ASSY	7	NO 6 32	HEX NUT 4 REQD
2	45 975	SPECIAL SCREW	8	45 977	STIFFENING RING 2 REQD
3	45 831 1	PUSHER ROD	9	451839 1	DAPH MASY 2 REQD
4	SEE TABLE	DAPH CLAMP 2 REQD	10	3 48x 4	PAN HD SCR 2 REQD
5	6 32x7/16	PAN HD MACH SCR 4 REQD	11	NO 4	STL WASHER 2 REQD
			12	NO 3-48	HEX NUT 2 REQD

	TEM 1	TEM 4
	DAPH & GSKT ASSY	DAPH CLAMP
PART NO 451978 1	452024	451837 1
PART NO 45 979	452025	45 838

FIGURE 17 Parts Drawing M-42 30, Diaphragm Assemblies for Diaphragm Mechanism, Model D□

Type PG Multi Pointer Gage





FIGURE 18 Parts Drawing M42 28. Pneumatic Transmitter for Type PG Multi Pointer Gage, Model P□



L S T O F P A R T S			
TEM	PART NO	N A M E	
	CODE LABEL	SPECIFY NO WHEN ORDERING	PTS
2	45 2007	BELLOWS ASSEMBLY	
3	45 953	VA NE ASSEMBLY	
4	45 949	NOZZLE ASSEMBLY	
5	45 850	JEWEL ED BEAR NG	2 REQ
6	97 32 4	PAL NUT	2 REQ
7	45 956	CLAMP P LATE	
8	45 2009	SPR NG S P P O R T	
9	45 2035	OFFSET CR VE ARM	
0	45 2039	L N K	
	53 428 2	O R N G.	3 REQ
2	53 428 3	O R N G	
3	53 428 10	O R N G	
4	SEE TABLE	BOOSTER RELAY	
5	68 820	BELLOWS BEAM H N G E SPR NG	
6	68 824	TAPPED PAD,	2 REQ
7	SEE TABLE	CLAMP BLOCK	
8	SEE TABLE	RANGE SPR NG	
9	6 32 X 1/2	PAN HD I T SEMS	
20	45 2040	BELLOWS BEAM	
2	45 945	CONNECTR ASSEMBLY	
22	3 48 X 1/4	PAN HD EXT SEMS	4 REQ
23	2 56 X 3/8	PAN HD NT SEMS	2 REQ
24	95 04	P P E PLUG SEE TABLE	
25	SEE TABLE	SUPPORT BLOCK	
26	4 40 X 1/4	PAN HD SCREW	2 REQ
27	68 4	P V O T	
28	4 40 X 3/16	SOC HD SCREW,	2 REQ
29	4 40 X 3/8	SOC HD CAP SCREW	
30	45 2032	ADJ SCREW BRACKET	
3	4 40 X 1/4	SOC HD SCREW	
33	R9023 0 29	BMOG NO 38 INSULATION TUBING	5 LG
34	NO 4 SAE	SPR NG LOCKWASHER	3 REQ
35	206 00	SHKPRF LOCKWASHER	2 REQ
36	8 32	HEX NUT	2 REQ
38	8 32 X 2 1/2	FL HD SCREW,	2 REQ
39	NO. 8 SAE	SPR NG LOCKWASHER	2 REQ
40	6 32 X 1/2	PAN HD SCREW	
4	206 00	SHKPRF LOCKWASHER	

USE	RANGE PS G	PNEUMATIC TRANSMITTER PART NO	TEM 25 SUPPORT BLOCK	TEM 4 BOOSTER RELAY	TEM 8 RANGE SPRING	TEM 24 P P PLUG	TEM 7 CLAMP BLOCK
CLASS PA TRANSMITTER	3 27	45 2043	45 2005	53 9700-3	68 870	0 M T	68 246
CLASS PB TRANSMITTER	3 5	45 2043-3	45 2005	53 9700-3	68 97	0 M T	68 246
TYPE PG MULT POINTER GAGE, MODEL PA	3 27	45 2043 2	45 2005 2	53 9700-2	68 870	2 REQ	68 834
TYPE PG MULT POINTER GAGE, MODEL PB	3 5	45 2043 4	45 2005 2	53 9700-2	68 97	2 REQ	68 834
HALF CHART APPL CAT ON, CLASS PA	3 27	45 2043 2	45 2005	53 9700-3	68 2474	0 M T	68 246
HALF CHART APPL CAT ON, CLASS PB	3 5	45 2043	45 2005	53 9700-3	68 870	0 M T	68 246

SPARE PARTS K T PART NO 256 60			SPARE PARTS K T PART NO 256 60 2			SPARE PARTS K T PART NO 256 60 3		
USE	QTY	ITEM NO.	USE	QTY	ITEM NO.	USE	QTY	ITEM NO.
CLASS PA TRANSMITTER	EA	2 0 2, 3 8 8	CLASS PB TRANSMITTER	EA	2 0 2, 3 8 8	HALF CHART APPL CAT ON CLASS PA2 PA3	EA	2 0 2, 3 8 8
TYPE PG MULT POINTER GAGE MODEL PA	3 EA		TYPE PG MULT POINTER GAGE, MODEL PB	3 EA			3 EA	
HALF CHART APPL CLASS PB2 8 PB3								

FIGURE 19 Parts Drawing P09 33 Model □ Pneumatic Transmitter Details

Product Warranty

Bailey Meter Company warrants the products manufactured by it to be free from defects in material and workmanship and will repair or replace, at its option, free of charge, for its factory, such part or parts which prove defective within one year from date of shipment. In respect to any products which are not an integral part of a product manufactured by the Company, the warranty given by the manufacturer thereof shall apply.

Shipping Damage

We strongly recommend that you inspect and test your instrument as soon as you receive it. If the instrument is damaged or operates improperly, notify the carrier for inspection of the shipment. The carrier's claim agent will prepare a report of damage, a copy of which should be forwarded to your nearest Bailey District Office (see back cover for location). The District Office will then tell you how to have the instrument repaired or replaced.

Service

The Bailey Meter Company is vitally concerned that your Bailey instrument provides continued, fine performance. This instruction manual is designed to fully describe the correct installation, operation and maintenance of your instrument under recommended conditions. If the need arises, factory trained Service Engineers are on call for prompt, in plant maintenance. Telephone or wire your nearby Bailey District Office to make arrangements for this service.

Replacement Parts and Supplies

Complete parts drawings and recommended spare parts kit information are included in this instruction manual. When replacement parts or supplies are required for maintenance of your Bailey instrument, contact your nearest Bailey District Office (see back cover for location). Always specify complete data on the instrument nameplate on your inquiry or order for parts. Common parts are available for shipment within 48 hours on a speed order basis.

•