









E96-701

# Instruction

## Personal Computer Software Computer-Aided Drawing/Text (CAD/TXT) (Release 4.2)



## NOTICE

The information contained in this document is subject to change without notice.

BAILEY CONTROLS MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Bailey Controls shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied or reproduced without the prior written consent of the Bailey Controls Company.

---

## Preface

---

This manual explains the features and commands of CAD software release 4.2. It is intended for users who will install and use this software. This manual is not a tutorial nor an application guide. The reader is presumed to have PC and DOS experience.

Key enhancements in this software release are

Support for C-Itoh, Genicom 4440 and HP Laserjet II printers

Support for Function Codes 113, 180, 181, 182, 183, 200, 201 and 210

Support for these modules: NGCMO2, INIPT01, CLC03 and CLC04

TEXTEWS has been enhanced considerably

This revision supersedes and replaces Instruction I E93 916 1B (release date 3/89)

## List of Effective Pages

Total number of pages in this manual is 218, consisting of the following

Page No.	Change No.
Preface	Original
List of Effective Pages	Original
iii through ix	Original
1 1 through 1 12	Original
2 1 through 2 6	Original
3 1 through 3 69	Original
4 1 through 4 5	Original
5 1 through 5 16	Original
6 1 through 6 5	Original
7 1 through 7 46	Original
8 1	Original
9 1 through 9 3	Original
A 1 through A 4	Original
B 1 through B 2	Original
C 1 through C 2	Original
D 1 through D 3	Original
E 1 through E 2	Original
F 1	Original
G 1 through G 6	Original
H 1 through H 4	Original
I 1 through I 2	Original
J 1 through J 2	Original
K 1 through K 2	Original
L 1 through L 2	Original
M 1 through M 2	Original
N 1 through N 3	Original
O 1 through O 9	Original

When an update is received, insert the latest changed pages and dispose of the superseded pages

**NOTE** On an update page the changed text or tables indicated by a vertical bar in the outer margin of the page adjacent to the changed area. A changed figure is indicated by a vertical bar in the outer margin next to the figure caption. The date the update was prepared will appear under the page number.

# Table of Contents

	<i>Page</i>
<b>SECTION 1— INTRODUCTION</b> . . . . .	<b>.1-1</b>
OVERVIEW	1 1
INTENDED USER . . . . .	1 1
RELATED DOCUMENTS	1 1
STANDARD DOCUMENT CONVENTIONS	1 2
ENGINEERING WORK STATION CONCEPTS AND DEFINITIONS	1 2
EWS	1 2
Drawing Files . . . . .	1 3
HOW THE EWS WORKS . . . . .	1 3
STRUCTURES	1 4
THE MAIN MENU . . . . .	1 5
SET UP JOB HEADER . . . . .	1 5
Set Up Module Header	1 6
CREATE CAD DRAWINGS	1 7
The Status Line	1 8
Entities	1 8
Layers	1 9
Shapes and Shape Libraries	1 9
Modes	1 9
Cursor Movement	1 10
Command Entry . . . . .	1 10
Function Keys	1 10
Screen Control . . . . .	1 11
Identify	1 11
Scaling . . . . .	1 11
ENDING A CADEWS EDITING SESSION	1 11
MONITORING AND TUNING	1 12
COMPILING AND DOWNLOADING	1 12
PLOTTING . . . . .	1 12
<b>SECTION 2 — INSTALLATION</b> . . . . .	<b>.2-1</b>
INTRODUCTION	2 1
<b>SECTION 3 CAD COMMAND REFERENCE</b> . . . . .	<b>.3-1</b>
INTRODUCTION	3 1
USE OF DELIMITERS IN COMMAND LISTS	3 1
EXAMPLES	3 1
ADD CONNECTION	3 2
ARC	3 3
ASSIGN NAME	3 4
AUTOPAN	3 5
CHANGE ATTRIBUTE	3 6
CHANGE LAYER	3 7
CIRCLE	3 8
COPY	3 9
CURSOR INCREMENT	3 10
DELETE ENTITY . . . . .	3 11
DISTANCE BETWEEN CURSOR POINTS . . . . .	3 12

## Table of Contents (cont nued)

	<i>Page</i>
<b>SECTION 3 CAD COMMAND REFERENCE (cont nued)</b>	
EXIT	3 13
EXPLODE	3 14
FIND ENTITY	3 15
FORM MACRO	3 16
FORM SHAPE	3 17
FUNCTION NAME	3 18
GRID	3 19
GRIDLOCK	3 20
HARD COPY	3 21
HORIZONTAL ORTHOGONAL (Solid Line)	3 22
HORIZONTAL ORTHOGONAL (Dashed Line)	3 23
HORIZONTAL ORTHOGONAL (Dotted Line)	3 24
HORIZONTAL ORTHOGONAL (Dot Dashed Line)	3 25
IDENTIFY	3 26
IDENTIFY POINT	3 27
IDENTIFY WINDOW	3 28
LAYER	3 29
LIBRARY MANAGER	3 30
LINE	3 31
LIST LIBRARY	3 32
LIST SPECIFICATIONS	3 33
MODIFY BLOCK	3 34
MONITOR/TUNE	3 35
MOUSE	3 36
MOVE	3 37
PAN	3 38
PLOT	3 39
QUICK CURSOR	3 41
QUIT	3 42
RECTANGLE	3 43
REDRAW	3 44
REFRESH	3 45
RESET	3 46
ROTATE	3 47
SAVE	3 48
SCALE ENTITIES	3 49
SET VIEW	3 50
SHAPE DELETE	3 51
SHAPE REFERENCE	3 52
STATUS	3 53
STRAIGHT LINE	3 54
SYSTEM MACRO	3 55
SYSTEM SHAPE	3 57
TEXT	3 58
TEXT DISPLAY	3 59
UNDELETE SHAPE	3 60
USER LIBRARY	3 61

# Table of Contents (cont nued)

	<u>Page</u>
<b>SECTION 3 CAD COMMAND REFERENCE</b> (cont nued)	
USER MACRO	3 62
USER SHAPE	3 63
VERTICAL ORTHOGONAL (Solid Line)	3 64
VERTICAL ORTHOGONAL (Dashed Line)	3 65
VERTICAL ORTHOGONAL (Dotted Line)	3 66
VERTICAL ORTHOGONAL (Dot Dashed Line)	3 67
VISIBLE LAYER	3 68
ZOOM	3 69
<b>SECTION 4 THE NETWORK 90 COMPILER</b> . . . . .	<b>4 1</b>
INTRODUCTION	4 1
Using the Module Selection Methods Efficiently	4 2
NETWORK 90 COMPILER ERROR MESSAGES . . . . .	4 4
<b>SECTION 5 CAD UTILITIES</b> . . . . .	<b>5 1</b>
INTRODUCTION	5 1
TRENDING AND TUNING	5 1
START UP	5 2
TRENDING	5 2
TUNING	5 3
SCREEN LAYOUT	5 4
FUNCTION KEYS . . . . .	5 4
MODULE MAINTENANCE UTILITY	5 8
How To Use The Module Maintenance Utility	5 8
Error Codes . . . . .	5 9
COMPRESS LIBRARY UTILITY	5 9
TRACE UTILITY	5 9
PRINT/PLOT UTILITIES	5 12
Print from DBF Genicom Printers	5 12
Print from DBF LaserJet II Printer	5 12
C Itoh Printer	5 14
Plot from DBF	5 14
How To Create A Batch File	5 14
Plot from DMP 60 . . . . .	5 15
<b>SECTION 6 — PC TO PC COMMUNICATIONS</b> . . . . .	<b>6-1</b>
INTRODUCTION	6 1
MODEM SETUP	6 1
HOW TO RUN THE PROGRAM	6 1
THE SCREEN	6 2
OPERATION	6 3
CHANGING DEFAULTS	6 3
TRANSMITTING A FILE	6 4
Preparing the Receiver S de	6 4
Preparing the Sender	6 4
After the Transmit	6 4
SAMPLE DEFAULTS FOR TYPICAL USERS	6 5
PC to PC Direct Connect	6 5
PC to PC Through a Modem	6 5

## Table of Contents (continued)

	<b>Page</b>
<b>SECTION 7 TEXT ENGINEERING WORKSTATION</b> . . . . .	<b>7-1</b>
INTRODUCTION	7 1
START UP	7 1
SELECTING THE COMMUNICATIONS PORT	7 2
RESTARTING THE CIU/SPM	7 2
USING A MODEM	7 3
SCREEN EDITING	7 3
TEXT CONFIGURATION MAIN MENU	7 4
MODIFY MODE	7 5
Inspect	7 6
Setting Module Modes	7 8
Module Problem Reports	7 9
CONFIGURE BLOCK	7 13
Modify File Header	7 14
Add, Modify, Delete Blocks	7 15
Copying Blocks	7 17
LIST/SAVE/LOAD CONFIGURATION	7 19
Listing a Module Configuration	7 20
Listing Configuration Files	7 23
Saving (Uploading) Module Configurations	7 24
Loading Module Configurations	7 26
MONITOR/TUNE	7 30
Monitoring a Value	7 31
Tuning a Value	7 32
Modifying the Scan Interval	7 33
Monitoring a Group of Points	7 34
VERIFICATION	7 36
Verifying Configuration File vs Module	7 37
Verifying Drawing File vs Module	7 39
Update Specifications in Drawing Files?	7 39
Verifying Drawing File vs Configuration File	7 39
Verifying Configuration File vs Configuration File	7 40
MONITOR GROUP DEFINITION	7 41
Enhanced Module Processing Section	7 43
STANDARD TEXT FILES	7 45
 <b>SECTION 8 MODULE BINDING UTILITY</b> . . . . .	 <b>8-1</b>
INTRODUCTION	8 1
 <b>SECTION 9 NETWORK 90 CROSS REFERENCE UTILITY (N90XREF)</b> . . . . .	 <b>9-1</b>
INTRODUCTION	9 1
How To Use The Cross Reference Utility	9 2
Error Messages	9 3
 <b>APPENDIX A CAD COMMAND SUMMARY</b> . . . . .	 <b>A-1</b>
 <b>APPENDIX B — GLOSSARY</b> . . . . .	 <b>B-1</b>

## Table of Contents (cont nued)

	<i>Page</i>
<b>APPENDIX C</b> <b>TERMINATION UNIT DRAWINGS</b> . . . . .	<b>C-1</b>
<b>APPENDIX D</b> <b>FIRMWARE REVISION LEVELS</b> . . . . .	<b>D-1</b>
<b>APPENDIX E</b> <b>TEXT ERROR MESSAGES</b> . . . . .	<b>E-1</b>
<b>APPENDIX F</b> <b>TEXT STATUS MESSAGES</b> . . . . .	<b>F-1</b>
<b>APPENDIX G</b> <b>FUNCTION BLOCK SHAPE LIBRARY</b> . . . . .	<b>G-1</b>
<b>UTILIZATION</b> . . . . .	<b>G 6</b>
Calculating Function Codes 30 and 45 RAM Utilization (NMFC03/04/05) . . . . .	<b>G 6</b>
Calculating Function Code 140 Non Volatile Memory (NVM) Utilization NMFC03/04/05) . . . . .	<b>G 6</b>
<b>APPENDIX H</b> <b>CAD SYMBOL LIBRARY</b> . . . . .	<b>H-1</b>
<b>APPENDIX I</b> <b>FILE GENERATION</b> . . . . .	<b>I-1</b>
<b>APPENDIX J</b> <b>ENHANCED COLOR DISPLAY</b> . . . . .	<b>J-1</b>
<b>APPENDIX K</b> <b>PASSWORD SECURITY</b> . . . . .	<b>K-1</b>
<b>APPENDIX L</b> <b>INSTALLING CTRL386</b> . . . . .	<b>L-1</b>
<b>APPENDIX M</b> <b>QUICK REFERENCE</b> . . . . .	<b>M-1</b>
<b>APPENDIX N</b> <b>SHEET NUMBER AND ADDRESS TRANSLATION TABLES</b>	<b>N-1</b>
<b>APPENDIX O</b> <b>STANDARDS</b> . . . . .	<b>O-1</b>
<b>OVERVIEW</b> . . . . .	<b>O 1</b>
<b>STANDARD COLORS</b> . . . . .	<b>O 1</b>
<b>DATA STATES</b> . . . . .	<b>O 2</b>
<b>INPUTTING DATA</b> . . . . .	<b>O 5</b>
<b>STANDARD FUNCTIONS</b> . . . . .	<b>O 6</b>
Help . . . . .	<b>O 6</b>
Clearing Configurations . . . . .	<b>O 6</b>
Printing Configurations . . . . .	<b>O 6</b>
Leaving Current Page . . . . .	<b>O 6</b>
Input Field Checking . . . . .	<b>O 6</b>
Justification . . . . .	<b>O 7</b>
Error Tones . . . . .	<b>O 7</b>
Clearing Input Field . . . . .	<b>O 7</b>

## Table of Contents (cont nued)

### APPENDIX O — STANDARDS (cont nued)

KEY FUNCTIONS	O 8
Edit Input Field Keys	O 8
Move Enter and Go to Another Page Keys	O 8
Restore Active Input Field Keys	O 9

## List of Illustrations

<i>No</i>	<i>Title</i>	<i>Page</i>
1 1	Deep Structure	1 4
1 2	Semi Deep Structure	1 4
5 1	Network 90 CAD Utilities Submenu	5 1
5 2	Tuning Parameter Display	5 3
5 3	Screen Layout Trending/Tuning Function	5 4
5 4	Specification Data	5 5
5 5	Trending Point Data Display	5 6
5 6	Digital Point Display	5 7
5 7	Settings File	5 13
5 8	Display Files Select Menu	5 13
5 9	DMP 60 Control Panel	5 16
6 1	PC to PC Communications Screen	6 2
7 1	CAD Main Menu	7 2
7 2	TXTEWS Main Menu	7 4
7 3	Modify Mode Menu	7 5
7 4	Inspect Input Screen	7 6
7 5	Inspect Sample Screen	7 7
7 6	Configure Input Screen	7 8
7 7	Status Byte Display Page	7 9
7 8	Status Info Report	7 10
7 9	Status Error Report	7 11
7 10	Module Problem Report	7 12
7 11	Configure Block Menu	7 13
7 12	Configuration Header Screen	7 14
7 13	Add Block Input Screen	7 15
7 14	Delete Block Screen	7 16
7 15	Copy Blocks Source Input	7 17
7 16	Copy Blocks Destination Input	7 18
7 17	List/Save/Load Configuration Menu	7 19
7 18	Listing Types	7 20
7 19	List by Function Code	7 21
7 20	List by Block Range	7 22
7 21	Example Block Listing	7 23
7 22	Save Module Screen	7 24
7 23	Uploading Function Codes	7 25
7 24	Download Module Screen	7 26
7 25	Programmable Module Options	7 27
7 26	Download in Progress	7 28
7 27	Monitor/Tune Menu	7 30

## List of Illustrations (cont nued)

<b>No.</b>	<b>Title</b>	<b>Page</b>
7 28	Monitoring a Block	7 31
7 29	Tuning a Block	7 32
7 30	Scan Interval Screen	7 33
7 31	Monitor Group Input Screen	7 34
7 32	Monitor Group Display	7 35
7 33	Verification Menu	7 36
7 34	Verify CFG File vs Module	7 37
7 35	Verification in Progress	7 38
7 36	Monitor Group Definition Page	7 41
7 37	Download Module Identification	7 43
7-38	Download Options	7 44
9 1	Symbo Cross Reference	9 2
J 1	Cabling for 16 Color Palette	J 2J
J 2	Cabling for 64 Color Palette	J 2
L 1	Contro /386 Setup Menu	L 2

## List of Tables

<b>No.</b>	<b>Title</b>	<b>Page</b>
1 1	Main Menu and Section Reference	1 5
1 2	Keyboard Function Keys F1 through F10	1 10
2 1	Configuration files	2 5
5-1	Sample Trend Graph Data	5 2
5-2	DMP 60 Plotter Options	5 16
7 1	MFC Capabilities	7 44
J 1	Layer Colors	J 1



## SECTION 1 — INTRODUCTION

### OVERVIEW

SCAD Engineering Workstation (EWS) software is an integrated control system engineering package. It allows you to do the following for process control strategies in an on-line or off-line environment:

design	trend
configure	tune
modify	verify
monitor	troubleshoot

SCAD runs on the IBM® Personal Computer XT® and AT®, Bailey XT and AT industrial computers and the Intel 30□™ series with the following basic configuration:

- 640 Kilobytes of RAM
- Color Graphics Monitor (refer to Section 2 for list)
- IBM Color Graphics Adapter Card
- Bailey Graphics Card

The following components are optional:

- Mouse
- Plotter
- Dot Matrix Printer
- Genicom Graphics Printer (34XX or 4440)
- HP Laserjet II Printer
- Modem
- Enhanced Monitor and Graphics Card

When each program starts, it displays its version and copyright notice.

### INTENDED USER

This manual is intended for users who are familiar with Network 90/Infi 90 logic and configuration and also the IBM XT or AT system, or the Intel 30□™. It assumes the users are also familiar with the commands of the Disk Operating System (DOS).

### RELATED DOCUMENTS

Computer Interface Unit Product Instruction, E93 905  
Function Code Application Manual, E93 900 20

## INTRODUCTION

---

### STANDARD DOCUMENT CONVENTIONS

This manual uses the following conventions to illustrate a typical prompt sequence between the user and the computer

*Prompt* user response [Key]

where

*Prompt* Actual text of a system prompt is given in italics

**user response** Text typed after the *Prompt*

**Key** Key to press

Example *Enter macro nm* **MACRO 1** [Enter]

The user responds to the prompt *Enter macro nm* by typing **MACRO 1** and pressing the [Enter] key

**NOTE.** [Enter] refers to the Return or Enter key

**Ctrl [Key]** Depress and hold down the Control key [Ctrl] while pressing another key Key

Example **Ctrl |P** Hold down the |Ctrl key while pressing the P key

**(max n)** Maximum characters allowed in a string

### ENGINEERING WORK STATION CONCEPTS AND DEFINITIONS

#### EWS

The computer has a main directory containing the Disk Operating System (DOS), utility programs, a user configured autoexecute (AUTOEXEC BAT) file and a computer configuration file (CONFIG SYS). There are also subdirectories (\EWS, \EWS2) of all executable files associated with SCAD, the system shape library, data files and all master drawing files (e.g., Termination Unit Master drawings)

The system operates all the programs and accesses all data files, master drawings, and the shape libraries while in a user defined subdirectory. This allows easy back up of all drawing files without having to waste disk space when backing up the execute and data files associated with SCAD

---

### Drawing Files

Creation of a drawing or changes to an existing one, are accomplished within a drawing file (Refer to Appendix I for file extensions)

SCAD runs under DOS (Disk Operating System) This manual assumes the user is familiar with the basic DOS commands. If you are not, please study both the DOS User's Guide and the DOS Reference Manual before proceeding with this manual. To make full use of the SCAD package, including PC to PC Communication, you must have DOS Version 3.0 or later, although SCAD operates with any DOS Version 2.0 or later.

---

### HOW THE EWS WORKS

The EWS programs are designed to be used together in the EWS system to:

1. Create job header and module header definitions (JHD, MHD).
2. Create new, or modify existing sheet drawings (CADEWS)
3. Cross-reference the drawing (N90XREF and Module binding).
4. Compile the drawing (N90CPLR)
5. Plot or print the drawing.
6. Download the configuration (TXTEWS).
7. Verify the configuration (TXTEWS)
8. Modify or tune (CADEWS) or (TXTEWS)
9. Monitor your system (Trend program).

This is typical of the way many users work with the SCAD system. While individual needs may differ, this explanation gives an overview of how the system is designed to operate.

All EWS programs may be executed from drives other than drive C:. Job Header files must reside in the path (drive and directory) specified in the Module Header file.

STRUCTURES

You must use one of the directory structures that follow  
 Never store your own files nor modify any files in the \EWS  
 or \EWS2 directories

The EWS programs work when you have files in any of these  
 environments Deep Structure, Semi Deep Structure or Flat  
 Structure Programs such as Job Header Definition (JHD),  
 Cross Reference (N90XREF) and Binder (NET90BND) all re-  
 quire these structures to operate properly

**DEEP STRUCTURE** This means that a particular job directory has exactly two  
 levels of subdirectories In Figure 1 1, directory \JOB01 has a  
 deep structure




Figure 1 1 Deep Structure

**NOTE:** The system follows the Loop PCU Module structure de-  
 fined in the module header file The subdirectories must be named  
 LX and PXX as shown in Figure 1 1

**SEM DEEP STRUCTURE** This means that a particular job directory contains exactly  
 one level of subdirectories A semi deep structure is shown  
 in Figure 1 2 The semi deep structure is used if a job has  
 only one loop




Figure 1 2 Semi Deep Structure

**FLAT STRUCTURE** This means that a particular job directory has no sub-  
 directories; it contains drawing files This structure is used  
 for small jobs

---

**THE MAIN MENU**

At the C prompt, type: **CMM** Enter to call the main menu  
 After the copyright screen, SCAD automatically displays the main menu Refer to Table 1-1

*Table 1-1 Main Menu  
 and Section Reference*

Selection	Name	Section
A	Job Header Def n t o n	1
B	Modu e Header Def n t o n	1
C	CAD	3
D	Compi at o n	4
E	Cross Reference	8
G	Text	7
H	Utilit es	5

**NOTE** The vers on number and ser a number of the ent re EWS package is shown at the bottom of th s menu

---

**SET UP JOB HEADER**

Job Header Definition (JHD) is a program used to define job related information and maintain job specific details, e.g., job number, job directory, customer name Pertinent information from this file is copied to newly created module headers

Type **A** from the main menu to execute the Job Header Definition program Alternatively, type **JHD** Enter directly from DOS The program prompts for a job number, directory and drive for where to place the JHD file The data entry fields are highlighted with the field width indicated Use the ↑, ↓ and Enter keys to toggle between the data entry fields Press F10 to enter data After the data is entered, the program asks if it should open a new file If you reply with a **Yes**, the program presents a new display that allows you to fill in job related information.


customer name  
 plant site  
 control engineer  
 customer order number

After entering this information, press F10 to create the JHD file

**Set Up Module Header**

Module Header Definition (MHD) is a program used to define module related information. The Module Header Definition includes such information as module file name, job number, job directory, and job directory drive. A second screen asks for additional information.

Type **B** to execute the Module Header Definition program from the main menu. Alternatively, type **MHD** Enter from DOS. The first entry prompted for is the file name. This format is required:



**NOTE:** Refer to Appendix N for an explanation of A0 A9 etc.

The other fields prompt for the job number and the location of the JHD file. Press **F10** to enter the data. The program then asks if it should create a new file. After a **Yes** reply, it presents a menu asking for module related information. Some of the fields have already been copied from the JHD file:

- customer name
- plant site
- contract number
- job number

This information is decoded from the MHD file name:

- loop address
- PCU address
- module address

The remainder of the information is entered by the user:

- configuration description
- drawing title
- drawing number
- module type
- module ID
- software revision

Most of the fields are optional. The only information that CAD requires is a correct MHD file name, module type and software revision number. The latter two items must match one of the modules in Appendix D.

**NOTE:** If you are going to cross reference drawings, you must enter a module ID.


You must create a separate MHD file for each module appearing in a set of drawings.

**CREATE CAD DRAWINGS**

- 1 Execute the CADEWS program

Type **C** from the main menu, or  
Type **CADEWS** [Enter] from the DOS prompt

- 2 When the prompt asks for a file name, enter the name of the drawing file to be edited. The format for a drawing file name is



**NOTE:** The last 3 characters of the file name **MUST BE** sheet number and revision level. This allows the Network 90 compiler and the cross reference programs to run properly for downward loading of modules. Sheet numbers should be consecutive starting at 01.

When the name of an existing file is entered, the system retrieves that file, displays it on the screen, and enters the DB mode of the drawing file environment.

To enter the name of a file which does not exist, include on the same line the option **/n** for new file. There must be no spaces between the file name and the **/n**. CAD asks for a **user-library name**. To use an existing user library, enter the user library name. The system creates the drawing file and begins an editing session as already described. If the **/n** is omitted, the system gives a message that the file was not found, and prompts for a valid file name.

When a user library file name that does not exist is entered, CAD asks to initialize this user library. Answer **Y**, and CAD creates the user library. Answer **N**, and CAD asks again for a user library name. Press [Enter] to bypass the creation of a new library.

## INTRODUCTION

When entering the /n option for a file that already exists, the system asks to delete the file. A Y response causes the existing file to be overwritten when you save the new file. An N response prompts for a new entry.

### NOTICE

A Y response PERMANENTLY ERASES the file. It CANNOT be RECOVERED.

**Examples**

<b>1010201A</b>	System searches for file 1010201A.DBF
<b>1010202A/n</b>	System creates a new file 1010202A.DBF (if it does not already exist)

### The Status Line

The line of information that appears at the top of the screen is called the status line. It gives in order: the file name, module type, module software revision level, loop number, PCU number, Module Address, magnification number, utilization factors (which consist of the percentage of bytes of non-volatile memory used, percentage of bytes of RAM used, and number of non-fixed blocks available).

### Entities

The objects that are placed on a drawing are known as entities. The entities that can be placed are as follows:

Lines	Defined by two or more points
Rectangles	Defined by points in opposite corners
Circles	Defined by a center point and a point on the circumference
Connection + Points	Single points where lines connect
Arcs	Defined by the arc center, a start point, and end point
Text	Alphanumeric information placed on the drawing
Shapes	Groups of entities

## Layers

Creating a drawing works on a specific layer in CAD. Layers are overlays on a drawing. There are 16 available layers in CAD, represented by different colors on the screen (use the Status command **ST** to see the available colors for each of the layers). When you are creating Infi 90 configuration drawings, we recommend that you always work on layer 1.

## Shapes and Shape Libraries

Shapes are entity groups that can be referenced and placed in the drawing as a single entity. System shapes are stored in a shape library. The CAD software system comes with a complete Infi 90/Network 90 shape library.

Libraries of user shapes and user macros can be created as described by the **UL** command in Section 3. Macros are collections of individual shapes put together in a particular way. This is very useful for recalling a frequently used configuration of shapes.


In addition, there are several Infi 90/Network 90 master termination unit drawings available in the CAD directory. For a complete listing of these drawings, refer to Appendix C.

## Modes

There are four modes of operation:

- 1 **DB** (Database) mode: DB is the top level mode. You must enter this mode before other modes. Most display related and status commands are entered from this mode.
- 2 **ID** (Identify) mode: Enter ID mode from DB mode. It is the primary editing mode.
- 3 **MT** (Monitor/tune) mode: Enter MT mode from DB mode. It is the primary mode in which on-line tuning and monitoring is done.
- 4 **LM** (Library Manager) mode: LM mode allows the user to list the contents of the system and user libraries, and delete/undelete user shapes from user libraries.

The diagram below summarizes the organization of the CAD modes:



## INTRODUCTION

### Cursor Movement

Use either a keyboard input (via the positioning arrows) or a mouse to position the cursor. You can also choose to display a grid of points on the screen. This is an array of points in multiples of 1/1000th of an inch (1 mil), when printed on a standard D size (22 inches x 34 inches) drawing. Gridlock (command GL) is a mode of operation that constrains the cursor to moving only on the grid points. It is always best to leave the gridlock on when editing drawings, since symbols are difficult to connect unless they are placed on grid points.

The Infi 90/Network 90 logic configuration symbols are on a scale of 1/10. Symbols must be placed on a grid of 100,100 (Function Key 1, F1) to allow the easy connection of symbols with lines, lines are designed to be placed using a grid of 20,20 F2. All blocks (function codes) must be on a grid of 100,100.

### Command Entry

CAD commands can be entered by typing the mnemonic for a command, or using the appropriate function key (Refer to Table 1.2).

### Function Keys

Function keys execute single commands that are frequently used. Table 1.2 defines the Function Keys.

*Table 1.2 Keyboard  
Function Keys F1 through F10*

Key	Function	Mnemonic
F1	GRID 100 100	GR 100 100
F2	GRID 20 20	GR 20 20
F3	FUNCTION NAME	FN
F4	DENTIFY	D
F5	MOVE	(D) MO
F6	DELETE	(D) DE
F7	ADD CONNECTION	AC
F8	CHANGE ATTRIBUTE	(ID) CA
F9	PAN	PA
F10	DATA ENTRY	NONE

**Screen Control**

The graphics screen is a window into the drawing. The size and location of this window can be controlled. CADEWS provides commands to:

- Zoom in on a section of the drawing, or
- Move the window around the drawing without changing scale

**Identify**

Before entities in the drawing are modified, select or identify them by entering **ID** or **IW**. When one or more entities are identified, they are highlighted to distinguish them from other entities in the drawing. Once identified, CAD asks for the command to perform on the entities.

**Scaling**

Scaling refers to the multiplication of all distance vectors drawn from a common reference point, by the same scale factor. Scaling expands a shape equally in all directions about the reference point. All vectors drawn from the scaling reference point to points on the entity are multiplied by the user defined scale factor.

With CAD, two distinct classes of graphic entities can be scaled: (1) any system or user shapes that do not contain Network 90 compulsory shapes, and (2) text string entities.

Direct scaling of lines, rectangles, circles, and arcs is not allowed. However, a shape can be created from any of these entities, and then scaled. A shape may also contain other shapes that have been previously scaled. Refer to the **SC** command in Section 3 for more information.

**ENDING A CADEWS EDITING SESSION**

<b>Commands</b>	<b>Action</b>
<b>EXIT (EX)</b>	Saves ed t, returns to ma n menu or DOS prompt
<b>RESET (RS)</b>	Abandons ed t prompts for new f e
<b>QU T (Q)</b>	Abandons ed t returns to ma n menu
<b>SAVE (SA)</b>	Saves ed t returns to same draw ng

The Save command may be used at any time to retain file edits. Bailey recommends that drawings are saved from time to time to reduce the chance of accidental erasure.

## INTRODUCTION

### MONITORING AND TUNING

When EWS is connected to a Infi 90/Network 90 System, on line monitoring and tuning of Infi 90/Network 90 System configuration can be done while viewing the drawing on the monitor Refer to the **MT** command in Section 3 for more information

These commands can be used while monitoring under the **MT** command

Command Name	Mnemonic
Cont nue	C
Escape	Esc
Ex t	Esc Esc
Pan	PA
Refresh Screen	RF
Set V ew	SV
Tune	TU
Zoom	ZO

### COMPILING AND DOWNLOADING

After all configuration drawings associated with a module have been completed, the compiler can be run The compiler is entered through option **D** on the main menu (Refer to Section 4 for more details) This allows the drawings associated with a module to be compiled into a format that can be downloaded using the **TEXT** program (option **G** on the main menu), or type **NET90CMP Enter** from the DOS prompt

Refer to Section 7 for information on the **TEXT** program

### PLOTTING

The CAD Utilities also permit printing or plotting from a **DBF** file Refer to Section 5, CAD Utilities, for more information on these utility programs

## SECTION 2 — INSTALLATION

### INTRODUCTION

This section explains the steps for installing the SCAD software. Follow these steps thoroughly and carefully.

When installing EWS Software for the **FIRST** time

- a On a new Bailey EWS XT, Bailey EWS AT or Intel 30 series, start at Step 1.
- b With a Bailey EWS Enhancement Kit when DOS is already on the hard disk, start at Step 6

**NOTICE**

Instruction Steps 1 through 5 will result in the **LOSS OF ALL DATA** currently on the hard disk Drive C \

- c With a Bailey EWS Enhancement Kit when DOS has not yet been loaded onto the hard disk, start at Step 1

Current CAD users installing an updated release, start at Step 6

1 Load DOS into computer memory (RAM) by placing the DOS disk (Version 2.0 or later) in Drive A and turning on the computer. If your computer is already on, place the DOS disk in Drive A and press **[Ctrl]**, **[Alt]**, and **[Del]** simultaneously.

2. Partitioning is a procedure that divides the Hard Disk (Drive C) into separate areas (up to 4 partitions), so more than one operating system can be used. One partition is allocated for CAD software, because only one operating system (DOS) is used. To partition the hard disk drive

Type **FDISK** **[Enter]**

A prompt appears on the screen. Press **Enter**. Press **[Enter]** again to allocate the entire hard disk to DOS.

3 Before the DOS hard disk partition can be used, it must be formatted by the **FORMAT** command. The **FORMAT** command sets up a File Allocation Table and a directory on the hard disk.

Type **FORMAT C:/S/V** **[Enter]**

- 4 Copy COMMAND.COM onto the hard disk

Type **COPY COMMAND.COM C:** [Enter]

- 5 Log on to Drive C

Type **C:** Enter

- 6 Copy DOS into its own directory on the disk

Type **MD DOS** Enter

Type **CD\DOS** Enter

Type **COPY A:\*. \* Enter**

- 7 Ensure that the \DOS directory is on the path

Type **PATH** Enter

If \DOS is not part of the path,

Type **PATH \DOS, [previous path setting if any]** Enter

**NOTICE**

TO PRIVATE SCAD USERS Step 9 will DELETE all DBF, SPJ and MHD files in the \EWS directory. Move any user files in the \EWS directory to another directory or disk before proceeding.

- 8 Insert the first SCAD floppy into drive A

- 9 Type **A:INSTALL** Enter

Follow the instructions displayed

**NOTE** Several files may be split between 2 disks. A program named PATCHEWS puts them back together. This is done automatically during installation.

If it becomes necessary to reload a file from the CAD disks to your EWS following the initial installation, be sure to look in PATCHEWS.BAT (on a release floppy) to see if the needed file is one that was split up. If it was

a. Load all parts of the file into your \EWS directory. File parts are identified by the appropriate base file name appended with @XX (where XX is an alphanumeric combination). For example, CADEWS.EXE may be split into CADEWS@A1 and CADEWS@2 on the SCAD disks.

b Invoke the CAT program that was loaded into your EWS directory Use the same format as found in the PATCHEWS.BAT file.

c Delete the file parts exactly as done by the PATCHEWS.BAT file

DO NOT execute PATCHEWS BAT

10 With DOS, a single directory is created on the hard disk when formatted This directory is known as the root, system, or main directory The root directory simply contains the name of files and subdirectories that exist on the hard disk

Return to the root directory

11 When DOS is started, it searches the root directory for a file named AUTOEXEC BAT If this file exists, it executes each time the system starts Refer to the DOS manual for more information on the AUTOEXEC BAT file

If an AUTOEXEC BAT file does not exist in the root directory, execute the following command

**COPY \EWS\AUTOEXEC.EWS AUTOEXEC.BAT** Enter

If an AUTOEXEC BAT file exists in the root directory, add the commands from the AUTOEXEC EWS file to the beginning of the BAT file in the same sequence If there is an existing PATH command in the AUTOEXEC BAT file, append the existing PATH command to the PATH command copied from AUTOEXEC EWS, and delete the old PATH command

12 Each time DOS is started, a search is also made for a file named CONFIG SYS If the file is found, DOS reads the file and interprets the commands within the file If the file is not found, DOS assigns default values for the configuration commands Type

**COPY \EWS\BAILEY.EWS BAILEY.SYS** Enter

If you are installing CAD on an Intel 301 refer to Step 13, otherwise proceed to Step 14

13 For memory management, the Intel 301 requires a driver called CTRL386. There are two types: Partition Loading and CONFIG SYS Loading. Refer to the label on the CTRL386 disk provided with the Intel 301 to determine the type.

**NOTE.** To re-install CTRL386 (due to disk failure, etc.), refer to Appendix L for CTRL386 installation instructions.

If type is Partition Loading, all installation has been done by Bailey. Proceed to Step 15.

If type is CONFIG SYS Loading, a statement must be included in your CONFIG SYS file. If a CONFIG SYS file does not exist in the root directory:

type **COPY \EWS\CONFIG2.EWS\CONFIG.SYS** Enter

If a CONFIG SYS file exists in the root directory, edit the file to contain:

```
device = \ctrl386\ctrl386.sys
device = bailey.sys
device ansi.sys
files 20
```

If you cannot determine the CTRL386 type, or have difficulties with installation, contact Bailey Technical Support.

Go to Step 15.

14 If a CONFIG SYS file does not exist in the root directory,

type **COPY \EWS\CONFIG1.EWS\CONFIG.SYS** Enter

If a CONFIG SYS file exists in the root directory, edit the file to contain:

```
device - bailey.sys
device ansi.sys
files 20
```

15 Restart the system.

16 Identify the monitor to SCAD:

a Verify that you are in the \EWS directory.

Type **CD\EWS** Enter

b Select the configuration file for the monitor you are using from Table 2-1

NOTE: If your monitor is not listed here, use the configuration file

Table 2 1. Configuration files

File	Monitor
conf g cga	BM Color Monitor
conf g cpq	Compaq 286 with Bailey Enhancement Kit H KT03
conf g ega	IBM Enhanced Color Monitor
conf g m81	Mitsubishi AUM 1831A Color Monitor <sup>1</sup>
conf g m71	Mitsubishi AUM 1371A Color Monitor <sup>1 2</sup>
conf g m2	Mitsubishi JUM 1471A Color Monitor Japan only <sup>1 2</sup>
conf g nec	NEC Multisync Color Monitor <sup>1</sup>
conf g pn	Princeton Ultrasynch Color <sup>1</sup>
conf g toe	Topo FTC 1461 Graphics Monitor Japan only <sup>1 2</sup>

NOTE:

1 These monitors are capable of running faster

2 If you are using any of these, you must contact Bailey to have modifications done to the Graphics Card

c Type COPY [monitor-configuration-file] CONFIG.BIN.

Example If you are using a NEC Multisync II,

type COPY CONFIG.NEC CONFIG.BIN Enter

17 Determine the Genicom 34 printer firmware level With the printer on

a If the printer is on line, press the <on line> key to place it in the local mode

b Press the <PRG> key The Printer Configuration Menu should print out. An example of the first line is

THE PRESENT CONFIGURATION IS (00506103)

The number between the parentheses is the printer firmware level

**INSTALLATION**

---

c If the firmware level number is 00403404 or higher, continue with Step 18. If the number is less than 00403404, execute Step 17d.

d Type **COPY PRNEWS2.CHK PRNEWS EXE** **Enter**

e Take the printer out of program mode by pressing the **[←]** key.

18 Create a drawing directory (refer to Create CAD Drawings in Section 1). If this is the first time CAD software is being loaded on the computer, do Steps 18a, b and c. Otherwise, go to Step 18c.

a Type **CD\** **Enter**

b Type **MD** [directory name (18 characters)] **Enter**

c Type **CD\[directory name]** **Enter**

19 Begin CAD

Type **CMM** (CAD Main Menu) **Enter**

to initiate the main menu and see the following list of options:

- A Job Header Definition
- B Module Header Definition
- C CAD
- D Compilation
- E Cross Reference
- F Module Binding
- G Text
- H Utilities

20 Fill out the software registration card (use the serial number at the bottom of the main menu) at the end of this manual and return it to Bailey Controls.

---

## SECTION 3 — CAD COMMAND REFERENCE

---

### INTRODUCTION

The CAD command reference section is organized in alphabetical order by command name. Mnemonics for each command appear in **boldface** below the command name.

---

### USE OF DELIMITERS IN COMMAND LISTS

Many CAD commands include a list as part of the command input. In general, CAD recognizes either spaces or commas as valid list separators. The reference manual uses spaces as separators, commas may be used if desired.

The hyphen character, -, can be used in many lists to indicate a continuous series of numbers. For example, 1-4 is the same as specifying 1 2 3 4 in a parameter list.

---

### EXAMPLES

Examples are given for many commands. A look at an example may be the fastest way to get the needed information about a command.

**NOTE:** When adding NETWORK 90 shapes from the system library the current layer should always be layer 1.

**CAD COMMAND REFERENCE**

---

**ADD CONNECTION****MODES:** DB**COMMAND:** AC or F7]

**USAGE:** Adds a connecting point at a desired location between NET WORK 90 function codes. If two or more lines are connected logically, they must be connected with a connection point. Note that a connection point may have, at the most, 4 lines emerging from it.

Example This is a cursor controlled command

- 1 Ensure that the grid is set to 20, 20
- 2 Position the cursor at the connecting point location
- 3 Type: AC Enter or F7


A connecting point appears at the cursor location

**MODES:** DB

**COMMAND:** A

**USAGE:** Draws an arc around a center point defined by two end points. After entering the command, CAD prompts for the arc center, arc start point, and arc end point. After entering the start point, a circle is outlined in gray. Select a second point from this circle, and the arc is drawn between the points.

Example



**NOTE:** Arcs are always drawn in a clockwise direction

---

**ASSIGN NAME**

**MODES:** DB

**COMMAND:** AN  
AN name

**USAGE:** Allows a new name to be assigned to a drawing file when in DB Mode. When EXIT or SAVE is used, the drawing file is saved on disk using the new name, the original file IS NOT overwritten.

If the command is entered without a name, CAD prompts for one.

This command is useful for creating backups or new files from existing files.

Example In DB mode editing drawing 1234567A

1 Type AN 1234568A Enter

2 The current drawing is now assigned the name 1234568A and is stored under that name when saved with an EXIT or SAVE command.

3 Drawing 1234567A remains unchanged.

**NOTE:** File names may contain up to 8 alphanumeric characters plus a DBF extension.

## AUTOPAN

**MODES:** DB MT

**COMMAND:** AP - Toggle switch  
AP ON Activate autopanning function  
AP OFF Deactivate autopanning function

**DEFAULTS:** Autopan On

**USAGE:** The Autopan function allows the user to continue panning the screen, once the current display edge has been reached. The next display is determined by the length of time the cursor key is pressed, once the edge has been reached.

**Example** If the AP toggle is on and the user wishes to move the current display window to another part of a drawing (outside the current window), the user would move the cursor in that direction. Once the display edge is reached, the user would continue to press the chosen cursor key. This action causes the message **Scrolling** to appear above the command line, indicating to the user that he is still panning. Once the key is released, the new location is drawn with the cursor at its center. The user has to experiment with this feature to learn the length of time needed to move a necessary distance off screen.

## CAD COMMAND REFERENCE

## CHANGE ATTRIBUTE

**MODES:** ID

**COMMAND:** CA or F8

**USAGE:** Enter or change the attributes (e.g., block number, text, etc.) of the identified entity

Enter **CA** and CAD prompts for

- 1 On/off page reference
- 2 30 Character I/O description
3. Block number.

The prompts vary depending on the type of symbol that was identified

**Example** For a digital input (Function Code 41) to be labeled block number 70.

1. Enter ID mode.  
Type: **CA** Enter or **F8**.
2. Type: **3** Enter.  
CAD prompts for block number.
- 3 Type: **70** Enter.

---

**CHANGE LAYER**

**MODE:** ID

**COMMAND:** CL  
CL n

**USAGE:** Places an identified shape on a new layer. When the command is entered without the layer, CAD prompts for the new layer number.

**CAD COMMAND REFERENCE**

---

**CIRCLE****MODES:** DB**COMMAND:** C**USAGE:** This command draws a circle

- Example
- 1 Type **C** Enter  
CAD asks for the center point of the circle
  - 2 Type in the center point of the circle  
CAD asks for a point on the circumference of the circle
  - 3 Type in a circumference point  
Once both points are entered, the circle is drawn

**MODES:** ID

**COMMAND:** CO

**USAGE:** This command copies an identified entity to a specified location. The entity must be identified using ID or IW before executing COPY.

- Example
- 1 Type **CO** [Enter]  
CAD prompts for the marking of two points: a shape reference point and a to point. A copy of the identified entity is placed at a position determined by the displacement of the two reference points.
  - 2 Type in the shape reference point and the to point.  
After placement, CAD continues to prompt for copy to points. Copying can continue until [Esc] is pressed.

**CAD COMMAND REFERENCE****CURSOR INCREMENT****MODES.** DB, ID**COMMAND:** CI  
CI X Y

(X and Y are positive integers, X sets cursor step movement in the x direction, Y sets cursor step movement in the y direction Units are drawing file units )

**DEFAULTS:** X 10 Y 10

Sets the cursor step size in terms of user drawing file units This command is useful for cursor placement when inserting user documentation (text strings) into the drawings The cursor increment should always be 100,100 when inserting NETWORK 90 compulsory shapes Type in X and Y to set the desired step sizes If an X and Y are not typed in, CAD prompts for them

GRIDLOCK overrides this command When GRIDLOCK is on, the cursor automatically moves to grid points defined by the GRID command

Example Type **CI 1000 1000** [Enter]

The cursor moves in steps of 1000 units in both the X and Y directions The units are in mils, corresponding to a step of one inch in both the X and Y directions

---

**DELETE ENTITY**

**MODES:** ID

**COMMAND:** DE or **F6**

**USAGE:** Deletes an entity or window identified using the ID or IW commands. Once an entity or window is identified, enter the DE command, and the system deletes the identified entity or window.

CAD returns to DB mode after the command has been completed.

**Example** Type **DE** **Enter**  
The identified entity or window disappears from the display.

**CAD COMMAND REFERENCE**

---

***DISTANCE BETWEEN CURSOR POINTS*****MODES:** DB ID**COMMAND:** DI**USAGE:** Determines the distance between two points on a drawingExample 1 Type **DI** **Enter**CAD prompts for one cursor point, then a second cursor point  
The distance is measured in mils

2 Type in the two points

EXIT

**MODES:** DB LM

**COMMAND:** EX

**USAGE:** If in DB mode, saves the current drawing to disk and exits CAD. If in LM mode, exits LM mode and returns to DB mode. CAD is not exited.

**Example** If in DB mode, type **EX**

The System exits CAD, saves the drawing file, and returns to the CAD main menu.

**EXPLODE****MODES:** ID**COMMAND:** XP

**USAGE:** Use XP to break a shape into its component parts. The individual parts can then be manipulated. Identify the shape by using the ID or IW commands.

Example To break a system shape into its component parts

1 Enter ID mode

Type ID Enter

2 Identify the shape

3 Type XP Enter

4 CAD identifies the number of exploded shapes. Now the individual lines, shapes, or text can be manipulated.

**NOTE** NETWORK 90 Comp atory shapes cannot be exploded.

**FIND ENTITY**

**MODES:** DB

**COMMAND:** FE  
FE search category search string

**USAGE:** Used to identify

NETWORK 90 function code by its block number, or its I/O text string

CAD responds with the found count and enters ID mode. The first entity is highlighted. Once a shape is highlighted, any standard ID command is recognized. The command NX can be used to highlight the next found shape.

Example Type. FE Enter

Prompt 1

*Specify search type*

1(blk#) 2(NETWORK 90 description) 3(alias name)

Prompt 2

*Search for Blk # or*

*Search for Text (max 30) or*

*Search for alias name (max 8)*

Example Type FE 1,20 Enter

The system does a Type 1 (as shown in Prompt 1) search for block 20

**NOTE:** Max 30 and max 8 refer to the number of characters that can be typed in

## CAD COMMAND REFERENCE

## FORM MACRO

**MODES:** DB

**COMMAND:** FM  
FM macname

**USAGE:** A macro is a collection of entities that may be referenced as a single unit. Form Macro saves this collection of entities as a single unit in a user library. Type in FM, CAD prompts

- 1 Enter Macro nm (1st Alpha, max 8)
- 2 Mark window point 1 Draw a window around the symbols to be included in the macro
- 3 Complete window After the window is completed, the symbols are highlighted to indicate the shapes or entities that are in macro. To correct a mistake, press Esc and start over
- 4 Mark macro origin This is the macro reference point to be used when the macro is recalled
- 5 Enter macro description (max 60)

CAD tells when it is saving the macro and its description

Example Type **FM** Enter, receive the following prompts

- 1 Enter macro nm  
Type in the Text file name Enter
- 2 Mark window point 1  
Move cursor to window point 1 Enter
- 3 Complete window  
Move cursor to expand window (rubber band) Enter
- 4 Mark macro origin  
Move cursor to reference point Enter
- 5 Enter macro description  
Type **Single-ended input dipshunt** Enter

CAD responds **SAVE MACRO** *Textfile* *Single-ended input dipshunt*

**NOTE:** When a macro is saved NETWORK 90 shapes must have block numbers assigned. If the user wishes block numbers to be assigned when the User Macro (UM) command is used to recall the macro.

FORM SHAPE

**MODE:** DB

**COMMAND:** FS  
**FS** user shape name

**USAGE:** Saves a shape in the user library. As it does with the FM command, CAD responds with several prompts.

- Example
- 1 *Enter shape name*  
 Type in the Shapename Enter (8 characters maximum)
  - 2 *Mark window pt 1*  
 Move cursor to window point 1 Enter
  - 3 *Complete window*  
 Move cursor to expand window (rubberband) Enter
  - 4 *Mark pnt shape origin*  
 Move cursor to origin point of shape Enter
  - 5 *Mark pnt lower left extent*  
 Move cursor to lower left extent point Enter
  - 6 *Mark pnt upper right extent*  
 Move cursor to upper right extent point Enter

CAD displays the reference points and asks what to do next

Next? 1(save) 2(edit fields) 3(edit shape)

- Option 1 Saves the shape,
- Option 2 Allows the reference points to be changed,
- Option 3 Allows the shape to be edited

**NOTE:** User shapes cannot contain NETWORK 90 compatibility shapes

## CAD COMMAND REFERENCE

## FUNCTION NAME

**MODES:** DB

**COMMAND:** FN  
 FN shape name/function code number  
 FN shape block #

**USAGE:** Gets a NETWORK 90 function code from the library list for placement in the current drawing file. If the FN command is entered without the shape name parameter, CAD prompts for the name, and blk # (optional). The reference origin point of the shape is placed at the current cursor position.

- Example
- 1 Type **FN 37** **Enter**  
 Function Code 37 is retrieved from the library list and placed on the drawing
  - 2 Type **FN** **Enter**  
 CAD prompts for the shape name. No block number is assigned. (Use the CA command to assign a block number.)
  - 3 Type **FN fx, 100** **Enter**  
 CAD recalls shape fx and assigns block 100 to it

**MODES:** DB, ID

**COMMAND:** GR  
 GR ON  
 GR OFF  
 GR X Y

(X is the number of drawing units per grid division in the x direction (horizontal), Y is the number of drawing units per grid division in the y direction (vertical))

**DEFAULTS:** GR ON  
 GR 100 100

**USAGE:** Establishes grid spacing in user drawing units and controls the display of the grid

- 1 GR  
 This command toggles the grid display ON/OFF
- 2 GR ON  
 This command turns grid display on
3. GR OFF  
 This command turns the grid display off
4. GR X Y  
 This command sets the grid spacing in the x and y directions respectively, and turns the grid display on

Examples Type **GR ON Enter**

Type **GR Enter**

Type: **GR 100 100 Enter**

Grid points appear on the display at every 100 units in the x direction and every 100 units in the y direction

**NOTES**

- 1 CAD overrides the grid display setting and displays grid display if the spacing is such that points would run together on the display
- 2 The cursor can be locked to grid points using the GR DLOCK command
- 3 The current value of the grid setting can be observed by using the STATUS command
- 4 With GR DLOCK on the cursor steps lock to the GR defaults if GR DLOCK is off the cursor steps lock to the Current defaults

## CAD COMMAND REFERENCE

## GRIDLOCK

**MODES:** DB, ID

**COMMAND:** GL  
GL ON  
GL OFF

**DEFAULTS:** GRIDLOCK ON

**USAGE:** Locks cursor movement to grid points. The command toggles the current setting. If GRIDLOCK is off, cursor movement is controlled by the cursor increment setting entered using the CI command.

**Example** Assume GRIDLOCK is in the default ON condition

Type **GL** Enter  
GRIDLOCK is now disabled

**NOTE.** Use of the GL command in NETWORK 90 dialog/configuration is **NECESSARY** to ensure proper connection between shapes. Connections are made only at coincident vertices and points. GL ensures the proper connections are made by restricting connections to grid points.

The system is designed to drop shapes on the drawing with gridlock on and = 100 100 F1

Lines are designed to be drawn with gridlock on and = 20 20 F2

HARD COPY

**MODES:** Refer To USAGES

**COMMAND:** HC or **[Ctrl]** **[P]**

**USAGES:** Hard Copy allows the contents of a graphics display to be printed on a graphics printer, communicating through either parallel port 1 or 2. The highest print head speed is used, to allow for fast printing.

In CAD, use either HC or **[Ctrl]** **[P]**. The print can be made in both DB and MT modes.

In TREND, only the **[Ctrl]** **[P]** command can be used. The printed output has 5 different line types to distinguish between each point being trended.


**HORIZONTAL-ORTHOGONAL (Solid Line)**

**MODES:** DB

**COMMAND:** H

**USAGE:** Sets CAD to the HORIZONTAL ORTHOGONAL command to allow drawing solid lines. Angles are allowed only in 90° increments. Digitized points are connected by first completing the horizontal segment of the line.

Example



**NOTE:** HORIZONTAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and horizontal orthogonal lines.

Refer to **Line Command** for further details

---

**HORIZONTAL-ORTHOGONAL (Dashed Line)**

**MODES:** DB

**COMMAND:** H1

Used for drawing digital logic/configuration dashed connection lines on an analog drawing. Angles are allowed only in 90° increments. Digitized points are connected by first completing the horizontal segment of the line.

**Example** See the Example for Horizontal Orthogonal (Solid Line)

**NOTE:** HORIZONTAL-ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and horizontal-orthogonal lines.

Refer to **Line Command** for further details.

**CAD COMMAND REFERENCE**

---

**HORIZONTAL ORTHOGONAL (Dotted Line)****MODES:** DB**COMMAND:** H2

**USAGE:** Used for drawing dotted connection lines from adapt blocks on a configuration drawing. Angles are allowed only in 90° increments. Digitized points are connected by first completing the horizontal segment of the line.

Example See the Example for Horizontal Orthogonal (Solid Line)

**NOTE** HORIZONTAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and horizontal orthogonal lines.

Refer to **Line Command** for further details.

---

**HORIZONTAL ORTHOGONAL (Dot Dashed Line)**

**MODES:** DB

**COMMAND:** H3

**USAGE:** Used for drawing miscellaneous dotted/dashed lines on a logic/configuration drawing. Angles are allowed only in 90° increments. Digitized points are connected by first completing the horizontal segment of the line.

**Example** See the Example for Horizontal Orthogonal (Solid Line)

**NOTE:** HORIZONTAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and horizontal orthogonal lines.

Refer to **Line Command** for further details.

## CAD COMMAND REFERENCE

**IDENTIFY****MODES:** DB**COMMAND** ID or F4**DEFAULTS:** Searches the current working layer**USAGE:** Identifies an entity and puts the system in ID mode

CAD then searches the current working layer for the vertex or shape origin nearest to the selected point. The identified entity is then highlighted, and the system is in ID mode, ready to edit the entity.

Esc can be used to terminate ID and return to the DB mode. When leaving ID mode, identified entities return to their original color and all edits made are saved in the database. The identifying editing commands are now active (e.g., delete, move, rotate, etc.).

Example Type **ID ALL** Enter  
Closest entity on any layer is identified

Type **ID 2,4** Enter  
Closest entity on layer 2 or 4 is identified

Type **ID 6 - 10** Enter  
Closest entity on layer 6, 7, 8, 9, or 10 is identified

---

**HORIZONTAL ORTHOGONAL (Dot Dashed Line)**

**MODES:** DB

**COMMAND:** H3

**USAGE:** Used for drawing miscellaneous dotted/dashed lines on a logic/configuration drawing. Angles are allowed only in 90° increments. Digitized points are connected by first completing the horizontal segment of the line.

**Example** See the Example for Horizontal Orthogonal (Solid Line)

**NOTE:** HORIZONTAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and horizontal orthogonal lines.

Refer to **Line Command** for further details.

**CAD COMMAND REFERENCE**

---

**IDENTIFY**

**MODES:** DB

**COMMAND:** ID or F4

**DEFAULTS:** Searches the current working layer

**USAGE:** Identifies an entity and puts the system in ID mode

CAD then searches the current working layer for the vertex or shape origin nearest to the selected point. The identified entity is then highlighted, and the system is in ID mode, ready to edit the entity.

Esc can be used to terminate ID and return to the DB mode. When leaving ID mode, identified entities return to their original color and all edits made are saved in the database. The identifying editing commands are now active (e.g., delete, move, rotate, etc.).

Example Type **ID ALL** Enter  
Closest entity on any layer is identified

Type **ID 2,4** Enter  
Closest entity on layer 2 or 4 is identified

Type **ID 6 - 10** Enter  
Closest entity on layer 6, 7, 8, 9, or 10 is identified

## IDENTIFY POINT

**MODES:** DB ID

**COMMAND:** IP

**USAGE:** Reports the coordinates of a selected point

Example

1. Type IP Enter.  
CAD prompts for a point

2. Move the cursor to the point desired. Press Enter.  
The system responds with coordinates of the point

## CAD COMMAND REFERENCE

**IDENTIFY WINDOW****MODES:** DB**COMMAND:** IW**DEFAULTS:** Searches the current working layer**USAGF:** Similar to the ID command, except IW defines a window in which all entities are identified

CAD prompts for a point. This point becomes the corner of a rectangle which defines the identify window.

As the cursor is moved to select the second window point, CAD continuously draws a rectangle which outlines the current size of the window. When the second point is selected, CAD identifies all of the shapes and entities whose reference points lie within the window.

The identified entities are each highlighted. This group of identified entities is sometimes referred to as a window. The identify editing commands (e.g., MOVE, COPY, DELETE, etc.) apply to this window as a whole group. IW is the preferred command when more than one entity needs to be edited at one time.

Example Type IW Enter

CAD prompts for two points defining a window. Entities and shapes on the working layer that lie within the window are identified.

**NOTES**

- 1 Only entities whose vertices or origin reference points are inside the window are identified.
- 2 Use Esc] to exit from the IW command prior to entering the second point of the window definition.
- 3 Use Esc to terminate ID mode and return to DB mode.
- 4 WALL, Wn, Wjk, or Wj can be used to identify entities on layers other than the current layer.

---

**LAYER**

**MODES:** DB

**COMMAND:** LA  
LA n

**USAGE:** Indicates the current layer and allows switching to a different layer.

Example While in DB mode,  
Type: LA Enter.

CAD responds with:  
Layer set current layer  
LAYER ? \_\_\_\_

and indicates the current layer. If another layer is wanted, type in the number of the new layer.

**CAD COMMAND REFERENCE**

---

**LIBRARY MANAGER**

**MODES:** DB

**COMMAND:** LM

**USAGE:** Enters into Library Manager Mode

Example Type **LM** Enter  
 CAD gives a new screen and asks, *System/user?*

One of the following commands can then be entered

**System/user**

- LI Lists symbol names on the CRT
- LI/P Lists symbol names on the CRT and prints listing
- EX Exits from the Library Manager
- Esc also exits from the Library Manager

**User only**

- SD Deletes shapes from the user library
- UN Undeletes shapes from the user library

**NOTE:** The category number for each shape is as follows

- 1 NETWORK 90 function code shapes
- 2 Other miscellaneous shapes
- 3 Other miscellaneous shapes
- 4 Other miscellaneous shapes
- 5 System macros
- 6 User shapes
- 7 User macros

**MODES:** DB  
**COMMAND:** L  
**USAGE.** Draws a line at any angle

Example 1 Type L [Enter]

CAD displays the following prompt

*Point*

2 Key in and enter the actual coordinates of the beginning point of the line. If you press **Enter** without keying in coordinates, the current cursor coordinates are used.

3 After you press **[Enter]**, the *Point* prompt is displayed again. You may now key in coordinates or press **Enter**. A line segment will be drawn connecting the two points.

4 You may now continue to draw line segments in this manner. When done, press **Esc**. All segments of the line are drawn in the current layer color.

5 Press **Esc** to cancel the command before the second point is entered. No line will be drawn.

6 After one or more line segments are drawn, you may type **UN Enter** to undraw the last segment drawn.

**CAD COMMAND REFERENCE**

---

**LIST LIBRARY****MODES:** DB**COMMAND:** LI  
LI/P**USAGE:** LI allows users to list System/user library shapes to a CRT.  
LI/P allows users to list system/user library shapes to a CRT  
and a printer (assuming a printer exists).

## LIST SPECIFICATIONS

**MODE:** DB

**COMMAND:** LS

**DEFAULT:** LS OFF

**USAGE:** Lists specifications of function blocks on the screen. Specification descriptions can also be listed. This is a toggle on/off command.

Example 1 Type. **LS**

CAD indicates  
*Specs off* or *Specs on* *Display Descriptions with Specs*  
(y/n)?

Each time LS is entered, status is reversed. Use the Refresh command (RF) to redraw the screen with the new status.

2 If the specifications are on, answer either **y** or **n** depending upon whether or not the specifications and their descriptions are listed together.

**NOTE:** The Refresh command (RF) must be used to see the screen with its new status.

## CAD COMMAND REFERENCE

## MODIFY BLOCK

**MODES:** DB

**COMMAND:** MB

**USAGE.** Allows the user to MODIFY specifications of NETWORK 90 function blocks. Use the MODIFY BLOCK command by placing the cursor next to the block to be modified.

Example 1 Type **MB** Enter

The specification information appears in a window at the bottom of the screen.

2 Specifications can be modified by entering specification number and value. Use the **Pg Up** and **Pg Dn** keys to display specifications if they do not fit in the display window.

3 When all of the specifications have been modified to your satisfaction, press **F10** to enter the data. To end the modify block session without making any changes, use **Esc**.

4 To remove the window, use the Refresh (RF) command.

**NOTE:** The input/output character string of a Function Generator block (function code 1) can be displayed graphically on the screen. This display option is available for both the MB and MT commands. The effect of each specification change can be graphically visualized.

After returning to the DB or MT mode command, the displayed graph can be printed by typing **HC** or using **Ctrl P**. These print commands work, however, only if the Gencom 3400 or 3410 printer is being used.

MONITOR/TUNE

**MODES:** DB

**COMMAND:** MT

**USAGE:** Monitor and tune NETWORK 90 blocks. When selected, the blocks displayed on the screen are updated with live data from the NETWORK 90 System.

**Example 1** To tune a block, move the cursor to the symbol to be tuned, press Esc and type TU Enter.

The block is highlighted and the specifications are displayed on the bottom of the screen. Tuning parameters may then be modified and entered to the system using F10.

**2** While in the monitor mode, the Zoom, Pan, and Set View commands are active. Pressing Esc once, freezes the screen, but leaves CAD in monitor mode, typing a C causes the monitoring to continue. Pressing F8 twice causes the MONITOR/TUNE mode to be terminated and the system returns to DB mode.

**NOTES:**

**1** The following commands can be used while monitoring under the MT command:

Continue (C)	Set View (SV)
Hard Copy (HC) or <u>Ctrl</u> <u>P</u>	Tune (TU)
Pan (PA)	Zoom (ZO)
Refresh (RF)	

Tuning parameters may be modified and entered in the module through these commands by pressing F10.

**2** To exit the tuning session without saving the changes, press Esc.

**3** See the note under the MB command for a discussion of the function on generator graph.

**MOUSE****MODES:** DB**COMMAND:** MS**USAGE:** Selects or deselects the mouse as the input device**Example MS**

The mouse is selected as the cursor control input device. If the mouse is already on, this command turns off, or deselects, the mouse.

**NOTE** The cursor keys on the keyboard work in parallel with the mouse.

**MODES:** ID

**COMMAND:** MO or [F5]

**USAGE:** Moves an identified entity or window to a new location. The entity or window must be identified by using ID or IW prior to using this command.

Example 1 Type. MO Enter  
CAD prompts for a *from* point and then a *to* point

2 Type in the from and to points  
The identified entity or window is moved to a new location determined by the displacement of the two reference points entered. CAD remains in the MOVE command and a new reference point can be selected to move the entity again.

3. Press Esc to terminate the MOVE command and remain in ID mode.

**NOTE** When applied to an identified window every entity in the window is moved.

**CAD COMMAND REFERENCE**

---

**PAN**

**MODES:** DB MT

**COMMAND:** PA or F9  
PA X Y

**USAGE:** Shifts the screen display such that the cursor location, or a given x,y coordinate, becomes the new center of the display screen

Example Place the cursor in the desired location,  
Type PA Enter]

The display is redrawn with the chosen point at the center of the display

**NOTES:**

- 1 Magnification is not affected by the PAN command
- 2 The REDRAW command returns the original display except that the magnification factors set to 1

**MODES:** DB

**COMMAND:** PL  
 PL f  
 (f = plot scale factor; a positive number)

**USAGE:** Generates a plot of a specified window in the drawing file. The command can be issued with or without the plot scale factor. If a scale factor parameter (f) is omitted, CAD prompts for it.

**Example** The PLOT command uses the following steps:

1. Ready the plotter. Baud rate should be set to 9600.

**NOTE:** For a D size drawing, the drawing must be oriented so that the width is larger than the height.

2. Turn on the plotter, remove the pen cap, and load paper into the plotter.

3. Select the size paper to be used. Small is C size, large is D size. Pressing either of these buttons causes the paper to cycle back and forth and insures the paper is properly loaded.

4. Type **PL** .

5. CAD prompts for a scale factor. A scale factor of 1 implies 1 x scale, 2 implies 2 x scale, etc. A scale factor of .5 implies a .5 x scale factor (half size).

**NOTE:** The NETWORK 90 drawings are in 1/10th scale.

6. CAD prompts for the layers to be plotted. Type in the desired layer numbers, or type **all** to plot all layers.

7. CAD prompts for the plot window. Type in two points to define the plot window.

8. CAD asks if the drawing is to be rotated 90°. Any vertical drawings which are being plotted at a scale greater than 5 must be rotated.

9. CAD prompts for a paper size.

10. CAD prompts for a plotter margin. Type in two numbers. The first refers to the x-margin, and the second refers to the y-margin. CAD assumes these to be in drawing file units.

*PLOT (continued)*

11 CAD asks to change pens for each layer of the plot. If answered **N**, CAD plots all the selected layers with the same pen. Plotting begins now if a plot file has not been created.

12 If a plot file has been created by typing **Y** at Step 10, exit to the main menu by typing **EX**.

**NOTE:** The following steps are applicable for Plot option D CAD Utilities Menu (option D of the main menu) for plotting from an external file created through the PL command (Steps 1-13).

13 Insert the file disk in drive A, if it has been saved on a floppy disk.

14 Type in **D** from the CAD Utilities menu.

15 CAD asks to

*Enter Plotter Model Code*  
1 (DMP 41) 2 (DMP 51) 3 (EXIT)

16 Type in the appropriate number.

17 CAD prompts

*Enter Baud Rate*  
1 (1200) 2 (9600) 3 (EXIT)

9600 is the recommended baud rate, however, the baud rate must match the baud rate of the plotter. Type in the appropriate baud rate.

18 CAD prompts, *Enter the Plot Disk File Name*. Type the file name to be plotted.

The plotter should begin plotting immediately.

**NOTES.**

1 The scale factor chosen applies to all layers to be plotted.

2 Choose only the layers that contain data. If a layer without data (as part of a range, for example) is chosen, the system must examine the drawing file for entities on that layer. This can increase plotting time.

---

**QUICK CURSOR**

**COMMAND:** QC

**MODES:** DB, ID

**USAGE:** Increases cursor speed as the cursor key is held down. The acceleration allows moving the cursor rapidly across the screen and still make small adjustments to the cursor position when close to the cursor destination.

Examples

- Type **QC** Enter Toggles Quick Cursor on/off
- Type **QC ON** Enter Turns Quick Cursor on
- Type **QC OFF** Enter Turns Quick Cursor off

**CAD COMMAND REFERENCE**

---


**QUIT****MODES:** DB**COMMAND:** Q**USAGE:** Abandons the current drawing file without updating disk files

Issuing QUIT in DB mode returns to the CAD main menu. The drawing **IS NOT** saved! Before aborting the drawing file, CAD prompts for confirmation.

**NOTE:** A ed ts to the current draw ng are ost when QU T s exe cuted and abort s conf rmed w th a Y response. D sk f es are not updated.

**RECTANGLE****MODES:** DB**COMMAND:** R**USAGE:** Draws a rectangle. After the command is entered, CAD prompts for one point, then a second point. The second point **MUST** be the corner of the rectangle opposite the first point.

Example



**CAD COMMAND REFERENCE**

---

**REDRAW****MODES:** DB**COMMAND:** RE**USAGE:** Redraws the screen display at 1X magnificationExample Type **RE** Enter

The display is redrawn at a magnification factor of 1X

---

**REFRESH**

**MODES:** DB

**COMMAND:** RF

**DEFAULTS:** Current visible layers prior to rf command

**USAGE:** Redraws the current display view without changing the current scale and magnification factors

Example Type **RF**

The display is redrawn at the current scale and magnification factors. All visible layers are redrawn.

## CAD COMMAND REFERENCE

**RESET****MODES:** DB**COMMAND:** RS

**USAGE:** Quits the current drawing and allows the user to begin editing a different drawing without exiting CAD. Resets and reinitializes the program.

The program prompts for confirmation before executing the command. ANY WORK DONE SINCE THE LAST TIME A SAVE COMMAND WAS EXECUTED IS LOST!

Example Type **RS** Enter

CAD prompts for confirmation of a system reset. Enter **Y** to confirm, enter **N** to return to the DB environment. If **Y** CAD prompts for the drawing file name to be edited.

**NOTE:** This is a powerful command. Changes made since the last SAVE command are lost. Drawing files saved to disk prior to using the RS command are not affected.

This saves time when another drawing edit is required since the shape library is not loaded again.

---

**ROTATE**

**MODES:** ID

**COMMAND:** RO  
RO n  
RO n

(n degrees in 90° increments)

**USAGE:** Rotates the identified entity or window around a selected point. Rotation angles must be in increments of 90°. A positive angle implies counterclockwise rotation about the selected point, a negative angle implies clockwise rotation.

If the angle is not supplied as a parameter, CAD prompts for it (0° is the default).

If the number of degrees entered is not a multiple of 90 degrees, the system truncates the input to the next lowest 90° increment.

Example 1 Type **RO** (the angle of rotation) Enter  
CAD prompts for a reference point

2 Type in the reference point  
The identified entity or window is rotated about this reference point

**CAD COMMAND REFERENCE**

---

**SAVE****MODES:** DB**COMMAND:** SA**USAGE:** Compacts the drawing file by removing all entries marked for deletion, and saves the current drawing file on disk under the currently assigned file name

Example When in DB mode,

Type **SA** Enter

Saves the current drawing file to disk

**NOTE.** It is a good idea to SAVE files periodically as they are worked on

## SCALE ENTITIES

**MODES:** ID

**COMMAND:** SC

**USAGE:** Multiplies all distance vectors, drawn from a common reference point, by the same scalar factor. This allows a shape to be evenly expanded in all directions about the reference point. Any system or user shapes that do not contain NET WORK 90 compulsory shapes or text string entities can be scaled. Lines, rectangles, circles, or arcs may NOT be directly scaled although shapes made from these entities can be scaled. Shapes that contain other previously scaled shapes may also be scaled.

Shapes can be assigned a scale factor from 1 to 100, text character size can be scaled from 10 to 4095.

In DB mode, specify scale when using either SS or US commands, using the format COMMAND, SHAPE NAME, SCALE FACTOR, e.g., **SS PRIR6 4 Enter**

**Example** In ID mode,

1 Type **SC Enter**

There are three scaling choices: +N, scale upwards by a factor of N, -N, scale downwards by a factor of N, N, replace current scale factor by N. If no scale factor is entered when SC is entered (e.g., SC 5), the system prompts for it.

2 Type in the scale factor

**CAD COMMAND REFERENCE**

---

**SET VIEW****MODES:** DB MT**COMMAND:** SV**USAGE:** Gives an enlarged view of a section of the present display window

CAD prompts for a first point to define the view window. As the cursor is moved to define the second point, the system draws a rectangle on the screen showing the extent of the view window. When the second point is entered, the display is redrawn to the new view.

CAD computes an integer magnification factor based on the window size selected. The resulting factor is displayed on the status line after the command executes.

Example Type **SV** Enter,

CAD prompts for two points defining the desired view window. After the second point is entered, the system redraws the screen such that the window selected occupies most of the display.

**NOTES.**

1 A REFRESH command can be used to redraw a SET VIEW window without altering its size or magnification.

2 REDRAW command redraws the current page at 1X magnification.

## SHAPE DELETE

**MODES:** LM

**COMMAND:** SD  
SD NAME

**USAGE:** Deletes shapes from the user library. Type in SD and CAD prompts for the shape name. Type in the shape name (wild cards are acceptable) and it is deleted from the user library.

Example 1 Type **SD** Enter,  
CAD responds. *Delete Shape(s), Name*

2 Type in the shape name  
CAD responds. *1 shape(s) deleted*

**CAD COMMAND REFERENCE**

---

**SHAPE REFERENCE****MODES:** DB**COMMAND:** SR  
SR ON  
SR OFF**DEFAULT:** SR OFF**USAGE:** Controls the display of the shape reference fields in the visible layers. The reference points appear as crosses (They may appear as dots at 1X magnification.)

Entering SR toggles the SHAPE REFERENCE display. Entering SR ON or SR OFF explicitly sets the display mode of shape references.

**Example** Type **SR ON** **Enter**  
Turns on the display of shape reference fields.Type **SR** **Enter**  
Toggles the display of shape reference fields off.**NOTE** The NET90 COMP LER program uses the shape reference fields to determine if shapes can be connected. The SR command can be used to make these references visible for the purposes of checking connectivity.

STATUS

**MODES:** DB

**COMMAND:** ST

**USAGE:** Lists the user drawing file units, current layer, grid and cursor increments, and other important information about the current drawing. Also displays the colors and line type in which each layer is shown. The following information is contained in the display listing:

**Working Drawing File Name**

The name under which the current drawing is saved on disk when an EXIT or SAVE command is given.

**Drawing Units**  
MILS, INCHES, CM, or MM

**Current Layer**  
The working layer

**X org, Y org**  
The lower left hand coordinate of the current screen view

**Delta x, Delta y.**  
The digitizing cursor increment as set by the user

**Grid x, Grid y**  
The current grid point increment as set by the user

**Scale Factor.**  
The display factor of the current screen view

**Color Map**  
Shows color and line type for each layer

Press any key to return to DB mode

**CAD COMMAND REFERENCE**

---

**STRAIGHT LINE****MODES:** DB**COMMAND:** S**USAGE:** Allows straight lines to be drawn at multiples of 45 degree angles

Example

1 Type **S** Enter

CAD prompts to mark the end points of the desired line segments. An Esc before the second point is marked exits the command. The escape terminates point markings and causes the line to be drawn in the current layer color. If an attempt is made to draw a line in other than a 45 degree increment, CAD automatically draws the line to the nearest 45 degree increment.

2 Type in the end points

Refer to **Line Command** for further details

## SYSTEM MACRO

**MODES:** DB

**COMMAND:** SM  
SM macro name

**USAGE:** Gets a System Macro from the shape library and places it at the cursor location CAD prompts for the macro name and asks if a starting block number is to be assigned to blocks in the macro

- Example
- 1 Type **SM** Enter  
CAD prompts for the macro name
  - 2 Type in any macro name  
CAD prompts for a starting block number (optional)
  - 3 If block numbers are not to be assigned, press Enter No block numbers are assigned, although fixed blocks get their fixed numbers, if available If the fixed block numbers are not available, the request is rejected However, if other fixed block numbers for the same function code are available, then the fixed block numbers are assigned
  - 4 If a starting block number is assigned, the blocks begin with that number
- Example
- 1 Recall a macro named Test When it was saved, the block numbers assigned were 184, 185, 186, 187, 190 and fixed blocks 15-19
  - 2 Type **SM Test** Enter
  - 3 CAD asks for a starting block number Press Enter, and no block numbers are assigned, although the fixed blocks are numbered 15 19
  - 4 After each block is validated, the macro appears (from its origin point) at the cursor position

**CAD COMMAND REFERENCE**

---

**SYSTEM MACRO** (continued)

Example Same as the first example, except start with block number 62

1 When CAD prompts for a starting block number,  
Type **62** Enter

2 The blocks are then numbered 62, 63, 64, 65, 68, and fixed  
blocks 15-19.

**NOTES.**

1 If the blocks are not available CAD asks for a new starting block  
number or press **Enter** and assign no block number. Fixed blocks  
however always keep the reassigned numbers for that function code

2 Recalling a macro summary to executing FN commands and  
each block is validated

## SYSTEM SHAPE

**MODES:** DB

**COMMAND:** SS  
SS shape name

**USAGE:** Gets a specified shape from the library list and places an instance of it in the drawing at the current cursor position. If an SS command without the shape name parameter is entered, CAD prompts for the name. The reference origin point of the shape is placed at the cursor position existing when SS is entered. If it is NOT a NETWORK 90 compulsory shape, an optional parameter to the SS command is the scale factor (e.g., SS 3). If none is entered, the scale factor is 1.

Example 1 Type **SS DBORD** Enter  
Shape DBORD is retrieved from the library list and placed on the drawing.

2 Type **SS** Enter  
CAD prompts for the shape name. The user types in the shape name and presses Enter. The shape specified is retrieved from the library list and placed on the drawing.

CAD COMMAND REFERENCE

---

**TEXT****MODES:** DB**COMMAND:** T**USAGE:** Sets CAD to the TEXT command in order to type text onto the drawing. This text is only ornamental and not associated with any symbols or lines.Example 1 Type **T** Enter

2 CAD prompts for

a A character size Determines the text display size that is used. A typical size is 20.

b Text angle Determines the angle in which the text is drawn.

If the number of degrees entered is not a multiple of 90°, the system truncates the input to the next lowest 90° increment.

c Justification point Point at which the text origin is placed. The text origin is at the lower left-hand corner of the text string.

3 Type in the text

---

**TEXT DISPLAY**

**MODES:** DB  
**COMMAND:** TE  
TE ON  
TE OFF

**DEFAULTS:** ON

**USAGE:** Controls the display of text in the drawing. When text is off, drawing (including refreshing) is faster. The command affects all text on all layers. A change in the setting of TEXT DISPLAY only shows up after a command which redraws the screen.

Text display can be toggled by typing TE.

Drawings containing a lot of text refresh much faster when TEXT DISPLAY is off.

**Example** Assume text display is on,

Type. **TE** Enter

Text display is off, but text is still shown in current view.

Type **RF** Enter

Screen is redrawn with text no longer visible.

**NOTES:**

1. CAD warns when the T command is entered when text display is off.
2. TE applies to text on all layers.

**CAD COMMAND REFERENCE**

---

**UNDELETE SHAPE****MODES:** LM**COMMAND:** UN

**USAGE:** Restores a deleted user library shape providing the library has not been compressed since the shape was marked for deletion. Type UN, and CAD prompts for the shape name to restore or unerase. Type in the shape name and it is restored to the user library. (Wild cards are acceptable.)

**Example** Undelete shape joy

1 Type **UN** Enter  
CAD prompts for the shape name

2 Type **JOY** Enter  
The shape is marked active

## USER LIBRARY

**MODES:** DB

**COMMAND:** UL  
UL (library name)

**USAGE:** Initializes and associates a user library name to a drawing file. Use this command to create your own library of frequently used Shapes and Macros. CAD asks for the User Library Name (maximum of 8 characters) to be entered.

Example 1. Type **UL Enter**  
CAD asks for a library name

2. Type **SMITH Enter**  
CAD creates a User Library named SMITH, if it does not already exist. If it does exist, the user library name SMITH.LBR is associated with the current drawing.

**NOTE:** A drawing file (.DBF) is associated with one user library. A user library however can be associated with multiple drawing files.

**CAD COMMAND REFERENCE**

---

**USER MACRO**

**MODES:** DB

**COMMAND:** UM  
UM (MACRO NAME)

**USAGE:** Gets a Macro from the User Library

- Example**
- 1 Type **UM** **Enter**  
CAD prompts for the Macro name and asks to assign a starting block number. The Macro appears on the CRT with its origin point at the cursor location. See the SM command for an example of how to work with the Block Number designations.
  - 2 Type in the Macro name, and the starting block number, if desired.

---

**USER SHAPE**

**MODES:** DB

**COMMAND:** US  
US (shape name)

**USAGE:** This command gets a shape from the User Library and places it on the drawing at the cursor location. Like the System Shape (SS) command, CAD prompts for shape name. A scale factor may be entered with the command, e.g., **US shapename 3**.


**VERTICAL ORTHOGONAL (Solid Line)**

**MODES:** DB

**COMMAND:** V

**USAGE:** Sets CAD to the VERTICAL ORTHOGONAL command for inputting solid lines. Angles are allowed only in 90° increments. Digitized points are connected by first completing the vertical segment of the line.

Example



**NOTE.** VERTICAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and vertical orthogonal lines.

Refer to **Line Command** for further details

---

**VERTICAL ORTHOGONAL (Dashed Line)**

**MODES:** DB

**COMMAND:** V1

**USAGE:** Sets CAD to the VERTICAL ORTHOGONAL command for inputting dashed lines. This is used for drawing dashed digital logic/configuration connection lines on an analog drawing. Angles are allowed only in 90° increments. Digitized points are connected by first completing the vertical segment of the line.

Example See the Example for Vertical Orthogonal (Solid Line)

**NOTE:** VERTICAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and vertical orthogonal lines.

Refer to **Line Command** for further details.

**CAD COMMAND REFERENCE**

---

**VERTICAL-ORTHOGONAL (Dotted Line)****MODES:** DB**COMMAND:** V2

**USAGE:** Sets CAD to the VERTICAL ORTHOGONAL command for inputting dotted lines. This is used for drawing dotted connection lines from adapt blocks on a configuration drawing. Angles are allowed only in 90° increments. Digitized points are connected by first completing the vertical segment of the line.

Example See the Example for Vertical Orthogonal (Solid Line)

**NOTE:** VERTICAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and vertical orthogonal lines.

Refer to **Line Command** for further details.

---

**VERTICAL-ORTHOGONAL (Dot Dashed Line)**

**MODES:** DB

**COMMAND:** V3

**USAGE:** Sets CAD to the VERTICAL ORTHOGONAL command for inputting dot dashed lines. This is used for drawing miscellaneous separation lines on a logic/configuration drawing. Angles are allowed only in 90° increments. Digitized points are connected by first completing the vertical segment of the line.

Example See the Example for Vertical Orthogonal(Solid Line)

**NOTE:** VERTICAL ORTHOGONAL can be used to draw straight lines. This saves time when inputting combinations of straight lines and vertical orthogonal lines.

Refer to **Line Command** for further details.

**CAD COMMAND REFERENCE**

---

**VISIBLE LAYER**

**MODES:** DB

**COMMAND:** VL  
VL n

**USAGE:** Displays which layers are currently visible, or chooses the layers to be made visible

**Example** To see which layers are visible, use either one of these forms at the prompt,

- 1 Type VL Enter or
- 2 Type VL ?

CAD lists the numbers of the current visible layers in numerical order. If there are more than 10 visible, they are listed 10 at a time, and the system prompts if you want to see more.

To choose layers to be visible, use any of the following forms

**Example** At the prompt, type VL and layer or layers

- 1 Type VL n Enter
- 2 Type VL n1 n2 .. n16 Enter
- 3 Type VL n1 Enter
- 4 Type VL n1 - n8 Enter
- 5 Type VL 1 - 8, 12, 16 Enter

ZOOM

**MODES:** DB MT

**COMMAND:** ZO  
 ZO n  
 ZO n

(n integer magnification factor)

**USAGE:** Magnifies or reduces the size of the current display view  
 The cursor location becomes the center of the screen

When entering the ZO command without a parameter, CAD prompts for a zoom factor. Positive zoom factors result in a zoom in (the display is enlarged). Negative zoom factors result in a zoom out (the display is reduced).

Successive ZOOM applications result in the previous ZOOM factor being multiplied (ZOOM in), or divided (ZOOM out), by the new factor. The resulting zoom factor cannot be less than 1X.

Example Type **ZO 8** Enter  
 Zoom in, magnification of 8X

Type **ZO -2** Enter  
 Zoom out, magnification now 4X

Type **ZO -4** Enter  
 Zoom out, magnification now 1X



## SECTION 4 — THE NETWORK 90 COMPILER

### INTRODUCTION

The Network 90 compiler allows compilation from one module to the entire job. The compiler may be initiated by one of several methods:

1 Choose *Compilation* (item D) from the main menu. This causes the SELECT program to run. SELECT enables you to conveniently select which files you want to compile. It then starts the compilation process. Instructions for selecting modules are displayed when the program is initiated.

2 You can initiate SELECT directly from the DOS prompt. Type **SELECT** [Enter]. The SELECT program creates the MSTR.LST and module.LST files used by the compiler program.

3 To initiate the Network 90 compiler directly from the DOS prompt, type **N90CPLR** and press Enter. The LST files created by SELECT must be present for the compiler to work.

To use the SELECT program:

- SELECT BY JOB** Press [Enter] to select/deselect all modules for the entire JOB.
- SELECT BY LOOP** Press [Enter] to select/deselect all modules that are in the same LOOP as the module under the cursor.
- SELECT BY PCU** Press [Enter] to select/deselect all modules that are in the same PCU as the module under the cursor.
- SELECT BY MODULE** Press [Enter] to select/deselect only the MODULE under the cursor.

Selected modules are shown in black text on a green background. Deselected modules are shown in green text on a black background. The selection cursor is shown by black text on a cyan background. The cursor text is highlighted if the module under the cursor is currently selected.

Use the [←], [f], [→], [↓], Home and End keys to move the cursor. Use [Pg Up] and [Pg Dn] to change pages, if there are multiple pages (this is shown in the lower right corner of the screen).

Below is a summary of the allowable keystrokes and their meanings. Press the **Alt** **H** key to view these in the program.

<b>Alt H</b>	Display key usage information (HELP)
<b>↓ ↑ ← →</b>	Move the cursor around the screen
<b>Enter</b>	Select/deselect modules based on selection method
<b>Ins</b>	Change to SELECTION mode
<b>Del</b>	Change to UNSELECTION mode
<b>F1</b>	Change to SELECT BY JOB method
<b>F2</b>	Change to SELECT BY LOOP method
<b>F3</b>	Change to SELECT BY PCU method
<b>F4</b>	Change to SELECT BY MODULE method
<b>Esc</b>	Abort selection and return to DOS
<b>F10</b>	Finished selecting modules

**Using the Module Selection Methods Efficiently**

Following are examples that give you an idea of what the selection process for Binder and Compiler can do. In all examples, assume that you have a large job, with more than one loop, multiple PCUs in each loop and more than one module in each PCU. Press **Esc** at any time to abort the selection process without selecting any modules. Press **F10** to accept any selections made and proceed to compile or bind those modules.

**NOTE:** The initial selection mode is always SELECT BY MODULE.

Example 1 To select every module

- 1 Press **F1** to change mode to SELECT BY JOB
- 2 Press **Enter** to select all modules

Example 2 To select every module in Loop 1

- 1 Press **F2** to change mode to SELECT BY LOOP
- 2 Position the cursor over any module in Loop 1
- 3 Press **Enter** to select all modules in Loop 1

Example 3 To select every module in PCU 10, Loop 1

- 1 Press **F3** to change mode to SELECT BY PCU
- 2 Position the cursor over any module in PCU 10, Loop 1
- 3 Press **Enter** to select all modules in PCU 10 Loop 1

Example 4 To select an individual module

- 1 Press **F4** to change mode to SELECT BY MODULE
- 2 Position the cursor over the desired module
- 3 Press **Enter** to select that module

Example 5 To select every module except those in PCU 10, Loop 1

- 1 Press **F1** to change mode to SELECT BY JOB
- 2 Press **Enter** to select all modules
- 3 Press **F3** to change mode to SELECT BY PCU
- 4 Press **Del** to change mode to UNSELECT BY PCU
- 5 Position the cursor over any module in PCU 10, Loop 1.
- 6 Press **Enter** to deselect all modules in PCU 10, Loop 1

Example 6 To select every module except one individual module

- 1 Press **F1** to change mode to SELECT BY JOB
- 2 Press **Enter** to select all modules
- 3 Press **F4** to change mode to SELECT BY MODULE
- 4 Press **Del** to change mode to UNSELECT BY MODULE
- 5 Position the cursor over the desired module
- 6 Press **Enter** to deselect that module

The drawings are then compiled to an lppmm cfg file for downloading to the Network 90 System (lppmm is standard Bailey format 1 loop identifier, usually 0, pp PCU number, mm module address)

The lppmm cfg file can be loaded into the Network 90 System using the TEXT Program in a BAILEY EWS, connected to the Network 90 System with a Computer Interface Unit (CIU) or a Serial Port Module (SPM)

An lppmm log file is also created containing error messages and other pertinent data. The messages can be viewed on screen by using the **TYPE** command and then printed by pressing **Print Scrn**

## Hints about creating a drawing

- 1 The Compiler does not accept a mismatched point, so use a grid of 20, 20 [F2] with Gridlock on when connecting lines. Use a 100, 100 grid [F1] to drop shapes onto a drawing.
- 2 Add connection points when branching from input or output lines.
- 3 When moving from one sheet to another, use the Change Attribute (CA) command, and note the limit of 30 characters in the description of the off sheet connecting shapes.
- 4 Do not try to compile a drawing containing function blocks that have been saved in a rotated position.

**Network 90 COMPILER ERROR MESSAGES**

The following are common error messages and descriptions. Make necessary corrections to the drawing files and recompile the drawings until an error free lppmm cfg file is created.

- 1 Shape [shape name] Multiple Definition  
Same name appears more than once in Shape Library
- 2 Sheet No [n] Shape [shape name]  
No block number assigned
- 3 Sheet No [n] Shape [shape name]  
Illegal I/O descriptor, the first character must be a phabetic
- 4 Sheet No [n] Block No [bn] Spec No [sn]  
Input undefined, other end of the line fed into the specified block/specification does not coincide with an output connection (shape reference) point
- 5 Sheet No [n] Block No [bn] Spec No [sn]  
Data conflict, block feeding the specified block/type is not of the correct data type
- 6 Sheet No [n] Block No [bn] Spec No [sn]  
Overlapping connection points, connection (shape reference) point must not coincide with any other connection point
- 7 Sheet No [n] Block No [bn] Spec No [sn]  
Multiple inputs, more than one block feeds into the specified block/spec
- 8 Sheet No [n] Block No [bn]  
Block number previously used

**9 Sheet No [n] at ([x] [y])**

Erroneous flow line connection, such as a line joining two input connection (shape reference) points ([x], [y]) gives the end point coordinates of one line entity

**10 Sheet No [n] at ([x], [y])**

Too many lines joining at this point, a junction point can have at most 4 lines emerging from it. This error can often be caused by doing an **Add Connection** on line segments overlapping each other

**11 EEPROM utilization exceeds limit**

**12 RAM utilization exceeds limit**

**13 Too many segment control blocks**

**14 Too many executive blocks**

**15 Too many extended executive blocks**

The preceding is not a complete and exact listing of all the errors put out by the Network 90 Compiler. Most of the error messages given out by the Network 90 Compiler are descriptive enough to indicate where the problem has occurred.



## SECTION 5 — CAD UTILITIES

### INTRODUCTION

Type **H Enter** from the main menu to enter CAD Utilities. The submenu shown in Figure 5 1 appears on the screen.




Figure 5 1 Network 90 CAD Utilities Submenu

### TRENDING AND TUNING

The Trending/Tuning function for the Engineering Workstation is designed to collect trending data from the Network 90 System and to tune Network 90 modules on line. On line means that the Process Control Unit (PCU) is active, i.e. the modules are executing a control strategy.

The capabilities of the Trending/Tuning function include:

- 1 Monitoring/Trending point values in real time, either connected directly to a Network 90 System, or remotely through a modem.
- 2 Tuning control parameters in Network 90 modules.
- 3 Changing the trending points and files.
- 4 A hard copy display of the trend screen may be generated at any time. Refer to the Hard Copy (HC) command.

**START-UP**

Before start up, confirm that the EWS is connected to the Network 90 System through a Computer Interface Unit (CIU) or a Serial Port Module (SPM) To start the program

- 1 From the Utilities Menu, type **A** **Enter**
- 2 In response to the prompt, enter the name of the file to trend Standard DOS filenames are used, except that CAD adds the extension TRN. The trending file is created on the hard disk when the first trending is initiated If the name of an existing file is entered, CAD retrieves that file, and displays it on the screen If a file name which does not exist is entered, CAD prompts for a trending display period
- 3 If a new file is being created, at the prompt enter the display period (2 998 minutes) to trend CAD displays the trending configuration format on the screen Point data can be entered in the point data display area after first moving the cursor to that area

**TRENDING**

The trending display consists of two display elements a trend graph display and a point data display It uses a polling scheme and provides a sample resolution in one second multiples The trend graph has a total of 120 samples, or a minimum period of two minutes, and a maximum of 5 trending points

When the trend graph is full, it scrolls a quarter window at a time The trend graph is redrawn with the oldest data dropped, one quarter window (30 samples) at a time The display period can be as high as 998 minutes, set in two minute increments The following is an example (assume the current time is 12 00 00)

*Table 5 1 Sample Trend Graph Data*

Display Period	Sample Resolution	Next Scroll Time	Sample From Next Scroll
2 minutes	1 second	12 00 30	30
10 minutes	5 seconds	12 02 30	30
30 minutes	15 seconds	12 07 30	30
60 minutes	30 seconds	12 15 00	30
120 minutes	60 seconds	12 30 00	30

The trends only start collecting when this function is selected It has no historical data beyond that displayed on the screen

**TUNING**

The tuning parameters display shows the tunable specification list of a function block. This display cannot change the module mode.

This display only has enough screen space to display eight parameter specifications at a time. When there are more tunable specifications, a message displays to indicate this.

The cursor keys are dedicated to the tuning parameters display and are used to access the allowable parameters of the block. A closer look at the Tuning Parameter Display is shown in Figure 5.2.




Figure 5.2 Tuning Parameter Display

**CAD UTILITIES**

**SCREEN LAYOUT**

The trending/tuning function screen layout is shown in Figure 5-3




Figure 5-3 Screen Layout Trending/Tuning Function

- 1 Current function in Trending/Tuning
- 2 File Name
- 3 Current Date and Time
- 4 Point Data Display
- 5 Trend Graph Display
- 6 Tuning Parameter Display
- 7 User Prompt and Error Message Display

**FUNCTION KEYS**

The following function keys must be used to execute the Trending/Tuning functions. The function keys are defined as follows

- F1 Help Menu
- F2 Modify Display Period
- F3 Not Used
- F4 Change Trending File
- F5 Tune Block
- F6 Change Trending Point
- F7 Start Trending
- F8 Return to Main Menu
- F9 Clear the Field at the Cursor Location
- F10 Initiate Command
- Esc Exit the Help Menu or Escape from Tuning Function

The following examples show how each Function key works

**F1** Help Menu

Presents the help menu Press **Esc** to exit the help menu

**F2** Modify Display Period

CAD prompts for the display period time

Example

```

TREND PERIOD (2 998 [MIN]) ( _ _ )
STEP 2_[MIN]
    
```

The display period can be specified from 2 to 998 minutes in 2 minute increments Press **F7** to start trending with the new display period

**F3** Not used

**F4** Change Trending File

Type in the file name (8 characters maximum) and press

**F10** The trending display appears on the screen Press **F7** to start trending

**F5** Tune Block

Type in the PCU address, Module address, and Block number to be tuned Press **F10** to display the tuning parameters of the specified block Specification data similar to that shown in Figure 5 4 appears on the screen




Figure 5 4 Specification Data

Move the cursor to the specification to be changed, and type in the new specification value. Press **F10** to send the new data to the target module. Press **Esc** to tune the next block, press **Esc** twice to return to the trending function.

#### F6 Change Trending Point

The trending point data display is shown in Figure 5.5. Move the cursor to the desired location, using the cursor keys. Then change the data as needed. The various elements of the trending point data display are explained as follows:




Figure 5.5 Trending Point Data Display

- PCU-MD-BLOCK** The address of a trending point in the Network 90 System. Hyphens should be used as delimiters between address numbers. Pressing **F10** writes the point data into the trending file on the disk.
- TEXT** Trending point descriptions (14 characters maximum)
- MAXIMUM** Maximum value of the signal range
- MINIMUM** Minimum value of the signal range
- UNIT** Unit description (9 characters maximum)


Analog points and digital points can be displayed on the screen. Digital points are displayed within one of the 20% range lines, i.e., between 80% and 100%, between 60% and 80%, etc. A logic zero is displayed at 20% of the range (20% of the 20%), a logic one is displayed at 80% of the range (80% of the 20%). The display is shown in Figure 5.6.

**[F7] Start Trending**  
Trending restarts when you press F7]

**[F8] Return to Main Menu**  
The system prompts for confirmation of a trending reset. Type a **Y** (yes) to confirm; type an **N** (no) to return to trending.

**F9 Clear the field at the Cursor Location**  
Clears the field at the cursor location.

**F10 Initiate Command**  
Initiates the current command using the data in the input field.



TP6006

Figure 5.6 Digital Point Display

**MODULE MAINTENANCE UTILITY**

Module Maintenance (MODMAINT) allows the user to manage utilization factors on a module basis. Beginning with CAD version 3.0, utilization factors displayed on the status line refer to module values. Earlier versions of CAD displayed sheet values. The Module Maintenance utility performs the following functions:

1. Display and/or calculate the utilization factors of a given module on a sheet by sheet basis. The output can be displayed to the screen or written to a file. If written to a file, the file name has the extension UTL. When MODMAINT calculates utilization values, it also calculates block counts.

Bailey strongly recommends that the CALCULATE OPTION BE RUN FOR ALL DRAWINGS CREATED PRIOR TO CAD 3.0. This ensures correct utilization factors on both the module and sheet basis.

2. Copy one or more drawing sheets of one module to another module. If the destination sheets exist, CAD asks if the file is to be overwritten.

3. Delete one or more drawing sheets of one module. The module utilization factors are correctly maintained.

**How To Use The Module Maintenance Utility**

First select option **B** *Module Maintenance*, from the CAD Utilities Menu, or from DOS, type MODMAINT. Enter. The program prompts throughout the various screens.

File names must be in standard format LPPMMSSR, where

- L        Loop identifier (normally 0)
- PP      PCU number (01-63)
- MM      Module address (02-31)
- SS      Sheet No. of this module (01-29)
- R        Revision letter of the sheet (upper or lower case)

The copy/delete function requires the start-end sheet revision numbers to be input (e.g., 12A-50A). Sheets are numbered 00-99, A0-A9, B0-Z9. For example, if copying source module sheets 10A-50A to destination module sheets 30A-70A, sheet 10A would be copied to sheet 30A, sheet 11A would be copied to sheet 31A, etc. Only the most recent revision of a drawing file is processed.

**NOTE:** If a process is terminated early as a result of a cut or error condition, changes may already have taken place to the current directory. Some of the drawing sheets may have already been copied.

**Error Codes:**

- 2 File specified is not found.
- 3 Path specified is not found
- 8 No more files found
- 89 Drive specifier contains an invalid character
- 90 Directory name contains a backslash This is an illegal character
- 92 File name (module name) not specified

**COMPRESS LIBRARY UTILITY**

This utility compresses user libraries, thereby improving access time and reducing disk space requirements To use it, select item **E** from the CAD Utilities Menu CAD prompts for the name of the library to be compressed

Type in the name of the library to compress, or press **Enter** to exit without compressing a library The user library to compress must be in the current directory Once a library is compressed, shapes marked for deletion **CANNOT** be recovered

**NOTE:** Do not use the extension OLD for any libraries as the utility automatically renames a library with the extension OLD if the library compression is successful the OLD file is deleted if not successful OLD is renamed LBR and the file remains intact A file cannot be lost if a file OLD is already in use an error message appears *errtyp 1 retrn 5* if this happens rename the OLD file and start again

**TRACE UTILITY**

TRACE is a CAD utility which analyzes a CFG file to produce a report There are two types of reports available

The first report type is a listing of all spare, fixed and configured blocks for a particular module as defined by the CFG file This report is a useful tool for locating available (spare) blocks when additional function code logic needs to be added to the module

The second report available through the TRACE utility is a listing of all configured blocks and the associated specification values for input to a DBASE III Plus™ database This report is stored in a format called SDF (Standard Delimited Format) which can be read into a properly structured DBASE DBF file Included with the TRACE utility is a CFGSPECS DBF file which accepts the TRACE SDF format specification listing This facility allows the CFG data to be

easily ordered, searched, etc. as required to analyze a module configuration

**Operation**

1 TRACE can be started from the CAD Utilities Menu or from the DOS prompt.

If starting from the CAD Utilities Menu,

Type **H**

TRACE prompts for the name of a CFG file

Enter *CFG filename* [filename] **Enter**

If starting from the DOS prompt,

Type **TRACE Enter**

or

Type **TRACE [filename] Enter**

If TRACE was started from the CAD Utilities Menu, TRACE prompts for the name of a CFG file

Type [filename] **Enter**

2 TRACE displays the available report types and prompts the user to choose one

*Available report types*

- 1 *Spare and configured blocks report*
- 2 *SDF Specification Listing*

*Select Report type*

Type **1 or 2 Enter**

TRACE analyzes the specified CFG file and generates the requested report. If the Spare & Configured Block Listing was requested, the report is stored in the file

filename.blk                      where filename is the CFG file name  
 (e.g., 12345.cfg generates 12345.blk)

Any print function can be used to generate a hard copy of this report. If the SDF format specification listing was requested, the listing is stored in the file

filename.sdf            where filename is the CFG file name  
(e.g., 12345 blk generates 12345.sdf)

To use the data stored in this file, it must be read into a DBASE III Plus DBF file. The CFGSPECS DBF file stored in the EWS directory is structured to accept the TRACE SDF listing.

To generate a DBASE III Plus database from the TRACE listing

- 1 Type **CD**[directory with DBASE III Plus] **Enter**
- 2 Type **COPY\EWS\CFGSPECS.DBF** [filename F2BDBF]  
**Enter** (where filename is the CFG file name)
- 3 Type **DBASE** **Enter**
- 4 Type. **USE** [filename] **Enter**
- 5 Type **SET PATH TO** [directory of filename.sdf] **Enter**
- 6 Type **APPEND FROM** [filename.SDF] **SDF** **Enter**

The DBF file now contains all of the configured blocks and their associated specification values. Use DBASE III Plus functions to order, sort, analyze, etc., the data as needed.

For those users who need to load the specification data into an application program other than DBASE III Plus, the structure of the TRACE SDF format file is as follows:

Each line of the SDF file is 1228 characters long and contains the complete specification data for one function code.

Character Positions	Function
1        4	Start Block
5        8	End Block (if more than 1 block used)
9        11	Function Code Number
10       28	S1 Value
29       47	S2 Value
1210    1228	S64 Value

**NOTE:** A specification values (S1, S2, etc.) are stored as real numbers in a 19.3 format. Each value occupies 19 character positions with the last 4 positions being a decimal point and three decimal places.

---

**PRINT/PLOT UTILITIES**

**E** through **H** on the CAD Utilities menu give print/plot options

---

**Print from .DBF Genicom Printers**

Select **E** from the CAD Utilities menu to print on the Genicom 3400 or 3410 or **F** to print on the Genicom 4440. The program prompts for DBF file names to print. Enter file names individually in response to program prompts, or list them in a batch file. To enter a batch file, type @[file name]. Enter, do not enter the BAT extension. After you enter the last file, type **STOP** [Enter]. The program then prompts for a scale factor. Enter 100 to get a full size drawing. To get a B size (11 inches x 17 inches) drawing, the scale factor should be 84 for the 34XX series printers and 83 for the 4440 printer.

---

**Print from .DBF LaserJet II Printer**

To use the LaserJet II printer, the Print A-Plot™ program, written by the Insight Development Corporation (1024 Country Club Drive, Suite 140, Moraga, CA 94556, phone 415/375 9451), must be purchased. Copy the PP EXE program from their master disk to the \EWS directory.

**NOTE:** The LaserJet must have a 1 Megabyte or larger expansion board installed.

Select item **G** from the CAD Utilities Menu. The program presents a menu for choosing a settings file. A settings file specifies size and resolution of the plots to be made. Menu items A through D are CAD provided settings files. Menu item E allows selection of user created settings file. The Print A Plot documentation describes creation of settings files. See Figure 5 7.

Next, the program allows you to select which files to print. Enter the path of the directory that has the files to print (the default is the current directory). Choose **D** or **R**. **D** displays all files in the chosen directory that match the pattern. **R** moves the files from the list. Press **F10** to display the list. Use [←, →, ↑, ↓] to move to the desired file name, then press [Enter] to select the files to plot. Press **F10** again after making all the selections. See Figure 5 8. Call up this program from the directory that has the files you want to print. Press **F10** and choose the file to print.

Prompts asking whether specification values and descriptions appear on the drawings, replace the menu. After that, the plotting process begins. The program alternates between creating plot files and sending them to the printer, so plotting does not begin immediately. At any time before you answer the last question, press [←] to move back to the previous menu or question if you want to make different choices.




Figure 5 7 Settings File




Figure 5 8 Display Files Select Menu

**C-Itoh Printer**

The SCAD package supports the C Itoh printer (models 600Q, 3500, 310 and 315) This is not a menu item, you must invoke the printer program from the DOS command line Enter CIEPRN or SCIEPRN to invoke a driver for the C Itoh printer CIEPRN allows keyboard entry of print file names, while SCIEPRN expects those names to appear in a file called PRNLIST.BAT

**Plot from .DBF**

This utility allows plotting directly from a DBF file to a Bausch & Lomb DMP41/42 or Houston Instruments DMP51/52 sheet plotter No other plotters are supported by CAD, nor may CAD be reconfigured to support other plotters If other plotters are 100 percent compatible with those mentioned, they may work

After selecting item H from the CAD Utilities menu, CAD prompts for the name of the drawing file to plot To terminate a plot in progress, press (Ctrl) |C When the plot is completed, a prompt appears for the next drawing file name Press Ctrl |C to end

For both printing or plotting from a DBF file, the largest rectangle on the drawing (usually a border) is used to define the plot window This window is subsequently scaled and rotated (if necessary) to produce a D size plot

**How To Create A Batch File**

A batch file can be built by either of two methods

1 Create a file named **prnlist.BAT** Prnlist can be any name up to 8 characters The BAT file contains a list of DBF file names The names are listed one per line For example, the list might look like this

```
3830032B
3830001B
\job01\3830032C
\job02\sub\3830003B
3830012B
```

2 Use the utility MKBAT to build a new list of file names Type **MKBAT name1.DBF name2.DBF > prnlist.BAT** |Enter , where prnlist is a 1 8 character file name, and name can include path names, ?, or \* For example,

```
MKBAT \JOB1\*.DBF \JOB2\101*.DBF > FILE.BAT Enter
```

builds a file called FILE.BAT FILE.BAT contains a list of all the DBF file names in directory JOB1 and all the DBF file

names in directory JOB2 whose first three characters are 101 To append file names to an existing list, replace the > character with >> characters For example,

**MKBAT \JOB3\?????01a.dbf > > FILE.BAT** Enter

appends to FILE BAT the names of all the DBF files in directory JOB3, whose 6th 8th characters are 01a

The Printer/Plotter software can print specs and/or descriptions for each drawing Specify this in the PRNLIST BAT file To print specs only, insert a /S after each file name that you wish to print specs for To print specs and descriptions, insert a /SD after each file name that you want to print specs or specs and descriptions for To print specs or specs and descriptions for all files in a batch, invoke MKBAT as follows

**MKBAT -S C** [files to be printed] ) [batch file name (specs only)]

**MKBAT -S -D C**·[files to be printed] ) [batch file name (specs and descriptions)]

**Plot from DMP-60**

If you have a Houston Instruments DMP 60™ plotter, you must configure it per Steps 1 through 6 for it to work with CADEWS

1. Press the control panel ENTER and SCALE UP keys (see Figure 5 9) This activates the DM/PL menu mode The plotter plots the DM/PL option select line
2. When the plotter parks the pen by the help option, press ENTER to plot the help listing
3. Use the right and left arrow keys to move the pen to the list option select line Press ENTER to list menu options
4. Set the options as shown in Table 5 2.

**NOTE:** After you make a selection, press ENTER to save your selection, then use the right and left arrow keys to move the next option.

5. After you complete the settings of Table 5 2, press the SCALE UR or CLIP UR key to exit DM/PL menu mode The plotter is now in the active plotting language
6. Save the plotted menu (open the left and right pinch roller arms, remove menu).




Figure 5 9 DMP 60 Control Panel

Table 5 2 DMP 60 Plotter Options

Option	Setting
1) UP VELOC TY 2) UP ACCELERAT ON 3) UP DELAY 4) DOWN VELOC TY 5) DOWN ACCF FFAT ON	16 ( ps) 4 0 (g) 25 (msec) 16 ( ps) 4 0 (g)
6) DOWN DELAY 7) PEN CHANGE 8) PLOT OR G N 9) CONSTANT VELOC TY 10) ADDRESS NG	40 (msec) GNORE R GHT ON 001 n
11) MENU UN TS 12) TEXT FONT 13) CHARACTER SET 14) AUTO PEN CAPP NG 15) BAUD RATE	ENGL SH F0 G1 120 (sec) 9600 (baud)
16) UART PAR TY 17) HANDSHAKE RTS/DTR 18) PASS THROUGH PORT 19) OUTL NED FONTS 20) NUMBER OF PENS	B T 8 0 TOGGLE TOGGLE F LLED 1
21) ZERO CHARACT R 22) COMM ERRORS 23) OPT ON BOARD 24) TEXT SPAC NG	PLA N GNORED ON NON PROPOR TIONAL

83 18 48 04 10 07

---

## SECTION 6 — PC TO PC COMMUNICATIONS

---

### INTRODUCTION

This program allows the transfer of files between two PCs, either via direct cable hookup or through two Hayes compatible modems

---

### MODEM SETUP

If using modems to transfer the files, it is important that the modems have their switch settings properly set to allow transfer. On the Hayes external modem, the 8 switches should be set as follows (See the manual for definitions)

#### Switches

1	2	3	4	5	6	7	8
Up	Up	Down	Up	Up	Down	Up	Down

The important switches to note here are switch 1 and switch 6. Switch 1 causes the computer to recognize the DTR signal and Switch 6 causes the Carrier Detect signal to be held high at all times. These switches **MUST** be set as shown. If DTR is not recognized (Switch 1), the modem does not properly disconnect the call. If the Carrier Detect signal is not held high at all times (Switch 6) on the receiver modem, no transfer is enabled. For Hayes board modems, set the switch to assure Carrier Detect is held high.

---

### HOW TO RUN THE PROGRAM

To run the program, type the following command

```
C > PCPC Enter
```

**THE SCREEN**

When PCPC starts, the screen is cleared and then it displays five formatted windows as shown in Figure 6 1

**The First Window (number 1 on Figure 6 1)**

This window is used to display the name of the program and the copyright information

**The Default Setting Window (number 2)**

This window displays the current defaults

**The Menu Window (number 3)**

This window displays the various program options At start up, the *Send File* option is highlighted




Figure 6 1 PC to PC Communications Screen

**The File Prompt Window (number 4)**

This window is used to prompt the user for the name of the file to send or receive At start up, it is blank

**The Status Window (number 5)**

This window is used to display the various program status messages At start up, this window is blank

**OPERATION**

To transmit a file, the PCPC EXE program must be on both PCs. Then, start the program on both PCs. Once started, the program defaults can be changed, if necessary, to enable the two programs to communicate.

**CHANGING DEFAULTS**

To change the defaults, use the **↑** **↓** **←** **→** arrow keys on the right side of the keyboard. Press the **→** key and notice that the highlighted area, in the menu window, moves to the right. Press this key until the *Change Defaults* option is highlighted. Then press **Enter**. The menu window clears and the cursor is positioned under the port number, in the default window.

To change the port number, press the **↑** or **↓** key and the port number changes to either 1 or 2. Once the port number is correct, press **Enter**. The cursor is then positioned under the baud rate default.

To change the baud rate, press the **↑** or **↓** key and the baud rate changes to either 300, 1200, or 9600. Once the baud rate is correct, press **Enter**. The cursor is now positioned under the modem present default.

To change the present modem default, press the **↑** or **↓** keys. The default is changed to either **Y** or **N**. The **Y** indicates there is a modem connected to the port, the **N** means no modem is connected. Once, the proper default is selected, press **Enter**. The cursor is now positioned under the Phone number slot.

At this point, type in a phone number or just press **Enter**. If the you press **Enter**, then the current phone number (if any) is left undisturbed.

**NOTE:** If the present modem default is **N** then a phone number need not be typed in. If the modem default is **Y** and the program is to be set up for receiving then the phone number need not be typed in. When you have finished with the phone number then the menu window is displayed and the *Send File* option is highlighted.

**PC TO PC COMMUNICATIONS**

---

**TRANSMITTING A FILE****Preparing the Receive Side**

Once the defaults are set up, the user on the receive side must use the **→** key to highlight the *Receive File* option. Once highlighted, you must press **Enter**. Then the following prompt appears in the file prompt window

*Receive file*

At this point enter a file name or just press **@ \Enter**. If the latter is chosen, then the program gets the name from the sender. After the file name is entered, or **Enter** is pressed, the program enters a state that establishes contact with the sender. If, after 15 minutes, contact has not been made, the program times out with an error. Once contact is made, it reports the status of the transmit in the status window

**Preparing the Sender**

Once the defaults are set up, the user must move to the *Send File* option and press **Enter**. The following prompt appears in the file prompt window

*Send file*

Type in the name of the file to be sent. Once the file name has been typed in, the program establishes contact with the receiver. It times out in 15 minutes if no contact is made. Once contact is made, it displays transmit status messages in the status window

**After the Transmit**

After the transmit is finished, the menu is redisplayed (menu window 3). At this point, transmit another file, or move to the Exit Program option and exit out by pressing **Enter**

**SAMPLE DEFAULTS FOR TYPICAL USERS**

---

**PC to PC Direct Connect**

<b>Receiver:</b>		<b>Sender:</b>	
Port	1	Port	1
Baud rate	9600	Baud rate	9600
Modem	N	Modem	N
Phone #		Phone #	

---

**PC to PC Through a Modem**

<b>Receiver:</b>		<b>Sender:</b>	
Port	1	Port	1
Baud rate	1200	Baud rate	1200
Modem	Y	Modem	Y
Phone		Phone	886 2048



## SECTION 7 — TEXT ENGINEERING WORKSTATION

### INTRODUCTION

Network 90 Text Engineering Workstation (TEXT) allows you to interface with Network 90 systems while on line (PCU is active, connected to an EWS), or during system configuration. Use the TEXT package to

- modify module modes
- configure Network 90 blocks
- list/save/load module configurations
- monitor and tune system blocks
- verify configurations (both in the module and on the EWS)
- define monitor groups

You must connect the EWS to the Network 90 System through either a Computer Interface Unit (CIU) or a Serial Port Module (SPM) to do these functions. Refer to product instruction I E93 916 for set up information.

Menu screens identify all possible actions to take while input screens identify information needed from the user to proceed. TEXT adheres to the User Interface standards for key strokes and operation.

### START-UP

**NOTE** For installing the TEXT program without SCAD, refer to Section 2 of this manual, complete Steps 1 through 7.

You can invoke the Text Engineering Workstation program either from the CAD Main Menu or directly from the DOS prompt. If you use the CAD Main Menu, do the following:

From the DOS prompt of your EWS, type

```
CMM  or
CAD 
```

Select **G** (TEXT) from CAD Main Menu (Figure 7-1).

If you are calling the program directly, do the following:

From the DOS prompt of your EWS, type

```
TXTEWS  or
TEXT 
```

Either of these methods leads directly to the TEXT CONFIGURATION Main Menu (see Figure 7 2) TEXT prompts you throughout the various screens




Figure 7 1 CAD Main Menu

### SELECTING THE COMMUNICATIONS PORT

TEXT uses communications port 1 on your Engineering Workstation by default to communicate with the CIU or SPM. If it becomes necessary to use communications port 2, you must invoke the TEXT software via the DOS command line as follows:

**TXTEWS 2 Enter**

The number 2 following the TXTEWS name informs TXTEWS to use communications port 2.


### RESTARTING THE CIU/SPM

The first time you begin module communications, TEXT prompts you for the BAUD rate input:

**BAUD RATE 9600**

The default is 9600, but you can request 300, 1200 or 2400. Key in the desired baud rate or press F10 to accept the rate shown. TEXT prompts:

*Do you wish to restart SPM/CIU (Y/N) >*



If you want to restart the Serial Port Module (SPM) or Computer Interface Unit (CIU), answer Y(es). This prompt appears once during the TEXT session. Following your decision to restart or not, TEXT continues as outlined later in this section.

**USING A MODEM**

When using a modem, TXTEWS asserts these RS-232 communication signals: RTS (Request to Send) and DTR (Data Terminal Ready). Versions of TXTEWS prior to Version 4.0 do not check the presence of DSR (Data Set Ready) and CTS (Clear to Send). Version 4.0 and later require them. These signals are normally asserted on the modem side and should not be a factor. However, in setups where the modem is not asserting these signals, communications will fail (time out). To correct this, assert these signals from the modem side (usually by setting a dipswitch) or patch the connection by asserting CTS and DSR from an active signal (in this case, either RTS or DTR).

**SCREEN EDITING**

TXTEWS follows the Bailey Controls User Interface Standards for operation. The F10 key is the general purpose acceptance key and the Esc key ends a process or backs the user up to the preceding menu or input screen. Error message or audible tones note bad inputs or keystrokes. The following is a list of inputs and values that TXTEWS requires:

Input	Valid Response
Ring Address	0 250
PCU Address	0 250
Module Address	1 31 ( 1 is valid in some cases)
Block Address	0 9998
Function Code	1 255
Baud Rate	300, 1200, 2400, 9600
Scan Interval	001 86400

TEXT CONFIGURATION MAIN MENU

Entering a value of zero into ring number indicates either plant loop operation or communication strictly to the ring on which the EWS resides

File name fields expect only the base part of the name and never expect a path to be input. The system assumes the file name extension during operation. For example, the system assumes configuration files to have CFG extensions, programs NBS extensions and monitor group files MON extensions. Therefore, the user need only enter the base part of the filename





Figure 7-2 TXTEWS Main Menu

## MODIFY MODE

*Figure 7 3 Modify Mode Menu*

**Inspect**

The Inspect function lists all modules contained within a specified PCU. This function lists each module address, module type, and module mode. To inspect a certain range within the PCU, input the proper data into the following screen.

```
Modify Mode  
  
inspect  
  
Ring Address  0  
PCU Address   0  
Starting Module 0  
Ending Module 0
```

Figure 7 4 Inspect Input Screen

The start address must be a module address lower than the ending address, unless you are inspecting only one module. In this event, leave the end module address zero and enter only the start module. If an entire PCU inspection is needed, enter a 1 into the starting address field. Following this, TXTEWS presents the list shown in Figure 7 5. A > seen for the module type signifies an available address. A to the right of each address shows the current inspect location. The indicator moves to the next address once it has polled that address.




Figure 7 5 Inspect Sample Screen

### Setting Module Modes

This function operates similarly to the Inspect function. It allows the alteration of module mode instead of just retrieving its current state. The available modes are CONFIGURE, EXECUTE, INITIALIZE and RESET. You can place either one or several sequential modules in a particular mode in one operation. See Figure 7.6 for the screen to set Configure mode. (This screen is identical for other mode functions.)

The screenshot shows a terminal window titled 'Modify Mode'. Inside, the word 'Configure' is centered. Below it, four parameters are listed with their values: 'Ring Address' is 1, 'PCU Address' is 2, 'Starting Module' is 10, and 'Ending Module' is 20. The 'Ending Module' value is highlighted with a cursor.

```

Modify Mode

Configure

Ring Address      1
PCU Address      2
Starting Module   10
Ending Module    20
  
```

Figure 7.6 Configure Input Screen

This function issues the requested mode command to the module and follows with an inspection of the module's mode. A ? seen at an occupied module address may mean that the module has not yet completed the mode change. Mode updates on the next iteration of the module range. As before, it may also represent a vacant module address.

Module Problem Reports

The report function called from MODIFY MODE provides the user with the ability to detect the presence of module or configuration problems. Select an address. This function presents a depiction of that module's status bytes. Modules with type codes of 31 and less display 5 bytes of status. Extended module types display 16 bytes. In addition to the status bytes, this function identifies the module name, type, mode and status. See Figure 7-7.




Figure 7-7 Status Byte Display Page

The EWS can generate three reports for the selected module. Press F1 to invoke the first report Status Information Report. This report describes the set bit flags in the status bytes and any byte conditions. The descriptions include the byte number, bit number, current value and the interpretation of the condition. Use [Pg Up], [Pg Dn], [↑] and [↓] to scan this report and those that follow. See Figure 7.8.




Figure 7.8 Status Info Report

Press **F2** to invoke the Status Errors Report. This report occurs only if the error summary bit in the status byte is set to binary one. If the error summary bit is zero, this option does not appear on the status byte display page. It is different from the status information report in that it identifies only error conditions. (It does not give information such as byte numbers, byte values, etc.) This report is for users looking to determine any non default or error conditions within the module. See Figure 7.9.




Figure 7.9 Status Error Report

Press **F3]** from the Status Byte Display page to invoke the Module Problem Report. This report gathers all module problem reports and displays them. The system numbers and present Module Problem Reports in the order they originated from the module. It also presents the total number of reports. If there is a large number of reports, all may not be presented. If this condition occurs, clear the initially reported problems to view the rest of them. See Figure 7-10.




Figure 7-10 Module Problem Report

All reports can be output to a printer. The printing option appears when you press **Esc** to return to the Status Byte Display page. Type **Y** and then press **F10** to print the report.

CONFIGURE BLOCK




Figure 7 11. Configure Block Menu

**Modify File Header**

This function allows the user to edit a configuration file header. This may be either a CFG file (function code blocks) or a NBS file (program blocks). You must enter the base name of an existing configuration file. If both a CFG and NBS file exist with the entered file name, the system inquires if the file to edit is the CFG file, the NBS file or both. Choose the type of file you want to edit. If you specify the **both** option, the CFG file comes up first, the NBS file second. See Figure 7.12.

Module type and module revision validity are verified. The revision must be valid for the specified module type. The system verifies any other fields (identified in the section on **Screen Editing**) that require range checks. The system accepts all other information without checks.




Figure 7.12 Configuration Header Screen

**Add, Modify, Delete Blocks**

The next three CONFIGURE BLOCK options are Add Block, Modify Block and Delete Block, respectively. These functions do the required module operations necessary to change a module configuration. The module must be in configure mode to do one of these functions. If the selected module is not in the configure mode, the system gives you the opportunity to change modes.

To add a block to a module, input the ring, PCU, module, block number and function code number on the screen shown in Figure 7-13.




Figure 7-13 Add Block Input Screen

The specified function code appears with the default values contained within their specs. You can edit any specification values as needed. If function code information does not fit on one page, the message *Use PgUp, PgDn* appears in the lower left corner. Press the **Pg Up** or **Pg Dn** keys to view the rest of the specs. Press **F10** to write the block to the module when you are done editing.

Use the same steps to modify blocks. The selected block must be present in the module. In this case, it is unnecessary to input a function code, as reading the block number returns that information. When editing is done, press **F10** to write the modifications back to the module.

The ring, PCU, module and block range are needed to delete blocks from the module. To remove a single block, input that block's number in the starting block number field and leave the ending block number field zero. See Figure 7-14.

As the system deletes blocks, a message indicating deletion appears in the lower right hand corner.

The screenshot shows a terminal window titled "Configure Block". Inside the window, the text "Delete Block in Module" is displayed. Below this, several fields are listed with their values: "Ring Address" is 0, "PCU Address" is 0, "Module Address" is 2, "Start Block Number" is 100, and "End Block Number" is 110. The "End Block Number" field has a small cursor or highlight at the end of the number.

```
Configure Block
Delete Block in Module

Ring Address      0
PCU Address       0
Module Address    2
Start Block Number 100
End Block Number  110
```

Figure 7-14 Delete Block Screen

**Copying Blocks**

The next feature of the CONFIGURE BLOCK menu is the Copy Block function. This allows the copy of a block from a module to either another block address or a range of block addresses. The source address is the first required parameter. See Figure 7 15

The screenshot shows a window titled "Block Copy" with a sub-header "Copy Block from". Below this, there are four input fields, each with a label and a value:

Label	Value
Ring Address	2
PCU Address	0
Module Address	0
Block Address	0

Figure 7 15 Copy Blocks Source Input

Enter the source address (Copy Block From) parameters and press **F10**. Next, enter the destination. The destination may be a single block address or a block address range. If the copy is done to a single block address, the system requires only the ring, PCU, module and block addresses. If the source block is to be copied to a range of block addresses, the system requires the ending block address and offset. The offset field specifies the number of block addresses to skip before making the next copy. For example, to copy the block at address 100 to addresses 120 through 140, the offset specifies how many addresses to skip before writing the next copy of block 100. An offset of one is used when the blocks are to occupy consecutive addresses. However, function codes with multiple outputs cannot occupy consecutive addresses. If a function code has two block outputs, then the offset must be two or greater. An offset of one generates an error when the system attempts to write the block to the module. As the blocks are added, a system message informs the user of the progress of the operation. See Figure 7-16.

Copy Block from		Copying to	
Ring Address	0	Ring Address	0
PCU Address	0	PCU Address	0
Module Address	4	Module Address	4
Block Address	100	Start Block	200
		End Block	210
		Offset	1

Figure 7-16 Copy Blocks Destination Input

## LIST/SAVE/LOAD CONFIGURATION




Figure 7 17 List/Save/Load Configuration Menu

## TEXT ENGINEERING WORKSTATION

*Listing a Module Configuration*

You can list module configurations to either the screen or a printer. Select option A from the List/Save/Load Configuration menu to list a module to a printer. Option B displays the configuration on the screen. Once you choose a destination, the next step is to choose the type of listing required. Figure 7-18 lists the types.




Figure 7-18 Listing Types

There are three ways to list a module. Option A lists all blocks with a function code matching the one you selected. As with all options, these listings may span either a single module or cover a range of modules. To list from a single module only, either leave the ending module set to zero or enter the same module number set for starting module. The parameters required for that listing type are shown in Figure 7 19

List/Save/Load Configuration

List from Module to Screen

Ring Address	0
PCI Address	0
Starting Module	0
Ending Module	0
Function Code	0

Figure 7 19 List by Function Code

Option B lists a specified block range only. The EWS determines the range based on the starting and ending blocks you set. If the ending block number is set to zero, the range will go from the starting block number to the module's end. This is the only condition in which the ending block number can be less than the starting block number. See Figure 7-20.

The image shows a screenshot of a software interface titled "List/Save/Load Configuration". It features a central text area with a list of parameters and their values. The parameters are: Ring Address (0), PCI Address (0), Starting Module (4), Ending Module (4), Beginning Block (0), and Ending Block (100). The value "100" is highlighted with a black background. The text area is enclosed in a rectangular frame with a double-line border.

List/Save/Load Configuration	
List from Module to Screen	
Ring Address	0
PCI Address	0
Starting Module	4
Ending Module	4
Beginning Block	0
Ending Block	100

Figure 7-20 List by Block Range

The last option is the listing of the entire module. For this option, enter only the ring, PCU and module. This option lists all of the module's blocks. See Figure 7-21.

```

LIST/SAVE/LOAD CONF. LISTING

RING 0 PCU 0 MOD 4 BLK 240 FC 53 EXECUTIVE CONTROLLER MODULE

S1          0 0 SPARE
S2          4 11 MIN XRP TIME (250 NS INCR)
S3          240 11 MAX XRP TIME (250 NS INCR)
S4          2 02 S16 CHG PARAM LDDP REPORTS (% SPAN)
S5          1 02 ALARM DEADBAND H/LDD REPORTS (% SPAN)
S6          1 02 ALARM DEADBAND DEV REPORTS (% SPAN)
S7          25 11 WATCHDOG TMR/INTL TO COMP CPU (2.56S INC)
S8          4 11 RED BUS UPDATE TIME (300MS PCU-250 NS INC)
S9          25 11 I H/W CYCLE TIME ALGORITHMS (10 NS INCR)
S10         0 11 CFG LOCK/1 LOCK 0-UNLOCK
S11         10 02 T P/W DERIVATIVE GAIN FOR PID
S12         0 11 EXT RSET/PID FNCT BLK 0=WR 1 EXT RSET

Press F10 to Continue

Press ESC to Abort

```

Figure 7-21. Example Block Listing

### Listing Configuration Files

Listing configuration files follow the same pattern as module listings. The only difference is that a configuration filename replaces the ring, PCU and module addresses. As with all filenames, only the base part of the filename is entered. The CFG extension is assumed. You can direct configuration file listings to either the screen or a printer and any of the previous listing options may be selected with these files.

### Saving (Uploading) Module Configurations

Uploading is the process of saving a module configuration to a disk file. Option E of the List/Save/Load/Configuration menu allows a user to upload configurations to a disk file. This process creates a configuration file with either a CFG or NBS extension, depending on the saved blocks. Function code blocks are saved in a CFG file. Program blocks, consisting of either BASIC, C, BATCH language or file system blocks, are stored in a NBS file.

After selecting the upload option, enter the ring, PCU and module address to save, and the filename that will contain the configuration. See Figure 7-22 for an example.

```

List/Save/Load Configuration

Save Module

Filename      MNMLE2
Ring Address  0
PCU Address   0
Module Address 5
  
```

Figure 7-22 Save Module Screen

Upon acceptance of the address and filename, the system checks to see if the module falls within the group of modules requiring additional information (refer to **Enhanced Module Processing**). Next, the system searches to see if the selected configuration file exists. If so, it acknowledges this and asks if you want to continue. If you want to continue or if the configuration file does not exist, edit the configuration header (refer to **Modifying File Headers**). If you decide not to continue (do not want to overwrite the current CFG/NBS file), press N then F10 to abort.

Upload begins when the file header has been edited (optional when a configuration file exists) and you press **F10**. The header remains on the screen and an indicator line is displayed. This line shows which block is currently being uploaded (see Figure 7-23). Once the process is complete, the message *Complete* appears. The program returns to the upload input screen.

List/Save/Load Configuration

MODULE2 CFG File Header			
Username	BAILEY CONTROLS		
Plant Site	WICKLIFFE OHIO		
Contract #	1234567890		
Configuration Description	MODULE 2 CONFIGURATION		
Ring Address	0		
PCU Address	0	Module Address	2
Module Type	MPC83	Module ID	AB
Software Revision	A		
New File		Saving Function Codes Block # 74	

Press ESC to Abort

Figure 7-23 Uploading Function Codes

If saving both function codes and program space, the system repeats the preceding steps for program space after saving the function codes. You have the option to edit the header. Upload begins when you accept the header. The program returns to the upload input screen when done.

Press **Esc** if it becomes necessary to abort an upload. The upload stops and an abort acknowledgment appears. Press **Y** to complete the abort. Press **N** if you do not want to abort and continue the uploading.

If an error occurs during the upload, an error message appears on the screen. Following this, a *Retry?* query appears. If you answer **Y**, TXTEWS attempts to once again save the block which generated the error. If you do not wish to retry, answer **N**. Another query then appears asking whether an abort of the save is requested. If you answer **Y**, TXTEWS aborts the upload. Answer **N** and TXTEWS ignores the block which produced the error and continues with the upload.

### Loading Module Configurations

Downloading is the process of transmitting configuration disk files to the module. Option F of the List/Save/Load/Configuration allows you to download either function codes, BASIC program, C language, BATCH or file system blocks. C, BATCH and file system blocks are done in a single download. They cannot be done separately. .CFG files store function code blocks. NBS files store program space.

To download, enter the module address and file containing the configuration. See Figure 7-24.

The screenshot shows a terminal window titled "List/Save/Load Configuration". Inside, there is a sub-section titled "Download Module". Below this title, there are four fields:

Filename	TEST
Ring Address	0
PCI Address	0
Module Address	1

Figure 7-24 Download Module Screen

The download process depends on the following:

- 1 If the module needs further identification (refer to **Enhanced Module Processing**), choose the exact module type from a menu selection. If it does not need further identification, proceed to Step 2.
- 2 If the module has programming capabilities (refer to **Enhanced Module Processing**), choose the download type from the menu selection in Figure 7-25. If not, proceed to Step 3.




Figure 7 25 Programmable Module Options

3 If function codes are to be downloaded, the system asks you to acknowledge module initialization with the prompt *Erase Old Configuration*.

If **YES**, proceed to Step 5  
 If **NO**, proceed to Step 4

If function codes are not to be downloaded, proceed to Step 7

4 The system asks you to acknowledge an **on line** configuration process (refer to Appendix A in your MFC product instruction).

If **YES** (on line configuration intended), proceed to Step 7  
 If **NO**, abort the download, return to download input screen

5 If the module supports BASIC programming, BASIC blocks are saved in file BASIC @#\$ If the module does not support BASIC, proceed to Step 6

**NOTE:** TXTEWS uses the BAS C @#\$ for interna purposes

6 If the module is not using on line configuration, the system initializes it If it is using on line configuration, proceed to Step 7

7 Download begins with Function Codes first followed by Program Space or saved BASIC (in file BASIC @#) next

8 If BASIC was saved in file BASIC @# (Step 5), TXTEWS deletes this file

The configuration file header is displayed when download starts. A progression line shows the block number just written and percentage complete to keep you informed of download status (see Figure 7 26). When complete, a download complete message appears and the program returns to the download input screen. If downloading both function codes and program space, the downloading of the program space immediately follows the downloading of the function codes.





Figure 7 26 Download in Progress

For certain modules, restoring program space may write a configuration to the module with a different format table. When the module receives the new, conflicting format table, the system writes the table, completes the format operation and the module enters Error mode with a CPU LED code of 20 (hex). It is important to note this process because it deletes all existing configuration data in the non-volatile memory. After the module changes to Configure mode, it accepts the entire configuration.

TXTEWS automates this procedure. First, it verifies whether the format tables differ. If they are identical, the download proceeds normally. If they are different, the system tells you of the difference and asks whether you want to continue (remember that continuing destroys all data in NVM). If you continue, the table is written, the module Status LED turns red and the module goes back into Configure mode as the download begins.

If an error occurs during the download, an error message appears on the screen. Following this, a *Retry?* query appears. If you answer **Y**, TXTEWS attempts to once again download the block which generated the error. If you do not want to retry, answer **N**. Another query then appears asking whether an abort of the download is requested. If you answer **Y**, TXTEWS aborts the download. Answer **N** and TXTEWS ignores the block which produced the error and continues with the download.

## MONITOR/TUNE

*Figure 7 27 Monitor/Tune Menu*

### Monitoring a Value

This function permits the monitoring of a single block output. When you enter the ring, PCU, module and block address and press **F10**, the current block output value appears. If the output has any status condition other than OK, the status condition code will appear below the value. See Figure 7-28.




Figure 7-28 Monitoring a Block

The status displays one or more of the following codes

blank	OK
*	Bad Quality
H	High Alarm (may be preceded by alarm level, e.g., <b>3H</b> )
L	Low Alarm (may be preceded by alarm level, e.g., <b>2L</b> )
HD	High Deviation
LD	Low Deviation
S	Point out of Service
C	Calibration Error

Press Esc to abort monitoring

*Tuning a Value*

Tuning a value is similar to adding or monitoring a block. The tune function allows modification of tunable block specifications while the module is in execute mode. The system displays the block when you enter the ring, PCU, module and block address and press F10. See Figure 7 29.




Figure 7 29 Tuning a Block

You can modify only those specifications marked with a T. In Figure 7 29, only specifications 2 and 14 can be modified. If you attempt to tune a block containing no tunable specifications, the system tells you that no tunable specifications are available. It then allows you to inspect the block specifications with no modifications possible. It is possible that a specifications page may not have any tunable specifications. In this case, the non-tunable specifications are displayed but you are not permitted to modify them. You must page forward or backward for the tunable specifications.

After you are done with the modification, press F10 to write the change(s) to the module.

### Modifying the Scan Interval

The scan interval is the time period to update all points in a monitor group. This includes scanning the points and displaying their values. If the scan interval is set too low for the file, the message *Scan Interval Too Short* appears in the lower right corner of the screen. If no such message occurs, the current scan interval is sufficient for the group monitor on screen. The default value is 3 seconds. To change this, enter the necessary value in the field located on the scan interval screen and press F10]. See Figure 7.30.





Figure 7.30 Scan Interval Screen

### Monitoring a Group of Points

The last option in the MONITOR/TUNE menu is the MONITOR GROUP function. MONITOR GROUP allows you to monitor up to 32 block outputs. To monitor a group of points you must first define the monitor group using the MONITOR GROUP DEFINITION function (called from the TXTEWS main menu). This function is held in a file. The base name of the file is chosen by the user. The extension MON is appended to that name. See Figure 7.31.



The screenshot shows a terminal window with the following text:

```
Monitor/Tune
Monitor a Group of Values
File name: TEST
```

Figure 7.31 Monitor Group Input Screen

To monitor the group of points, enter the base name of the MON file in the file name field and press **F10**. The monitor group screen appears. This screen displays the block name, ring address, PCU address, module address and block address as defined in the monitor group definition function. Following this is the block output value and status aligned in two columns. The status uses the same codes that are recognized in the MONITOR BLOCK function. A maximum of sixteen of the 32 possible values are displayed on a page. There can be two pages of block outputs. If more than sixteen values have been defined, use the page up/page down keystrokes to move from page to page. The page number is displayed in the lower left corner of the screen. See Figure 7-32.

MONITOR/TUNE													
Tit e				test				No of Us ues 32					
NAME	RNG	PCU	MD	BLK	VALUE	Q	NAME	RNG	PCU	MD	BLK	VALUE	Q
wike12	0	0	2	100	1		wike9	0	0	2	800	Err	104
wike23	0	0	2	105	1		wike10	0	0	2	900	Err	104
wike3	0	0	2	110	0		wike11	0	0	2	50		0
wike4	0	0	2	120	00		wike12	0	0	2	51		0
wike5	0	0	2	15	0 25		wike13	0	0	2	52		0
wike6	0	0	2	500	Err	104	wike14	0	0	2	53		0
wike7	0	0	2	600	0		wike15	0	0	2	54		0
wike8	0	0	2	700	Err	104	wike16	0	0	2	55		0

Page 1 of 2

Press ESC to Abort

Figure 7-32 Monitor Group Display

If the scan interval time in effect is too short to display the page of defined blocks, the message *Scan Interval Too Short* appears in the lower right corner of the screen. To correct this, exit the MONITOR GROUP function and set the scan interval to a higher value through the Modify Scan Interval option of the MONITOR/TUNE menu.

Errors detected for blocks defined in the Monitor Group Definition appear in the value field of the display.

## VERIFICATION




Figure 7-33 Verification Menu

### Verifying Configuration File vs Module

It often becomes necessary to verify whether the configuration in a module is the same as the configuration file on your EWS. This is easily accomplished through option A of the VERIFY menu.

First select option A of the VERIFY menu. A screen requesting the configuration filename and the ring, PCU and module address appears. See Figure 7-34.

The screenshot shows a terminal window with the following text:

```

Verify
-----
Verify Configuration File with Module

Filename      [REDACTED]
Ring Address  0
PCU Address   0
Module Address 0
  
```

Figure 7-34 Verify CFG File vs Module

Similar to the actions taken by the uploading and downloading process, TXTEWS determines if it needs enhanced module identification. If so, these steps are taken (refer to the **Enhanced Module Processing** Section).

The verification begins. A log screen appears that displays any verification errors. Do not be concerned if these errors scroll by quickly on the screen. A log file using the configuration file base name with the extension **.VFY** will be built containing all verification problems encountered. At the end of verification, this file can be inspected or printed to gather all differences. For example, if verifying configuration file 10101 CFG with a module, any verification errors found are put in file 10101 VFY.

The verification process checks for specification differences, block differences, function code inconsistencies and configuration file problems. Specification differences are defined as any INTEGER or BOOLEAN specifications not equal in value, or any REAL specifications not within .005 of one another. Block differences are instances such as the same block number from each source being assigned a different function code. Function code inconsistencies are situations where the data files used by EWS to define function codes differ in definition to the module. Finally, this function checks all configuration files for valid data.

An update line appears giving the current block under verification and the percentage complete. Since the percentage complete is based on the contents of the configuration file, differences between the sources will affect this number. Do not be alarmed if the verification ends prior to recognition of 100 percent complete. This happens if the block totals between the module and CFG file are not identical. See Figure 7-35.




Figure 7-35 Verification in Progress

The process completes with a count of block totals for both the module and the configuration file. No totals are given for verification of program space. This information is also included in the verification file.

If you need to abort from verification, press the Esc key and acknowledge the abort request.

### **Verifying Drawing File vs Module**

This option performs a verification between the contents of a module and a series of drawing files. The drawing files should be the set used to build the configuration file that was downloaded to the module. Any differences between these two sources may be the result of on line tuning or changes performed directly to the module. Another use of this function is to record any changes made to the drawing files prior to a download. This function allows for identification and file update.

Select option B from the VERIFY menu to invoke this function. Enter the module address and 5 character drawing file identifier into the appropriate fields. Once complete, the system presents the update option. If you want to update the drawing files with any differences detected in the module, answer Y to the following question:

#### *Update Specifications in Drawing Files?*

If no update is necessary, answer N to the question. Verification follows the same guidelines as outlined for option A. It analyzes one drawing file at a time. It uses the total number of blocks found in the drawing files as a base for the percentage complete variable. Note that differences from a 100 percent complete finale are due to differences in block counts.

The verify file uses the drawing file name as the base name with the .VFY extension.

### **Verifying Drawing File vs Configuration File**

This function allows for the verification of a set of drawing files with a configuration file. If a module has just been up loaded, the advantages to using this operation are the same as those for option B of VERIFY. This function provides a means to identify any module changes made on line from the original drawing files or as a means to record any changes made to the drawing files prior to a re configuration.

Select option C from the VERIFY menu to invoke this function. Enter the 5 character drawing file name and configuration file name into the appropriate fields.

All functionality is identical to option B.

### **Verifying Configuration File vs Configuration File**

The final option of verification is verification between two configuration files. This function verifies all function code information between the two CFG files. Select option D from the VERIFY menu to invoke this function. Enter the two configuration file names to verify. Press **F10** to begin verification.

The verify file created uses configuration file name number 1 as the base name of the VFY file. It also uses CFG file number 1 as the base for the block total for percentage complete calculations. Note that differences from a **100 percent complete** finale are due to differences in block counts.

The process completes with a count of block totals for both the configuration files. The system includes this information in the verification file.

If you need to abort from verification, press the **Esc** key and acknowledge the abort request.

**MONITOR GROUP DEFINITION**

Option F of the TXTEWS Main Menu is the MONITOR GROUP DEFINITION function. This function builds and maintains group definition files (MONs) for the MONITOR GROUP selection within MONITOR/TUNE. See Figure 7-36.

This function builds and maintains group definition files (MONs) for the MONITOR GROUP selection within MONITOR/TUNE.

Define Monitor Group

Title Group Definition												
	Name	Rng	PCU	Mod	BLK		Name	Rng	PCU	Mod	BLK	
1	A1	0	0	2	100		9	A9	0	0	2	800
2	A2	0	0	2	105		10	A10	0	0	2	900
3	A3	0	0	2	110		11	A11	0	0	2	50
4	A4	0	0	2	120		12	A12	0	0	2	51
5	A5	0	0	2	15		13	A13	0	0	2	52
6	no	0	0	2	500		14	A14	0	0	2	53
7	A7	0	0	2	600		15	A15	0	0	2	54
8	A8	0	0	2	700		16	A16	0	0	2	55

Figure 7-36 Monitor Group Definition Page


To define a Monitor Group Enter an appropriate MON file name and press **F10** The group definition page appears Key in the monitor group title The title is shown on the MONITOR GROUP display when you invoke Monitor a Group of Points using this file Next, key in up to 32 point definitions for this group The point definitions must be made sequentially starting from definition number one Since the Module Number must always be non zero, when this field is non zero, a point is considered to be defined The Name field is a 6 character alphanumeric field that identifies the block output It is optional Enter the ring, PCU, module and block address fields for each point to be defined

Press **F10** when you are done defining the points to be monitored The file is saved with only the number of points correctly defined You can now monitor this group of points using the Monitor a Group of Points function, called from the MONITOR/TUNE menu

Press **Fscj** to exit from the monitor group definition without saving the file

**Enhanced Module Processing Section**

When operating TXTEWS, it is sometimes necessary to better identify either a module or its characteristics. At the present, there are three places in which this is necessary. They are during uploading (option E of the LIST/SAVE/LOAD menu), downloading (option F of the LIST/SAVE/LOAD menu) and verification (option E of the main menu). The reason for further identification of a module is that there exists certain families of modules that are identified by the same module type but have differing capabilities. When this particular module type is chosen, then further identification will be needed from the user. At the present, this group includes only the MFC family. As an example of such an instance, the menu in Figure 7.37 appears during downloading:



*Figure 7.37 Download Module Identification*

As the example shows, there are 5 modules in the MFC family. Since each module has its own abilities, the correct module must be identified to proceed. Coinciding with this identification is the actual list of module capabilities. All MFC modules contain function code information. However, the MFC family, depending on the particular module, may contain programming blocks as well. These blocks may be either BASIC, C, or BATCH blocks. Table 7.1 identifies the module and its capabilities.

Table 7 1 MFC Capabilities

	Function Codes	BASIC	C	BATCH
MFC01	X			
MFC02	X	X		
MFC03	X	X	X	X
MFC04	X			X
MFC05	X			

As Table 7 1 shows, certain MFCs contain a number of programming capabilities. In the three TXTEWS functions mentioned earlier, it must be known on which type of blocks an operation is to be performed. Therefore, you may encounter another menu asking for this identification. These identification requirements are only necessary on the modules in Table 7-1. See Figure 7 38.




Figure 7 38 Download Options


**STANDARD TEXT FILES**

The following files come with the Network 90 Text Engineering Workstation. These files must be in the \EWS directory.

- TXTEWS.EXE:** The Text Engineering Workstation program
- TDF.DAT:** Text Description File. Function code specification descriptions
- STT.DAT:** Specification Text Table. Pointers to the Text Description File
- MDT.DAT:** Module Description Table. Function code headers and descriptions
- MFC.SDT:** Specification Description Table for the Multi Function Controller
- LAC.SDT:** Specification Description Table for the Logic Master Module, Analog Master Module, and Controller Modules
- TEXT.BAT:** Batch file used to invoke TXTEWS.EXE. Change this file as desired
- MXX.PRF:** Module Problem Report files. TEXT uses these files to identify module error conditions. XX is the module type number (i.e., MFC M11 PRF)

The following files may be used or created by TEXT

- XXXXXXYYZ.DBF** These are the drawing files created by CADEWS software
- XXXXXXYYZ.SPC** They have the following format



- XXXXX.CFG:** Configuration Files. Compiling the CADEWS drawing files using the Network 90 compiler or by saving the configuration stored in a module using TEXT creates this file

- XXXXX.CFG**
- 
- Module Address (00-31)  
 Process Control Unit Address (01-63, A0-Z9)  
 Plant Communication Loop (09, A-Z)

**XXXX.VFY** Text verification file. Contains any verification errors detected during this function.

**XXXX.NBS** Program block configuration file. This is a configuration file containing a BASIC program, C program or file system blocks.

The following files must be present in the \EWS2 directory

**I.SCR100** This file identifies the input screens used by the TEXT software. Do NOT edit or change this file under any circumstances.

**M.SCR100** This file identifies the menu screens used by the TEXT software. Do NOT edit or change this file under any circumstances.

**KEYS.HLP** This is the keystroke help menu. It should not be altered under any circumstances.

**TXTXX.HLP** These files are the help menus for the various TXTEWS functions. They should not be altered under any circumstances.

---

## SECTION 8 — MODULE BINDING UTILITY

---

### INTRODUCTION

The NET90BND (Binder) program is a utility that links module bus and plant loop inputs found in CAD drawing files to outputs that lie across module boundaries. Without Binder, you must enter module bus and plant loop input parameters manually. Binder automates this process. It matches module bus or plant loop input text descriptions with OREF text descriptions and places the appropriate input address in the CAD drawing files. It also detects any unmatched inputs or any type mismatches between matched input/OREF pairs.

Binder requires that all modules are compiled. The compiler generates BND and REF files for each module. These files contain the information needed by the Binder program. If your CFG files were not generated by versions 1.2 or later of the compiler (contained in SCAD 4.1), they must be recompiled for the binding process to work properly. Also, if you did not keep the BND and REF files after compilation, the modules must be recompiled before Binder can be used.

The program produces a log file (N90BIND LOG). This file lists all errors found during the binding process. It also creates a batch file (N90CMPL BAT). This file is used to recompile all changed modules. Delete it once the binding process is complete. When N90CMPL BAT is run, all changed modules will be compiled, even if there were errors in the binding process.

Change the DOS current directory to the main job directory to use Binder. Binder works from this directory down into all of its subdirectories. Type NET90BND to start the binder. The program scans the directory tree and displays all modules found (MFD files) for selection. Module selection for Binder is identical to that used in the compiler.



03 19 26 04 10 07

---

## SECTION 9 NETWORK 90 CROSS-REFERENCE UTILITY (N90XREF)

### INTRODUCTION

The N90XREF utility resolves the references between drawing sheets of a module, PCU, and loop. The resolved references contain the module ID, sheet number, and row column of the reference. This information becomes a permanent part of the drawing file.

N90XREF automatically completes cross reference data for these symbols.

IREF	input reference
IREFO	used for outputs which exit the left side of the page
OREF	output reference
AI/B	FC 25
AI/L	FC 26
DI/B	FC 41
DI/L	FC 42
DIL	FC 46
AIL/B	FC 63
DIL/B	FC 64

The 30-character text strings associated with input and output symbols are used in cross referencing the NETWORK 90 drawings. Output symbols (IREFO, OREF) are cross referenced to input symbols with the AASS YY XX format, where.

AA - Two unique characters identifying each module  
SS - Sheet number of module.  
YY - Y Coordinates  
XX - X Coordinates

The drawing borders have even numbers (x,y coordinates) printed in the margins. These numbers are used as a guide to find input/output symbols.

Use the following basic rules to be for cross referencing.

1. Fill in the module ID field before you use the Module Header Definition program. This field requires two unique user defined alpha characters for each module in the system.
2. Use a 30 character size to print two alpha characters on each drawing sheet associated with a module, above the drawing number.

- 3 Print sheet numbers above the drawing number. Ensure that they are the same as the last two numbers of the drawing file. The N90XREF program uses the drawing file to fill in the module sheet number in the input/output symbol.
- 4 The 30 character text string associated with input and output symbols must be unique for the cross reference program to work. The program allows an output symbol to reference input symbols within a module, and input symbols between modules using the same 30 character string. See Figure 9.1.




Figure 9.1 Symbol Cross Reference

**How To Use The Cross Reference Utility**

First, go to the proper directory. For example,

- CD \[deep structure directory] or
- CD \[semi deep structure directory] or
- CD \[flat structure directory]

Type **CD \JOB02 Enter**

Now type **CAD Enter**. At the main menu type **E**. A series of screens then prompts for the necessary information throughout the program.

N90XREF gives the option of generating a text cross reference list of each input and output signal on a drawing sheet, the origin location of the signal and any destination locations for the signal.

**Error Messages**

If N90XREF detects an error when opening or creating a file, a message identifies the file causing the error. N90XREF attempts to continue executing. If the directory does not contain the necessary files, N90XREF prompts to change to the correct directory.

Common error messages include:

*Duplicate output description in file skipping*

*Blank description in file.*

*Major error no room in drawing*

If the last error message above appears, *Major error no room in drawing*, the drawing must be made smaller before continuing.



## APPENDIX A — CAD COMMAND SUMMARY

NAME	COMMAND	MODES
ADD CONNECTION	AC or F7	DB
ARC	A	DB
AUTO PAN	AP	DB MT
ASSIGN NAME	AN or AN name	DB
CHANGE ATTRIBUTE	CA or F8	D
CHANGE LAYER	CL	D
CIRCLE	C	DB
CONTINUE	C	MT
COPY	CO	ID
CURSOR INCREMENT	CI X Y	DB ID
DELETE ENTITY	DE or F8	D
DISTANCE BETWEEN CURSOR POINTS	DI	DB ID
EXT	EX	DB LM
EXPLODE	XP	ID
FIND ENTITY	FE	DB
FORM MACRO	FM	DB
FORM SHAPE	FS	DB
FUNCTION NAME	FN F3 or FN shape name	DB
GRID	GR GR ON GR OFF GR X Y	DB D
GRID LOCK	GL	DB ID
HARD COPY	HC or Ctrl P	DB MT

## CAD COMMAND SUMMARY

NAME	COMMAND	MODES
H ORTHO solid line	H	DB
H ORTHO dashed line	H1	DB
H ORTHO dotted line	H2	DB
H ORTHO dot dashed Line	H3	DB
DENT FY	ID or F4	DB
DENTIFY POINT	IP	DB ID
IDENTIFY WINDOW	W	DB
LAYER	LA	DB
LIBRARY MANAGER	LM	DB
L NE	L	DB
LIST LIBRARY	L	LM
LIST SPECS	LS	DB
MODIFY BLOCK	MB	DB
MONITOR/TUNE	MT	DB
MOUSE	MS	DB
MOVE	MO or F5	D
NEXT ENTITY	NX	D
PAN	PA or F9 PA X Y	DB MT
PLOT	PL PL f	DB
QU CK CURSOR	QC	DB
QUIT	Q	DB
RECT ANGLE	R	DB
REDRAW	RE	DB

NAME	COMMAND	MODES
REFRESH	RF	DB MT
RESET DATABASE	RS	DB
ROTATE	RO RO n, n	ID
SAVE	SA	DB
SCALE ENT TIES	SC	D
SET VIEW	SV	DB MT
SHAPE DELETE	SD	LM
SHAPE REFERENCE	SR SR ON SR OFF	DB
STATUS	ST	DB
STRA GHT L NE	S	DB
SYSTEM MACRO	SM	DB
SYSTEM SHAPE	SS	DB
TEXT	T	DB
TEXT D SPLAY	TE TE ON TE OFF	DB
TUNE	TU	MT
UNDELETE	UN	LM
USER LIBRARY	UL	DB
USER MACRO	UM	DB
USER SHAPE	US	DB
V ORTHO solid ne	V	DB
V ORTHO dashed ne	V1	DB
V ORTHO dotted ine	V2	DB

**CAD COMMAND SUMMARY**

---

<b>NAME</b>	<b>COMMAND</b>	<b>MODES</b>
V ORTHO dot dashed line	V3	DB
V S BLE LAYER	VL or VL n	DB
ZOOM	ZO	DB MT

**Note.**

1 For an explanation of this command refer to Monitor/Tuning Section 3

## APPENDIX B — GLOSSARY

TERM	DEFINITION
Attribute	Definitions of properties associated with an object. Examples of attributes are the block number and text associated with an input or output.
Connect on	A point at which two or more objects are logically joined. The kinds of objects that can be connected are lines and shapes. Lines are connected only if they have coincident vertices. A line is connected to a shape if it has a vertex at the same point as one of the I/O pins of the shape.
Destination Point	A reference point in the drawing to which an identified object is copied or moved.
Diagram	A collection of entities forming a logical design such as a NETWORK 90 configuration drawing.
Endpoint	The final vertex of a line.
Entity	A line or shape.
Grid	A matrix of reference points marking multiples of the database units and used to place and locate entities in a drawing. The grid may or may not be displayed on the screen.
Grid Lock	A mode of operation in which the cursor is constrained to move on grid points (whether the grid points are currently displayed or not).
Help Window	An on-screen display of information about a given command.
Highlight	Displays drawing or text in white.
Horizontal-Orthogonal	Lines drawn in which points entered are connected by lines at right angles to the first line being parallel to the horizontal axis.
Identify	To mark an object or objects so they can be manipulated with one of the identify mode commands. Identified objects are highlighted after being selected.
Identify Mode	The mode in which an existing entity or entities can be modified, copied, deleted, etc. Identify mode is entered via the D/W Command.
Justification Point	The point at which the beginning of a text string is located. The overflowed part of the text is placed at the justification point.
Library Manager	The CAD mode in which the contents of system/user libraries can be stored and user libraries can mark shapes for deletion/recovery.

## GLOSSARY

TERM	DEFINITION
Library Manager	The CAD mode in which the contents of system/user libraries can be listed and user libraries can mark shapes for deletion/recovery
Line	An object which has a defining path. Lines are used in CAD both as graphic elements and as electrical connections
Line Segment	The portion of a line between two adjacent vertices
Macro	A combination of shapes and/or primary entities stored in either the user or system library
Magnification Factor	The current scale of the view window relative to 1 X integer values only
Origin	The point corresponding to coordinates (0,0) in the drawing
Origin Point	The point on a macro or shape when called from the library which is mapped to the cursor position on the CRT
Pan	To move the view window temporarily in the drawing. REDRAW restores the previous window
Redraw	To display the current page of the drawing at a magnification of 1
Refresh	Redraws the page at current magnification
Set View	To define a portion of the drawing in which to zoom
Shape	A collection of objects that is stored in a library. Multiple instances of a shape can be placed in a drawing. A shape instance is a single object regardless of the number of primary entities that make up the shape in the library
Shape Reference	A point on the shape which determines how an instance of that shape is placed in a drawing
Straight	A line which may be entered with angles which are integer multiples of 45
Surface	See line segment
Text	Character data placed in a drawing
Vector	A line which may be entered at arbitrary angles
Vertex	The point of intersection of two line segments
Vertical Orthogona	A line in which points entered are connected by lines at right angles. The first line being parallel to the vertical axis
Window	The portion of a drawing which is displayed on the screen. Windows are also used to describe the highlighted rectangle that is displayed in SETVIEW and DWINDOW
Working File	The database file currently being edited
Zoom	To change the view window scale of the drawing relative to the current scale

## APPENDIX C — TERMINATION UNIT DRAWINGS

The following master termination unit drawings are available in CAD

File No.	Description
0000401	NAOM01 and NTAO01
0000402	NAOM01 and NTAO01 (2 per drawing)
0000403	NASM01 and NTA 01
0000404	NASM02 and NTA 02
0000406	NASM01 and NAI01
0000407	NASM02 and NTA01
0000405	NASM03 and NTA 03
0000101	NCIS01 and NTCS02
0000114	NC S01 with NCS01 and NDS01
0000201	NCOM0 and TCS
0000202	NCOM0 with NCS01 and NDS01
0000110	Digital Logic State on master for MFC
0000116	NDSI01 with MFC or NLMM02 and N D 01
0000307	NDS 01 with MFC or NLMM02 and NTD 01
0000115	NDS 01 with MFC or NLMM02 and NTD 01
0000301	NDSM03 with LMM and NTD 01
0000108	NDSM03 with LMM or MFC and no termination unit
0000102	NDSM03 with MFC or NLMM02 and NTD 01
0000112	NDSM03 with MFC or NLMM02 and N D 01
0000305	NDSM03 with MFC and no termination unit
0000105	NDSM04 and NTD 01
0000111	NDSM04 and N D 01
0000302	NDSM05 with LMM and NTD 01
0000306	NDSM05 with LMM and no termination unit
0000113	NDSM05 with MFC and N D 01
0000103	NDSM05 with MFC or NLMM02 and NTD 01 for 16 outputs
0000109	NDSM05 with MFC or NLMM02 for 16 outputs and no termination unit
0000104	NDSM05 with MFC or NLMM02 and NTD 01 for 8 inputs and 8 outputs
0000310	NDSO0 with NLMM02 and N D 01
0000309	NDSO0 with NLMM02 and N D 01 (includes function code 83)
000011	7NDSO0 with MFC or NLMM02 and N D 01
0000303	NTD001 with LMM (first)
0000304	NTD001 (Second)
0000106	NTD001 with MFC or NLMM02

**NOTE** Refer to the README.DBF file for the latest revisions and available drawings

**TERMINATION UNIT DRAWINGS**

---

Use the following procedure when working with the master termination unit drawings

- 1 Change to the job directory where the work is to be done
- 2 Type **CAD** **[Enter]**.
- 3 When the prompt *Database File* appears, type the file number of the master drawing to be accessed
- 4 After the drawing is displayed on the screen, use the **ASSIGN NAME (AN)** command to *rename* the drawing for the job
- 5 Modify the drawing to meet the job requirements
- 6 Use the **SAVE (SA)** command The drawing is then saved in the job directory under the name entered in Step 4

## APPENDIX D — FIRMWARE REVISION LEVELS

This appendix is a listing of current revision levels for the Network 90 Engineering Workstation. The easiest way to use this listing is to first look at the assembly number on the PC Board in the module. Find the number on the chart on the next two pages, and then find the appropriate revision level.

### *Revision Level Output*

Module	Block Number	Nomen. Hardware		Firmware		PCB Assembly Number	Firmware Revision Level(s)
		1000s	100s	10s	1s		
NAMM01	N/A	1	0	0	0	D3078063	A B
NAMM02	N/A	2	0	0	0	D5634882	A D 1
	97	2	0	0	1	D5634882	E 0
	97	2	0	0	2	D5634882	E 1
	97	2	0	0	3	D5634882	E 2
	97	2	0	0	4	D5634882	E 3
	97	2	0	0	5	D5634882	E 4
	97	2	0	0	6	D5634882	E 5
NAMM02A	97	2	1	0	0	D6635334	A 0
NAMM03	97	3	0	0	0	D6637204	A 0
	97	3	0	0	1	D6637204	A 1
NAOM01	N/A	1	0	0	0	D6631966	A B
NCLC01	252	3	1	0	2	D6636740	B 1
NCLC02	252	4	1	0	0	D6636740	B 1
NCOM02	N/A	2	0	0	0	D6631942	A E
NCOM02A	N/A	2	1	0	0	D6634882	F K 3
NCOM02B	N/A	2	2	0	0	D6635405	A 0 A 1
NCOM03	N/A	3	0	0	0	D6634882	A J 3
NCOM03A	N/A	3	1	0	0	D6635405	A 0 A 2
NCOM04	N/A	4	0	0	0	D6634882	A - D
NCOM04A	N/A	4	1	0	0	D6635405	A 0
NCSC01	13	1	0	0	0	D6637427	A 0

**FIRMWARE REVISION LEVELS**



*Revision Level Output*

Module	Block Number	Nomen. Hardware		Firmware		PCB Assembly Number	F rmware Revision Level(s)
		1000s	100s	10s	1s		
NLMM01	N/A	1	0	0	0	D6631948	A F
	2	1	0	0	1	D6631948	F 1
NLMM01A	2	1	1	0	0	D6635814	A 0
	2	1	1	0	1	D6635814	A 1
NLMM02	13	2	0	0	0	D6635814	A 0
	13	2	0	0	1	D6635814	B 0
	13	2	0	0	2	D6635814	B 1
	13	2	0	0	3	D6635814	C 0
	13	2	0	0	4	D6635814	C_1
	13	2	0	0	5	D6635814	C 2
	13	2	0	0	6	D6635814	C 3
	13	2	0	0	7	D6635814	D 0
	13	2	0	0	8	D6635814	D 1
NMFC01	N/A	1	0	0	0	D6635334	A 0 C 0
	13	1	0	0	1	D6635334	D 0
	13	1	0	0	2	D6635334	E 0
	13	1	0	0	3	D6635334	E 1
	13	1	0	0	4	D6635334	F 0
	13	1	0	0	5	D6635334	G 0
	13	1	0	0	6	D6635334	J 0
	13	1	0	0	7	D6635334	J 1
	13	1	0	0	8	D6635334	K 0
	13	1	0	0	9	D6635334	K 1
	13	1	0	1	0	D6635334	K 2
	13	1	0	1	1	D6635334	K 3
	13	1	0	1	2	D6635334	K 4
	13	1	0	1	3	D6635334	L 0
	13	1	0	1	4	D6635334	L 1
13	1	0	1	5	D6635334	M_0	
13	1	0	1	6	D6635334	M 1	
NMFC02	N/A	2	0	0	0	D6635334	A 0 A 2
	13	2	0	0	1	D6635334	B 0
	13	2	0	0	2	D6635334	C 0
	13	2	0	0	3	D6635334	C 1
	13	2	0	0	4	D6635334	D 0
	13	2	0	0	5	D6635334	E 0
	13	2	0	0	6	D6635334	F 0
	13	2	0	0	7	D6635334	F 1
	13	2	0	0	8	D6635334	G 0
	13	2	0	0	9	D6635334	G 1
	13	2	0	1	0	D6635334	G 2

**FIRMWARE REVISION LEVELS**

*Revision Level Output*

Module	Block Number	Nomen. Hardware		Firmware		PCB Assembly Number	Firmware Revision Level(s)
		1000s	100s	10s	1s		
NMFC02	13	2	0	1	1	D6635334	G 1
	13	2	0	1	2	D6635334	G 2
	13	2	0	1	1	D6635334	G 3
	13	2	0	1	2	D6635334	G 4
	13	2	0	1	3	D6635334	J 0
	13	2	0	1	4	D6635334	J 1
	13	2	0	1	5	D6635334	K 0
	13	2	0	1	6	D6635334	K 1
NMFC03	13	3	0	0	1	D6636896	B 0
	13	3	0	0	2	D6636896	B 1
	13	3	0	0	3	D6636896	C 0
	13	3	0	0	4	D6636896	C 1
	13	3	0	0	5	D6636896	C 2
	13	3	0	0	6	D6636896	C 3
	13	3	0	0	7	D6636896	D 0
	13	3	0	0	8	D6636896	E 0
NMFC04	13	4	0	0	0	D6637133	A 0
NMPC01	13	1	0	0	4	D6635334	F 0
	13	1	0	0	5	D6635334	G 0
	13	1	0	0	6	D6635334	J 0
	13	1	0	0	7	D6635334	J 1
	13	1	0	0	8	D6635334	K 0
	13	1	0	0	9	D6635334	K 1
	13	1	0	1	0	D6635334	K 2
	13	1	0	1	1	D6635334	K 3
	13	1	0	1	2	D6635334	K 4
	13	1	0	1	3	D6635334	L 0
	13	1	0	1	4	D6635334	L 1
	13	1	0	1	5	D6635334	M 0
	13	1	0	1	6	D6635334	M 1
NQRC01	N/A	3	0	0	0	D6634882	J 3
NQRC01A	N/A	3	1	0	0	D6635405	A 0 A 2
	N/A	3	1	0	1	D6635405	B 0
	N/A	3	1	0	2	D6635405	B 1

23 19 46 04 10 07

**Bailey**<sup>®</sup>

---

## APPENDIX E — TEXT ERROR MESSAGES

Most Text Engineering Workstation messages are self explanatory. Error messages define problem situations and status messages describe actions.

Text Engineering Workstation error messages can be grouped into six classifications: CIU Reply Code and Module Bus Errors, CIU Driver Error Messages, Screen Error Messages, Module Status Error Messages, List/Save/Load Error Messages, and Module Configuration Error Messages.

Some common error messages, causes, and remedies are listed in the following chart.

Error Message	Probable Cause	Possible Remedy
Waiting for Parity Loop	These errors usually indicate a conflict with data traffic.	Retry command
Time out of Plant Loop Response		
Module Bus Busy		
Module Conflict	Wrong module mode for the command	Change Mode
Module Not Responding	Module not connected	Check PCU number Program module
Invalid Block Number	Block number out of range for that module	Use valid block number
Undefined Block Number	Tried to access a non configured block	Configure block
Invalid Function Code	Function code not defined for that module	Use valid function code number

The following errors can result from improper setup, bad cable connections, or hardware failure

Error Message	Possible Remedy
Need a Restart Command	Check C U or SPM switch settings Baud Rate Stop B t
Repeat C U Restart Command	
Input Time Out	
Device Error	
Received Data Error	
Data Bits	
Checksum Error	
Parity	
Output Time Out	Check cables and cable connections Check cable to the Async Port 1
Unable to Initialize Communication Port	
PTM not Responding	

**NOTE** After the errors *Need a Restart Command* through *PTM Not Responding*, perform a manual hardware reset of the C U or SPM. Refer to Product Instructions E93 905 or E93 905 1 for details.

---

## APPENDIX F — TEXT STATUS MESSAGES

---

Engineering Workstation status messages report problems and confirm the completion of tasks. The following is a list of Text Engineering Workstation messages.

- Block added
- Block deleted
- Block modified
- Block tuned
- Configuration verified
- Failed verification
- Loading Function Description
- Loading Text Description
- Module type does not exist in MDT file
- More specs
- Restart CIU, Stand by .
- Start loading configuration



## APPENDIX G — FUNCTION BLOCK SHAPE LIBRARY

Function Code			Applicable Module								
Number	Name	Mnemonic	LM01	LM02	COM02	CLC01/02 COM03/04 GR01	CLC03/04	MPC01	MFC01/02 /03/04/05	CBC01	CSC01
			1	Function Generator	FX		X	X	X		X
2	Manual Set Constant	A		X	X	X	X	X	X	X	X
3	Lead/Lag	FT			X	X	X	X	X	X	X
4	Pulse Position	PULPOS			X	X	X	X	X	X	X
5	Pulse Rate	PULSE			X	X	X	X	X	X	X
6	High/Low Limiter	LIMIT			X	X	X		X	X	
7	Square Root	SQRT		X	X	X	X	X	X	X	
8	Rate Limiter	VELLIM			X	X	X		X	X	
9	Analogue Transfer	TAN			X	X		X	X	X	X
10	High Select	HSEL		X	X	X	X	X	X	X	
11	Low Select	LOSEL		X	X	X	X	X	X	X	
12	High/Low Compare	H/L		X	X	X	X	X	X	X	X
13	Integer Transfer	TINT			X	X	X	X	X	X	
14	Four Input Summer	SUM4		X	X	X	X	X	X	X	
15	Two Input Summer	SUM		X	X	X	X	X	X	X	X
16	Multiply	MULT		X	X	X	X	X	X	X	X
17	Divide	DV		X	X	X	X	X	X	X	X
18	PD Error Input	PD		X	X	X	X		X	X	
19	PD (PV and SP)	DELPD			X	X	X		X	X	
20	Indicator Status	IND			X	X	X		X	X	X
21	M/A Status (Basic)	M/A BAS			X	X	X				
22	M/A Status (Cascade)	M/A CAS			X	X	X				
23	M/A Status (Ratio)	M/A RAT			X	X	X				
24	Adapt	ADAPT		X	X	X	X	X	X	X	X
25	Analogue Input/Bus (Same PCU)	A/B		X	X	X	X	X	X	X	X
26	Analogue Input/Loop (Different PCU)	A/L		X	X	X	X	X	X	X	X
27	Analogue Input	A		X	X	X					
28	Analogue Output/Bus (Same PCU)	AO/B			X	X	X		X	X	X
29	Analogue Output	AO			X	X	X				
30	Analogue Except on Report	AO/L		X	X	X	X	X	X	X	X
31	Test Quality	TSTQ	X	X	X	X	X	X	X	X	X
32	Trip	TRIP	X	X	X	X	X	X	X	X	X
33	NOT	NOT	X	X	X	X	X	X	X	X	X
34	Memory	SR	X	X	X	X	X	X	X	X	X
35	Timer	TD-DG	X	X	X	X	X	X	X	X	X

**FUNCTION BLOCK SHAPE LIBRARY**



Function Code			Applicable Module								
Number	Name	Mnemonic	LMM01	LMM02	COM02	CLC01/02 COM03/04 QRC01	CLC03/04	MPC01	MFC01/02 /03/04/05	CBC01	CSC01
36	Qualified OR (8 nput)	QOR	X	X	X	X	X	X	X	X	X
37	AND (2 nput)	AND2	X	X	X	X	X	X	X	X	X
38	AND (4 nput)	AND4	X	X	X	X	X	X	X	X	X
39	OR (2 nput)	OR2	X	X	X	X	X	X	X	X	X
40	OR (4 nput)	OR4	X	X	X	X	X	X	X	X	X
41	Digital/Module Bus	D/B	X	X	X	X	X	X	X	X	X
42	Digital/Loop	D/L	X	X	X	X	X	X	X	X	X
43	TCS Digital	D	X	X	X	X	X	X	X	X	X
44	TCS Digital Output	DO			X	X	X				
45	Digital Exception Report	DO/L	X	X	X	X	X	X	X	X	X
46	Digital List	D/L	X	X							
47	Analogue Input Exception Report	A/ASM	X								
48	RESERVED										
49	Digital Output Buffer	DOBUFF	X	X							
50	Manual Set Switch	ON/OFF	X	X	X	X	X	X	X	X	X
51	Manual Set Constant (Nontunable)	A REAL		X	X	X	X	X	X	X	X
52	Manual Set Integer	A NT			X	X	X	X	X	X	X
53	Executive Block (COM)	EX/COM			X	X	X				
54	Executive Block (LMM01)	EX/LMM	X								
55	RESERVED										
56	Executive Block (AMM01)	EX/AMM1									
57	RESERVED										
58	Time Delay (Analogue)	DELAY			X	X	X		X	X	
59	Digital Transfer	T D G	X	X	X	X	X	X	X	X	X
60	Group /O Definition	G O/LMM	X								
61	Blank	BLNK	X	X				X	X	X	X
62	Remote Control Memory	HCM	X	X	X	X	X	X	X	X	X
63	Analogue Input List (Module Bus)	A/LB			X	X	X	X	X	X	X
64	Digital Input List (Module Bus)	D/LB	X	X	X	X	X	X	X	X	X
65	Digital Sum With Gain (4 nput)	DSUM		X	X	X	X	X	X	X	X
66	Analogue Trend	TREND			X	X	X		X	X	
67	RESERVED										
68	Remote Manual Set Constant	REMSET		X	X	X	X	X	X	X	
69	Test Alarm	TSTALM			X	X		X	X	X	X


Function Code			Applicable Module									
Number	Name	Mnemonic	LMM01	LMM02	COM02	CLC01/02 COM03/04	QRC01	CLC03/04	MPC01	MFC01/02 /03/04/05	CBC01	CSC01
			70	Ana og Po nt Def n t on	ASO/L							
71	Ana og Execut ve B ock	EX/AMM										
72	Ana og Save Def n t on	EXS/AMM										
73	Ca brat on	CAL/AMM										
74	Ca brat on Command	CMD/AMM										
75	Four Ana og Ca brat on Status	CALST/A										
76	Thermocoup e Temperature	TUTEMP										
77	Ana og Po nt Serv ce Status	PTSST										
78	Trend Def n t on	ATREND										
NOTE: Funct on Codes 70 through 78 are ava ab e for the Ana og Master Modu es (NAMM02 NAMM03) on y												
79	Contro nterface Save	C S/O								X	X	X
80	Contro Stat on (MFC)	M/A M							X	X	X	X
81	Execut ve (MFC and MPC)	EX/MFC							X	X	X	X
82	Segment Contro (MFC and MPC)	SEGCRM							X	X	X	X
83	D g ta Output Group	DOGRP		X					X	X	X	X
84	D g ta nput Group	D GRP		X					X	X	X	X
85	Up/Down Counter	UP/DN		X	X	X	X	X	X	X	X	X
86	E apsed T mer	ET MER			X	X	X	X	X	X	X	X
87	DLS nterface	DLS		X					X	X		
88	D g ta Log c Stat on	DLS		X					X	X		
89	RESERVED											
90	Extended Execut ve	EEX/MFC							X	X	X	X
91	BAS C Configuraton	BASCFG								X <sup>1</sup>		
92	nvoke BAS C	NVBAS								X <sup>1</sup>		
93	BAS C Rea Output	BASRO								X <sup>1</sup>		
94	BAS C Boo ear Output	BASBO								X		
95	Modu e Status Monitor	MODSTAT				X	X	X	X	X <sup>1</sup>	X	X
96	Redundant Ana og nput	REDA							X	X	X	
97	Redundant D g ta nput	REDD							X	X	X	X
98	Save Select	SLESEL							X	X	X	X
99	Sequence of Events Log	SOELOG								X <sup>1</sup>		
100	D g ta Output Readback Check	DOREAD							X	X	X	X
101	Exc us ve OR	XOR		X		X	X	X	X	X	X	X
102	Pu se nput/Per od	P PER							X	X	X	X
103	Pu se nput/Frequency	P FREQ							X	X	X	X
104	Pu se nput/Tota zat on	P TOT							X	X	X	X
105	Execut ve B ock (LMM02)	EX/LMM2		X								
106	Segment Contro B ock	SEGCR		X								
107	Group /O Def n t on	G O/LMM2		X								
108	Extended Execut ve	EEX/LMM2		X								
109	Pu se nput Durat on	P DUR							X	X		
110	F ve nput Rung	RNG5		X					X	X	X	X

<sup>1</sup>MFC02/03 on y

# FUNCTION BLOCK SHAPE LIBRARY

Function Code			Applicable Module									
Number	Name	Mnemonic	LMM01	LMM02	COM02	CLC01/02 COM03/04	GRC01	CLC03/04	MPC01	MFC01/02 /03/04/05	CBC01	CSC01
111	Ten nput Rung	RG10		X					X	X	X	X
112	Twenty nput Rung	RG20		X					X	X	X	X
113	ASC I Str ng Descr ptor	ASCI SD							X	X	X	X
114	BCD nput	BCD N		X					X	X	X	X
115	BCD Output	BCDOUT		X					X	X	X	X
116	Jump/Master Contro Re ay	JUMP		X					X	X	X	X
117	Boo ean Rec pe Tab e	REC PB		X					X	X	X	X
118	Rea Rec pe Tab e	REC PR		X					X	X	X	X
119	Boo ean S gna Mu t p exer	BMUX		X					X	X	X	X
120	Rea S gna Mu t p exer	RMUX		X					X	X	X	X
121	Ana og nput/Super oop	A /S								X <sup>2</sup>		
122	D g ta nput/Super oop	D /S								X <sup>2</sup>		
123	Dev ce Dr ver	DDR VE							X	X	X	X
124	Sequence Mon tor	SEQMON							X	X	X	X
125	Dev ce Mon tor	DEVMON							X	X	X	X
126	Rea S gna Demu t p exer	REDEMUX							X	X	X	X
127	P ant Loop Gateway Node Map	GCMMP										
128	S ave Defaut Def nton	D GDEF		X					X	X	X	X
129	Mu t State Dev ce Dr ver	MSDVDR		X					X	X	X	X
130	P ant Loop Gateway Execut ve	EX/GCM										
131	P ant Loop Gateway Po nt Def nton	GPDEF						X	X	X		
132	Ana og nput/S ave	A S								X <sup>2</sup>		
133	W se Transm tter Def nton	W SE							X	X	X	X
134	Mu t Sequence Mon tor	MULT MON							X	X	X	X
135	Sequence Manager	SEQMGF							X	X	X	X
136	Remote Motor Contro	RMC								X		
137	BAS C Rea Output W th Qua ty	BASROQ								X		
138	BAS C Boo ean Output W th Qua ty	BASBOQ								X	X	
139	Pass ve Stat on Interface	PS								X <sup>3</sup>	X	
140	Restore	RESTR								X <sup>3</sup>	X	
141	Sequence Master	SEQMST								X <sup>2</sup>	X	X
142	Sequence S ave	SEQSLV								X <sup>2</sup>	X	X
143	nvoke C	NVKC								X <sup>3</sup>		
144	C A ocat on	CALLOC								X <sup>3</sup>		
145	Frequency Counter/S ave	FCS								X <sup>4</sup>		

<sup>1</sup>MFC02/03 on y  
<sup>2</sup>MFC03/04/05 on y  
<sup>3</sup>MFC03/04 on y  
<sup>4</sup>MFC03 on y



Function Code			Applicable Module								
Number	Name	Mnemonic	LMM01	LMM02	COM02	CLC01/02 COM03/04 QRC01	CLC03/04	MPC01	MFC01/02 /03/04/05	CBC01	CSC01
146	Remote /O nterface	R/O							X <sup>2</sup>		
147	Remote /O Def n t on	R/OD							X <sup>2</sup>		
148	Batch Sequence	BSEQ							X <sup>3</sup>		
149	Ana og Output/S ave	ASO							X <sup>2</sup>		
150	Hydrau c Servo S ave	HSS							X <sup>2</sup>		
151	Text Se ector	TEXT							X <sup>2</sup>		
152	Mode Parameter Est mator	PAREST				X	X		X <sup>2</sup>		
153	SC Parameter Converter	SCCON				X	X		X <sup>2</sup>		
154	Adapt ve Parameter	PARSCH				X	X		X <sup>2</sup>		
155	Schedu er Regress on	REGRES							X	X	
156	Advanced P D Contro er	AP D				X	X		X <sup>2</sup>	X	
157	Genera D g ta Contro er	DTF							X		
158	Enhanced Ana og Po nt Def n t on	EASO/L									
159	Po ynom a Adjustm nt Sm th Pred ctor	A3POLY SMTH				X	X		X	X	
161	Sequence Generator	SEQGEN		X		X	X	X	X	X	X
162	D g ta Segment Buffer	DSNAP		X		X	X	X	X	X	X
163	Ana og Segment Buffer	ASNAP		X		X	X	X	X	X	
164	Segment Contro	SEGCRC				X	X				
165	Mov ng Average	MOVAVG				X	X		X	X	
166	ntegrator	NTEGR				X	X		X	X	X
167	Po ynom a	POLY				X	X		X	X	
168	nterpo ator	NPOL				X	X		X	X	
169	Matrx Add t on	[ADD]				X	X	X	X	X	X
170	Matrx Mult p cat on	[X]				X	X	X	X	X	X
171	Tr gonometr c	TRG				X	X	X	X	X	
172	Exponent a	EXP				X	X	X	X	X	
173	Power	POWER				X	X		X	X	
174	Logar thm	LOG				X	X		X	X	
175	Sequence Execut ve (CSC)	EX/CSC									X
176	Sequence Stat on (CSC)	M/A CSC									
177	Data Acqu st on Ana og	DAA							X <sup>2</sup>	X	X
178	Data Acqu st on Ana og nput/Loop	DAV/L							X <sup>2</sup>		
179	RESERVED										
180	Batch nput/Output	CBC/O								X	
181	Batch Stat on (CBC)	M/ACBC								X	
182	Ana og nput Def n t on	A DEFCBC								X	
183	Batch Exec t ve (CRC)	FXFCRC								X	
184	through 189 RE SERVED										

<sup>1</sup>MFC02/03 on y

<sup>2</sup>MFC03/04/05 on y

<sup>3</sup>MFC03/04 on y

<sup>4</sup>MFC03 on y

**FUNCTION BLOCK SHAPE LIBRARY**

Function Code			Applicable Module										
Number	Name	Mnemonic	LMN01	LMN02	COM02	CLC01/02	COM03/04	QRC01	CLC03/04	MPC01	MFC01/02 X <sup>3</sup> X <sup>3</sup> /03/04/05	CBC01	CSC01
190	User Def ned Funct on Dec arat on	UDFDEC											
191	User Def ned Funct on One	UDF1									X <sup>3</sup>		
192	User Def ned Funct on Two	UDF2									X <sup>3</sup>		
193	through 197 RESERVED												
198	Aux ary Rea User Def ned Funct on	ARUDF									X <sup>3</sup>		
199	Aux ary D g ta User Def ned Funct on	ADUDF									X <sup>3</sup>		
200	Loca nf Net/P ant Loop Gateway Execut ve	NFGATEX									X <sup>3</sup>		
201	nf Net Data Po nt Def n t on	DPDEF									X <sup>3</sup>		
210	Sequence of Events Save	SOE/S											

<sup>1</sup>MFC02/03 on y  
<sup>2</sup>MFC03/04/05 on y  
<sup>3</sup>MFC03/04 on y  
<sup>4</sup>MFC03 on y

**UTILIZATION**

Use the following to determine how to figure out the memory utilization for Function Codes 30, 45 and 140

**Calculating Function Codes 30 and 45 RAM utilization (NMFC03/04/05)**

RAM utilization depends upon S1. In CAD release 4.2, each time Function Code 30 is dropped, 102 bytes are added to RAM. If Function Code 45 is dropped, 66 bytes are added to RAM.


These are the correct values if S1 does not refer to a program i.e., if S1 does not equal 2. If S1 = 2, the correct RAM for Function Code 30 is 130 and for Function Code 45, 90.






**Calculating Function Code 140 Non-Volatile Memory (NVM) utilization (NMFC03/04/05)**

NVM utilization depends upon S1. In CAD release 4.2, each time Function Code 140 is dropped, 66 bytes are added to NVM.

Refer to Function Code Application Manual, E93 900 20 for the correct NVM value.

# APPENDIX H — CAD SYMBOL LIBRARY






TE  
 ○ + 14 VC  
 ● + 25 VD  
 LATED SYSTEM  
 COMM BUS

TPCAL0




PR OF




PR OR




PR OP




PR F1




PR F2




PR F4




PR F5



FR F




PR XU




PR XU, P


TF 7AD03




FF FL




FF FR




FF F




FF FF



FF FT



FF



P-INTC

AVAILABLE SYMBOLS

- LB FLV VERTICAL BALE B FDEF
- LB FLH HORIZONTAL BALE B FDEF
- E FLV VERTICAL BALE B FDEF
- E FLH HORIZONTAL BALE B FDEF

TP 4034

## APPENDIX I — FILE GENERATION

Various files are created by the different aspects of CAD. These file names use the standard Bailey configuration of LPPMSSR ext, where

L	Loop identifier, normally 0 9
PP	PCU #. 00 99
MM	Module address, 01 31
SS	Sheet # of this module, A0 Z9
R	- Revision # of this sheet, A Z

The file extensions are

**CAD.** LPPMSSR DBF  
LPPMSSR SPC  
LBR Shape library extensions, nnbcc lbr, shape lbr  
LPPMSSR PLT If executing a **PL** command, and using write to file option

**TRENDING AND TUNING.** TRN

**COMPILATION.** LPPMSSR SPD A temporary file until a CFG is created, a copy of .SPC LPPM CFG  
LST - Used to store sheet data, output of SELECT, input to compiler  
MSTR LS Holds list of modules to compile  
BND Created by compiler for binder Left on disk  
REF Created by compiler for binder Left on disk  
LOG Log file created by compiler for user, errors, etc  
SDT Database files  
DAT Database files

**JOB HEADER DEFINITION.** JHD

**NETWORK 90 CROSS-REFERENCING.** XRF LOG Created by XREF, contains all messages generated by the program

XRF OUT Created by XREF, contains text cross reference list

**FILE GENERATION**

The following files are created by XREF and deleted at its termination, they are data files used internally

INPTINDX DAT  
INPTFILE DAT  
OUPTINDX DAT  
OUPTFILE DAT  
FILEINFO DAT  
DIRECT DAT  
LIST DAT

**MODJLE MAINTENANCE** LPPMM UTL

**COMPRESS LIBRARY.** OLD Generated if compress fails

**TXEWS** CFG Function Code Configuration File  
VFY Verify File  
NBS Basic/C Configuration File  
MON Monitor Group File

23 00 01 04 10 07

---

## APPENDIX J — ENHANCED COLOR DISPLAY

---

The following information is for EWS users with Enhanced Color Displays

1. CADEWS displays have a screen resolution of 640 x 400 with 16 colors. See Figure J 1 for cable hook up.
2. When CAD is not being executed, the resolution of the screen is 640 x 350. The cable connection of Figure J 1 produces a 16 color palette. For a 64 color palette, connect the cables as in Figure J 2.
3. When CAD is not being executed, adjust Brightness and Contrast to a comfortable level. For optimum display during CAD execution
  - a. Invoke the **ST** command.
  - b. Adjust the Brightness and Contrast controls until the colors associated with each layer are as shown in Table J 1.

Table J 1 Layer Colors

Layer	Color
1	Brownish gold
2	Blue
3	Magenta (purplish red)
4	Dark Gray
5	Light Red
6	Light Blue
7	Light Magenta
8	Green
9	Red
10	Cyan (greenish blue)
11	Light Gray
12	Light Green
13	Yellow
14	Light Cyan
15	White
16	White




Figure J 1 Cabling for 16 Color Palette




Figure J 2 Cabling for 64 Color Palette

## APPENDIX K — PASSWORD SECURITY

Password (PW) security has been added to CADEWS, TXTEWS and TREND software. Password security allows a program to be called up by authorized individuals only. The PW program, included in the CADEWS and TXTEWS software, allows passwords to be set. Usage is as follows:

**PW program name** Enter

where **program\_name** is the software you want to password protect. No program name extension is necessary. When the PW software is executed, it responds with the following:

*Enter password (maximum 8 characters, ESC to quit)*

As you key in the password, your keystrokes do not appear on the screen. When you complete keying in the password, press Enter. Another prompt follows:

*Retype password*

Once again, you enter the password just given. This is done so that an errant keystroke is not saved in the password. If the passwords do not match, this message appears:

*Passwords not the same retype again*

If this happens, you must start the process again.

If a password already exists for the software, the old password is shown by executing PW:

**PW TXTEWS** Enter

*Old password is 'hubba'*

*Enter password (maximum 8 characters, ESC to quit)*

This way, you can retrieve a forgotten password if necessary. A password can be removed from a program by simply typing Enter when prompted for a password. For example:

**PW TXTEWS** Enter

Enter password (maximum 8 characters, ESC to quit) Enter

Retype password Enter

This removes password protection from TXTEWS

The PW software is part of the EWS software. It is loaded when the EWS software is loaded. For those users planning to use password protection for one or more of the programs, the person responsible for setting passwords should do so once the EWS has been loaded on the computer. Once complete, the PW program should be deleted from the \EWS directory. This keeps unauthorized personnel from viewing or changing the password. If passwords need to be changed, the PW program can be restored from the original EWS floppies of a backup copy.

Since a password is embedded directly into the software, care must be taken when moving source. If a version of TXTEWS containing a password is overwritten by a version with none at all, password protection is lost. Remember, passwords are associated with each program, not the EWS. Also, PW sets up only the programs found in directory \EWS with a password. It does not protect any software found in other directories.

Programs set up with a password halt after version information and prompt the user for password entry. After proper password entry, type Enter to gain full software functionality. Invalid password entry terminates the program without user access.

**NOTE:** Spaces and certain other non-printable keystrokes are accepted as password characters. The backspace key erases a mistyped character. However, since no keys are seen on the display, it is best to Esc and start again.

## APPENDIX L — INSTALLING CTRL386

Bailey Engineering Work Station software requires 640 kbytes of conventional RAM. The Intel 301 computers currently available from Bailey have only 512 kbytes of conventional RAM, and 2 Mbytes of extended RAM.

For Bailey EWS software to run, the 512 kbytes RAM must be filled to 640 kbytes. The Intel 301 is supplied with a driver to handle this called **CTRL386**. CTRL386 accomplishes this by causing 128 kbytes of extended RAM to effectively be moved down to the conventional RAM area. This process is called **Memory Backfill**.

Two types of CTRL386 have been supplied with Intel 301 computers: **Partition Loading** and **CONFIG.SYS Loading**. The type provided is printed on the label of the CTRL386 disk supplied with the computer. Locate this disk and determine the type. This appendix covers only the **CONFIG.SYS Loading CTRL386**. If Partition Loading is provided, contact your local Bailey Field Service Office.

### Installing CONFIG SYS Loading CTRL386

1. Make a CTRL386 directory by typing

```
mkdir c:\ctrl386 Enter
```

2. Insert the CTRL386 disk in drive A: and close the drive door. Copy all files to the CTRL386 directory by typing

```
copy a:.* c:\ctrl386 Enter
```

3. Change to the CTRL386 directory by typing

```
cd\ctrl386 Enter
```

4. Execute the CTRL386 setup program by typing

```
setup386 Enter
```

5. The CTRL386 Setup Menu will be displayed to the screen. Fill in each field as shown in Figure L 1.

For further information on each CTRL386 option, refer to the CTRL386 manual provided.

When complete, press **[Esc]** to exit Type **Y** to save

6 Verify the line

**device=\ctrl386\ctrl386.sys**

is in the CONFIG SYS file in the root directory Installation is now complete




Figure L 1 Control/386 Setup Menu

## APPENDIX M — QUICK REFERENCE

### Data Base Commands

A	Arc	MT	Monitor/Tune
AC	Add Connection	PA	Pan
AN	Assign Name	PL	Plot
AP	Autopan (toggle)	Q	Quit
C	Circle	QC	Quick Cursor (toggle)
CI	Cursor Increment	R	Rectangle
D	Distance between points	RE	Redraw
EX	Exit (saves then exits)	RF	Refresh Drawing
FE	Find Entity	RS	Reset
FM	Form Macro	S	Straight Line
FN	Function Name	SA	Save Drawing
FS	Form Shape	SM	System Macro
GL	Grid Lock (toggle)	SR	Shape Reference (toggle)
GR	Grid (toggle)	SS	System Snap
H	H Ortho (solid line)	ST	Status
HC	Hard Copy or Ctrl P	SV	Set View
H1	H Ortho (dot dashed)	T	Text
H2	H Ortho (dotted line)	TE	Text Display (toggle)
H3	H Ortho (dashed line)	UL	User Library
ID	Identify	UM	User Macro
IP	Identify Cursor Coordinates	US	User Shape
IW	Identify Window	V	V Ortho (solid line)
L	Line	V1	V Ortho (dashed line)
LA	Layer Selection	V2	V Ortho (dotted line)
LM	Library Manager	V3	V Ortho (dot dashed)
LS	List Specs	VL	Visible Layer
MB	Modify Block	Z	Zoom
MS	Mouse (toggle)		

### Identify Commands

CA	Change Entity Attribute	IP	Identify Cursor Coordinates
C	Cursor Increment	MO	Move Entity
CL	Change Entity Layer	NX	Select Next Entity
CO	Copy	QC	Quick Cursor
DE	Delete Entity	RO	Rotate Entity
D	Distance Between Points	SC	Scale Entity
GL	Gridlock (toggle)	XP	Disconnect a Shapes Entity
GR	Grid (toggle)		

## QUICK REFERENCE

*Library Commands*

EX	Exit Library Manager	SD	Shape Delete (user library command)
L	List to CRT	UN	Undelete (user library command)
L/P	List to CRT and Printer		

*Monitor / Tune Commands*

C	Continue	SV	Set View
HC	Hard Copy	TU	Tune Block
PA	Pan	ZO	Zoom
RF	Refresh		

*Function Keys*

F1	Grid 100 100	F6	Delete
F2	Grid 20 20	F7	Add Connect on
F3	Function Name	F8	Change Attribute
F4	Identify	F9	Pan
F5	Move	F10	Data Entry

## APPENDIX N — SHEET NUMBER AND ADDRESS TRANSLATION TABLES

The table below shows how to translate the two character field for sheet number and PCU address. Note that valid number for PCU go up to 250, for sheets to 369.

Two Char. Field	Decimal Number	Sheet Number	PCU Address	Sheet Number	PCU Address
A0	100	E0	140	0	180
A1	101	E1	141	11	181
A2	102	E2	142	2	182
A3	103	E3	143	3	183
A4	104	E4	144	4	184
A5	105	E5	145	15	185
A6	106	E6	146	6	186
A7	107	E7	147	7	187
A8	108	E8	148	8	188
A9	109	E9	149	9	189
B0	110	F0	150	J0	190
B1	111	F1	151	J1	191
B2	112	F2	152	J2	192
B3	113	F3	153	J3	193
B4	114	F4	154	J4	194
B5	115	F5	155	J5	195
B6	116	F6	156	J6	196
B7	117	F7	157	J7	197
B8	118	F8	158	J8	198
B9	119	F9	159	J9	199
C0	120	G0	160	K0	200
C1	121	G1	161	K1	201
C2	122	G2	162	K2	202
C3	123	G3	163	K3	203
C4	124	G4	164	K4	204
C5	125	G5	165	K5	205
C6	126	G6	166	K6	206
C7	127	G7	167	K7	207
C8	128	G8	168	K8	208
C9	129	G9	169	K9	209
D0	130	H0	170	L0	210
D1	131	H1	171	L1	211
D2	132	H2	172	L2	212
D3	133	H3	173	L3	213
D4	134	H4	174	L4	214
D5	135	H5	175	L5	215
D6	136	H6	176	L6	216
D7	137	H7	177	L7	217
D8	138	H8	178	L8	218
D9	139	H9	179	L9	219

**SHEET NUMBER AND ADDRESS TRANSLATION TABLES**

<b>Two Char. Field</b>	<b>Decimal Number</b>	<b>Sheet Number</b>	<b>PCU Address</b>	<b>Sheet Number</b>	<b>PCU Address</b>
M0	220	Q0	260	T0	300
M1	221	Q1	261	T1	301
M2	222	Q2	262	T2	302
M3	223	Q3	263	T3	303
M4	224	Q4	264	T4	304
M5	225	Q5	265	T5	305
M6	226	Q6	266	T6	306
M7	227	Q7	267	T7	307
M8	228	Q8	268	T8	308
M9	229	Q9	269	T9	309
N0	230	R0	270	U0	310
N1	231	R1	271	U1	311
N2	232	R2	272	U2	312
N3	233	R3	273	U3	313
N4	234	R4	274	U4	314
N5	235	R5	275	U5	315
N6	236	R6	276	U6	316
N7	237	R7	277	U7	317
N8	238	R8	278	U8	318
N9	239	R9	279	U9	319
O0	240	S0	280	V0	320
O1	241	S1	281	V1	321
O2	242	S2	282	V2	322
O3	243	S3	283	V3	323
O4	244	S4	284	V4	324
O5	245	S5	285	V5	325
O6	246	S6	286	V6	326
O7	247	S7	287	V7	327
O8	248	S8	288	V8	328
O9	249	S9	289	V9	329

**SHEET NUMBER AND ADDRESS TRANSLATION TABLES**

<b>Two Char. Field</b>	<b>Decimal Number</b>	<b>Sheet Number</b>	<b>PCU Address</b>	<b>Sheet Number</b>	<b>PCU Address</b>
P0	250	T0	290	W0	330
P1	251	T1	291	W1	331
P2	252	T2	292	W2	332
P3	253	T3	293	W3	333
P4	254	T4	294	W4	334
P5	255	T5	295	W5	335
P6	256	T6	296	W6	336
P7	257	T7	297	W7	337
P8	258	T8	298	W8	338
P9	259	T9	299	W9	339
X0	340	Y0	350	Z0	360
X1	341	Y1	351	Z1	361
X2	342	Y2	352	Z2	362
X3	343	Y3	353	Z3	363
X4	344	Y4	354	Z4	364
X5	345	Y5	355	Z5	365
X6	346	Y6	356	Z6	366
X7	347	Y7	357	Z7	367
X8	348	Y8	358	Z8	368
X9	349	Y9	359	Z9	369

23 20 11 04 10 07

**Bailey**

---

## APPENDIX O — STANDARDS

### OVERVIEW

This appendix explains the standard user interface conventions which the Engineering Work Station uses. This includes the significance of menu/display colors, inputting of data, moving around within displays, etc. Note that not all EWS programs comply with all standards in this appendix.

### STANDARD COLORS

Different colors convey different information. There are a limited number of colors used on any display. The standard colors are

<b>cyan</b>	All static text including headers. Standard prompts that come up each time you call a given function are cyan. It is also used as a border to show the active window, if there is any question about which is the active window. For example, a screen with only one window would not have a cyan outline.
<b>green</b>	All dynamic data. On input screens, this means data that you may key in or that has been keyed in. On screens where data is not keyed in, green is used to show data that may change when a screen comes up. For example, a screen that has headers and shows contents of files would have the headers in cyan (same whenever the screen comes up) and the contents of the files in green (different depending on the file contents).
<b>yellow</b>	To get your attention. Used for messages including errors, special attention getting prompts, etc.
<b>red</b>	Alphabetic characters or keys ( <b>F1</b> )–( <b>F10</b> ) in menus, i.e., the key that you press to make a menu choice.
<b>blue or dark blue</b>	Outlines, borders.
<b>highlight</b>	For special emphasis, items may be highlighted in the same color.

**STANDARDS**

**DATA STATES**

Data in the system can be in one of several states. The state depends upon input fields and key functions. The states are Default, Original, Entered, Active and Accepted.

- Default** Each data field has a default value. It is the value given by the programmer. The system uses this value if you do not enter any data for the field. It can be blank. When a screen page comes up for the first time, the fields show default values.
- Original** Fields contain original data when a screen appears. The original data remains unchanged until you accept it. If you enter data in one or more of the fields, but do not Accept, you can recall the original data by pressing Alt O.
- Entered** When you key data into the input field and then move away by any means other than Esc, the data is entered. If you key in data, but do not enter it (by leaving the field), you can recall the last entered value with the Undo Alt U function.
- Active** When the input field is on a given field, it is active and can be modified.
- Accepted** After the Accept function is done for a screen, the system accepts all fields on the screen.

In the following example, an underline shows the active field.

Example Begin on a menu page.

A Choose Hardware Address

B

Select A. The system takes you to a page to enter the hardware address. The page has four fields: Loop, PCU, Module and Block. When the page first comes up, the default values are shown in the fields.

```

Loop   1
PCU    1
Module 1
Block  1
    
```

Modify the Loop value to 2. Do the Undo function, the loop returns to 1.

Modify the Loop value to 3 Move to the next field by tabbing

```
Loop      3
PCU       1
Module    1
Block     1
```

The Loop value of 3 is entered If you move the cursor to the Loop field and do the Undo function, the value will not change

Modify the PCU value to 2

```
Loop      3
PCU       2
Module    1
Block     1
```

Press Esc The message *Data has been changed, do you really want to Escape (Y/N)?* appears Press Y This takes you back to the menu page you started with These values are accepted

```
Loop      3
PCU       1
Module    1
Block     1
```

At the menu, press A again to call up the Hardware Address page. The display shows these values

```
Loop      3
PCU       1
Module    1
Block     1
```

Tab to the PCU field and modify the value to 3

```
Loop      3
PCU       3
Module    1
Block     1
```

Press  $\overline{F10}$  to accept the data The system returns to the page on which you began The accepted values are

```
Loop      3
PCU       3
Module    1
Block     1
```

Do other functions, but do not return to the Hardware Address page again. The system shows

```

Loop      3_
PCU      3
Module   1
Block    1
    
```

At this point, the default values are 1 1 1 1, the original, entered and accepted values are 3 3 1 1

Tab to the Module field and modify the value to 3. Tab to the Block field and modify the value to 3. The page looks like

```

Loop      3
PCU      3
Module   3
Block    3
    
```

At this point, the accepted and original values are 3 3 1 1. The entered values are 3-3 3 1. Do a Page Set to Original Values (Alt O) and the page looks like

```

Loop      3
PCU      3
Module   1
Block    1_
    
```

If you do a Page Set to Defaults (Alt D) function now, the values shown return to their defaults, and the page looks like

```

Loop      1
PCU      1
Module   1
Block    1_
    
```

**INPUTTING DATA**

The Input Field is the standard method for inputting data. The Input Field is a green backlit field. It is as long as the maximum allowable input for the field (e.g., 32 characters). The cursor within the field is a blinking line or space.

When entering text, the cursor does not wrap around. That is, when entering text, the cursor stays at the last (rightmost) character of the field, rather than wrapping back around to, and overwriting the first character. These functions are available for editing text within the input field.

Move the cursor within the input field one space, with wraparound.

Move cursor to first/last character in the input field.

Toggle insert mode on/off. When insert is on, characters go in the field at the current cursor position, shifting existing characters over. When insert is off, characters overwrite the existing characters in the field. When insert is off, the cursor is a single, blinking line. When insert is on, the cursor is a blinking full space.

Delete the character to the left of the current cursor location.

Delete the character under the cursor.

Clear to blanks the current input field. Return the cursor to the left in the input field.

Undo the input field to the last entered value. If the last entered value is what is shown, no action occurs. If the last entered value is an empty string, then the current selected field is emptied.

Note that data is entered whenever you leave a field (except via **ESC**). Therefore this function works only as illustrated in the case below.

User arrives at a field with the value 1.

User changes the field to 2.

Without leaving the field, he presses **ALT** **U**.

The change is *undone* back to 1.

Set the current input field to its original value. If the last entered value is what is shown, no action occurs. If the last entered value is an empty string, the current selected field empties.

Escape from the field without entering data.

Set the current input field to its default value (may be blanks).

## STANDARD FUNCTIONS

**Help**

Press **Alt H** to bring up a help screen that provides information about the function. This help screen is context sensitive where practical.

Press **Alt K** to bring up a help information screen that defines the standard keystrokes. If a help screen is on the display, press **Esc** to exit, then press **Alt K** to bring up the standard keystrokes help screen.

**Clearing Configurations**

Press **Alt D** to clear the current page to defaults. Press **Alt O** to clear the current page to original data.

**Printing Configurations**

Press **Alt P** to print the configuration. If the logical piece to print is the one screen you are working on, the print is done. If it is reasonable that you may wish to print more than is shown on one page, you are given a prompt so that you may determine how much should be printed. Press **Esc** to abort the request to print operation.

If the printer is offline, not connected or not functional, the system displays an error message and the print is not done.

**Leaving Current Page**

Press **Esc** to leave the current page without saving data when appropriate, escape one level up in the menu hierarchy. If you try to escape and leave data changed but not entered on the screen, the system displays *Are you sure?* You must answer the prompt to continue.

**Input Field Checking**

The system checks input to prevent erroneous information from being entered. This checking covers invalid characters and invalid field contents.

Most checking is done when you tab away from the field. The system displays an error message if it finds an error. You can not tab away from the erroneous field. The erroneous data stays in the field so that you may see what you did wrong. Press **Esc** to clear the error message. If you cannot correct the data, you may escape, and the last correct data entered is shown on the display.

In some cases, further error checking is done when you press **F10**. Complex error checks on those that depend on the data in several different fields are done when you press **F10**.

---

**Justification**

Some fields are right justified, some are left justified and some are not justified. Justification depends on final use.

---

**Error Tones**

It is common to sound a tone when an error message displays. Such tones help direct your attention to the error message.

---

**Clearing Input Field**

After you tab to a field, if the first key you press is an alpha-numeric, the field automatically clears. The key pressed becomes the first character in the field. This is done so that when you are inputting a new field, you do not need to clear it first. Note that if you do any other function first (e.g. move the cursor), the auto clear does not work. The program assumes that you wish to edit the field, not clear it, and therefore works in normal character replace mode. If you wish to edit the first character of the field without clearing it, you may move the cursor right, then left, then proceed.

**KEY FUNCTIONS**

**Edit Input Field Keys**

The following keys allow input field editing

Backspace	Delete the character to the left of the current cursor location
Ctrl Home, Ctrl End	Move cursor to first/last character in input field
Del	Delete the character under the cursor
Ins	Toggles insert mode on/off When insert is on, characters are placed in the field at the current cursor position, pushing the characters When insert is off, characters overwrite the existing characters in the field When insert is off, the cursor is a single, blinking line When insert is on, the cursor is a blinking full space
→, ←	Move the cursor within the input field one space, with wraparound, in the direction specified
Alt B	Clear to blanks the current input field Return the cursor to the left in the input field

**Move, Enter and Go to Another Page Keys**

Enter	Enters data into the system, and moves the input field, with wraparound, to the next logical field (same as Tab)
Esc	Escape from current page without saving data escape one level up in the menu hierarchy If you try to escape and leave data changed but not entered on the screen, the system displays <i>Are You Sure?</i> You must answer the prompt to continue Note that the entered data comes back after the escape Additionally, you must press Esc to clear an error message Doing so does not escape from the current page or jump up one level in the menu hierarchy
F10	System Accept Typically used when you finish keying in all data on a page and wish to save it
Home, End	Move input field to the logical first/last input field on page
Pg Up, Pg Dn	Accept current page of data and go to the next logical page of data, with wraparound
Tab	Enters data into the system, and moves the input field, with wraparound, to the next logical field (same as Enter)
Shift Tab	Enters data into the system, and moves the input field, with wraparound, to the previous logical field

Ctrl ↑, ↓    Move the input field in the direction specified with wrap around, on the given column or row that you are working in. Data is entered as you leave the field.

**Restore Active Input Field Keys**

The following keys allow you to restore the active input field or entire screen to earlier values

- Alt** **D**    Set all input fields on the current screen to defaults. Note that defaults may be blanks.
- Alt** **E**    Set the current input field to its default value. Note that the default may be blanks.
- Alt** **O**    Set all values on the screen to the original values they had when the screen came up for the first time.
- Alt** **R**    Set the input field to its original value. If the original value is what is shown, no action occurs. If the original value is an empty string, then the current selected field will be emptied.
- Alt** **U**    Undo the last data keyed into the active field. Set the contents of the Active field back to the last entered value. This can only be done while still on the field. Note that data is entered when you move away from a field (except with Esc).

The following keys facilitate other functions

- Alt** **H**    Pop up a Help screen for the presently active field.
- Alt** **L**    If appropriate, do a forced load of given configuration file from disk.
- Alt** **P**    Print current page.
- Alt** **S**    If appropriate, save to disk all data for the page on which you are, return user to previous editing position.
- Alt** **Y**    Initiate a copy function, if appropriate. This generally is a copy of a page of data. The system prompts for the page to copy from (pressing **Esc** aborts the operation) and then for confirmation (*Are you sure?*) before the copy takes place. When completed, the current page is overwritten with data from the copy from page. The details of how this works vary from program to program.

