


Bailey

SECTION
P81-18

PRODUCT INSTRUCTIONS

PNEUMATIC CONTROL DRIVE
TYPE AC0608



BAILEY METER COMPANY • WICKLIFFE, OHIO 44092

00 33 40 04 11 07

INDEX

	<u>Page</u>
INSTALLATION	6
Location	6
Mounting	6
Tubing Connections	6
Positioner Control Loading Arrangements	7
Lever Assemly	7
Position Indicator	8
Connecting Linkage	8
All Failure Brake	8
Travel Limit Stops	8
Electric Position Transmitter	9
Pneumatic Position Transmitter	9
Pre Service Adjustment Checks	9
OPERATION WITHOUT AIR FAILURE BRAKE	9
Positioner Supply and Bypass Valves	9
Manual Operation	9
Transfer from Manual to Automatic	10
Automatic Operation	10
Transfer from Automatic to Manual	10
OPERATION WITH AIR FAILURE BRAKE	10
Positioner Supply and Bypass Valves	10
Manual Operation	10
Transfer from Manual to Automatic	10
Automatic Operation	11
Drive Operation Necessary During Failure Period	11
Drive Operation Unnecessary During Failure Period	11
Transfer from Automatic to Manual	11
SERVICE ADJUSTMENTS	12
Zero or Suppression Adjustment	12
Range Adjustment	12
Speed Adjustment	13
Cam Characteristic Adjustment	14
DESCRIPTION OF OPERATION	16
Manual Operation	17
Electric Position Transmitter	17
Solenoid Valves	17
Heating Elements	18
Alarm Contacts	18
Air Failure Brake	18
ROUTINE MAINTENANCE	20
CORRECTIVE MAINTENANCE	20
Removing Casing Access Panels	20
Removing Piston and Cylinder Assembly	21
Servicing Cylinder Assembly	21
Removing Air Failure Brake Assembly	21
Recalibration of Drive and Positioner	21
REPLACEMENT PARTS	23
EXPLANATION OF NOMENCLATURE	24

CROSS REFERENCES

Instruction or Equipment	Instruction Section
Bailey Control Linkage	Product Specification P81-5
Pneumatic Position Transmitter	P99 35




FIGURE 3 - Tubing Connections for Air Failure Brake

INSTALLATION

Location

1. Locate Drive in accordance with desired linkage arrangement (see "Connecting Linkage" page 8).

CAUTION. Standard Drive is designed for ambient temperature of 120F (a special design Drive is available for high temperature service to 250F). If Drive is subjected to extreme cold, protect compressed air lines and cylinder (trapped moisture in compressed air may freeze and make Drive inoperative). Drives equipped with a heater (Figure 17) are available for this purpose.

Mounting

2 Figures 1 thru 5 give Control Drive mounting dimensions and details. For Drives with casings (Figure 2) see "Removing Casing Access Panels", page 20, for access to mounting base.

3. Mount Control Drive in any desired position

CAUTION: Before tightening mounting bolts and Drive connecting linkage, shim mounting base if necessary so it will not warp when bolts are tightened. Warping of the base will interfere with the freedom of motion of the Drive lever (see Figure 1 and 2)

Tubing Connections

4. Make supply and loading pressure connections as shown in Figure 1, 2, and 3. Use copper or aluminum tubing and suitable fittings

SUPPLY PRESSURE PSIG	MAXIMUM TORQUE FT LBS (NO LOAD)
40	280
50	400

5. If Drive is equipped with an Air Failure Brake with a remote release pushbutton (Figure 4), run a line from an air supply header thru the pushbutton to the connection shown in Figure 3. Use 1/4-inch copper or aluminum tubing and suitable fittings. Mount the remote release pushbutton on a panel near the operator

Positioner Control Loading Arrangements

6 The Positioner is normally furnished mounted on the Control Drive stand with all tubing connections made between the cylinder and Positioner for direct loading operation. Depending upon the specific application, however, the Positioner may be adjusted for reverse loading operation as described below.

Direct loading (Figure 16) is that arrangement whereby the piston rod moves out of the cylinder as control pressure to the Positioner bellows increases. Control air pressure from the upper port of the Positioner pilot valve is supplied to the underside of the piston. The positioning cam is assembled (black concentric and radial lines visible) so when the cam turns in a counterclockwise direction, tension on the positioning spring increases.

Reverse loading is that arrangement whereby the piston rod moves into the cylinder as control loading pressure to the Positioner bellows increases. For applications requiring reverse loading, it is necessary to switch air line connections to the cylinder and reverse the positioning cam (red concentric and radial lines visible) so when the cam turns in a clockwise direction, tension on the positioning spring increases.

a To reverse air lines.

(1) Move air line connection C2 at top of cylinder to tapped hole on opposite side of cylinder. Plug original C2 connection hole.

(2) Move air line connection C1 at bottom of cylinder to tapped hole on opposite side of cylinder. Plug original C1 connection hole.

(3) Then exchange connections of the air lines running to the cylinder at manifold.

b To reverse positioning cam

(1) Remove cam (Figure 8)

(2) Remove locating set screw

(3) Reassemble set screw in tapped hole in other side of cam hub.

(4) Reassemble positioning cam so opposite side of cam faces outward

Lever Assembly

7. Locate the Hand lever (Figure 1) on the side of the Drive that is most convenient for operation. Then assemble the Drive linkage lever on the opposite side. Assemble both hand lever and Drive linkage lever at any desired angle on the splined end of the Drive shaft. Locate the hand lock lever on either side of the Drive

To change the location of the hand lock lever


a. Disassemble the hand lock and shaft

b. Reassemble lever and shaft in the identical holes and bracket in the opposite side of stand or casing.

c. Disassemble the slotted bar and reassemble it on the other side of the Drive lever.

Position Indicator

8 The Control Drive is provided with a position indicator (Figure 1) on which the position of the piston in the cylinder may be noted. Any position of the driven device may also be determined. The position indicator scale is divided into 10 equal parts, each division representing 10% travel of the Drive piston. Install position indicator as follows



TO MOUNT PUSHBUTTON: REMOVE KNOB NUT & LOCKWASHER. INSERT VALVE THRU CUTOUT FROM REAR OF PANEL. REASSEMBLE LOCKWASHER & NUT. SCREW NUT TIGHT AGAINST PANEL. REASSEMBLE KNOB.

FIGURE 4 - Mounting Dimensions,
Remote Pushbutton, Part No. 5315129 2




FIGURE 5 Mounting Dimensions,
Remote Signal Lamp

a Assemble position indicator to hand lever between lever and stand or casing. For a Drive with casing, the indicator pointer is welded to the casing cover and the cover may be assembled on the casing so the pointer is on the desired side. For a Drive without casing, assemble the indicator pointer on either side of the Drive (the assembly is identical in either case).

b Assemble indicator scale to indicator drum, so OPEN and SHUT on the scale refer to the position of the operating device. Then assemble indicator drum to driven lever.

c Position scale in slots so one extreme end of scale is under the pointer when the piston is at its corresponding travel position.

Connecting Linkage

9 Install connecting linkage in accordance with Product Specification P81 5, "Bailey Control Linkage" or in accordance with the special linkage arrangement drawing if provided for the control system.

Air Failure Brake

10 For Control Drives equipped with a Air Failure Brake (Figure 3), no additional installation is required unless a remote release pushbutton or remote signal lamp is used.

See steps 5 and 11 for these additional installation requirements.

For Control Drives with an Air Failure Brake, set the spring adjustment nut (Figure 18) which determines the air pressure at which the Brake will trip. Turning the adjustment nut to decrease the spring compression decreases the pressure at which the Brake will trip. It is suggested that for a normal supply pressure of 40 psig to the Drive, the Brake should be set to trip at 25 psig, for a 50 psig supply pressure the Brake should trip at 30 psig.

11 If Drive is equipped with an Air Failure Brake with a remote signal lamp, make wiring connections as shown in Figure 5 to the terminals designated in Figure 3. Use No. 14 or larger building wire for protection against damage. Run the wiring in conduit with at least the last two or three feet at the Drive end in flexible conduit so that the wire may be disconnected easily. Mount remote signal lamp on a panel near the operator.

Travel Limit Stops

12 The design of the travel limit stops furnished depends upon whether or not the Drive is equipped with an air failure brake.

For Drives not equipped with an air failure brake, a slotted bar adjustable stop is provided (see Figure 1). To set the stop, loosen the nut and slide the stop to the desired position, then tighten nut. To secure the stop, drill a hole thru the stop washer and slotted bar and insert a dowel pin in the hole.

For Drives equipped with an air failure brake, either a fixed or releasable travel limit stop is provided in place of the slotted bar. The fixed stop consists of one or two steel sleeves which fit over the brake rod (see Figure 26) and mechanically limit travel in either or both directions. The releasable stop is essentially a spring loaded pin which butts against the clevis to limit piston travel. These stops can be released pneumatically to permit additional travel under manual control. Various combinations are possible using pins cut to varying lengths to limit piston travel in either or both directions.

Electric Position Transmitter

13 If the Control Drive includes an Electric Position Transmitter, a drawing is included in

this Instruction Book to illustrate factory installation details (see Drive Specification Sheet for drawing number). Make external wiring connections as required.

Pneumatic Position Transmitter

14. If the Control Drive includes a Pneumatic Position Transmitter, a drawing is

included in this Instruction Book to illustrate factory installation details (see Drive Specification Sheet for drawing number). Also refer to Instruction Section P99 35

Pre-Service Adjustment Checks

15. Make applicable adjustments as described under "Service Adjustments", page 12, before placing Drive in operation

OPERATION WITHOUT AIR FAILURE BRAKE

Positioner Supply and By-pass Valves

The operation of the Positioner supply and by-pass valves is shown in Figure 6. The arrangement shown is for use with either direct or reverse loading connections to the piston cylinder.

A safety latch is provided to lock the supply and by-pass valves in position when they are set for automatic operation. The latch sets itself and prevents the valves from being bumped or jarred out of position.

Manual Operation

1. Supply valve in HAND-CLOSED position.

2. By pass valve in OPEN HAND position

3. Hand lock lever pulled up tight when hand lever is not being operated.

4. With the hand lock lever released, position the Drive by manual operation of the hand lever. Pull the hand lock lever up tight to hold the Drive in any position. (Note position of piston in cylinder on position indicator.) To position the Drive in accordance with demand from the control system, remove Positioner access panel (see "Corrective Maintenance"), remove Positioner cover, and operate Drive so Positioner balance beam is centered between stops (see Figure 8).




FIGURE 6 - Positioner Supply and By-pass Valve Operation

Transfer from Manual to Automatic

- 1 Remove Positioner access panel (see "Corrective Maintenance") and Positioner cover
- 2 Adjust loading pressure to Positioner so that balance beam is centered between upper and lower stops
- 3 Turn by pass valve to CLOSED AUTO
- 4 Release hand lock lever
5. Slowly turn Positioner supply valve to AUTO OPEN

The Drive is set for automatic operation in accordance with the loading pressure applied to the Positioner from the preceding controller in the system

NOTE The above procedure is awkward for routine transfers since the removal of covers and operation at the Drive and controller locations are involved. If transfers are made frequently, determine Drive positions for various loading pressure values, and, then in place of step 1 and 2 above, note Drive position on position indicator and set the

corresponding loading pressure without referring to Positioner balance beam. Install a small pressure gage in loading pressure line at Drive for reference.

Automatic Operation

- 1 Supply valve in AUTO OPEN position
- 2 By pass valve in CLOSED position
- 3 Hand lock lever released
4. The Drive piston is positioned automatically as described under "Description of Operation". Note piston position on position indicator

Transfer from Automatic to Manual

- 1 Pull the hand lock lever up tight.
- 2 Press IN on safety latch assembled with supply and by pass valve.
- 3 Turn by pass valve to OPEN HAND
- 4 Turn supply valve to HAND CLOSED. The Drive is set for manual operation

OPERATION WITH AIR FAILURE BRAKE**Positioner Supply and By pass Valves**

The operation of the Positioner supply and by pass valves is shown in Figure 6. The arrangement shown is for use with either direct or reverse loading connections to the piston cylinder

A safety latch is provided to lock the supply and by pass valves in position when they are set for automatic operation. The latch sets itself and prevents the valves from being bumped or jarred out of position

Manual Operation

- 1 Positioner supply valve in HAND CLOSED position
- 2 Positioner by pass valve in OPEN HAND position if desired
- 3 Brake operating lever (Figure 7) in MANUAL position
- 4 Position the Drive by manual operation of the hand operating lever. Turn Air Failure Brake operating lever to LOCK position to hold Drive in any position. Piston position may be noted on the Drive position indicator. To

position the Drive in accordance with demand from the control system, remove Positioner access panel (see Corrective Maintenance), remove Positioner cover and operate Drive so Positioner balance beam is centered between stops (see Figure 8)

Transfer from Manual to Automatic

- 1 Make certain that full air supply is available
- 2 Turn Positioner supply valve to AUTO OPEN
- 3 Turn Positioner by pass valve to CLOSED AUTO
- 4 Turn Brake operating lever to MANUAL
- 5 Whether or not Hand Auto Station for Control Drive is on HAND, slowly position Drive (by operation of hand lever) to approximately that point which will be held by the Positioner. This will keep the Drive from suddenly jumping to position when placed on automatic. If Drive position vs. control loading pressure is known, position Drive in accordance with control pressure noted on Hand Auto Station in loading line to Drive. If not desired position

Type AC0608□□A Control Drive

combination with the zero adjustment described above, full piston travel may be obtained for as small a pressure change as 10 psi -- e.g., a range of 10 to 20 psig.) Range adjustments available with each of the three Positioner cams furnished are shown in Figures 9, 10 and 11. This adjustment is of value when the device being regulated by the Drive is oversized, since the adjustment allows operation of the Drive thru its useful motion for the desired full change in control loading pressure. It is also useful in matching the loading vs. position characteristic of the Drive with those of related power devices in the same control system.

Speed Adjustment

When the system involves only a single Drive, a high positioning speed is usually an advantage. In a complex control system involving more than one drive, it is generally desirable to operate all power devices at the same speed in order to avoid interaction between units or undesirable process conditions during load changes. However, the speed of operation of the Drive may be decreased if necessary (see Table 3 for normal and minimum decreased speeds of the Control Drive) If it is necessary to reduce the speed of operation, speed control orifices are available for insertion in the control lines from the pilot valve to the cylinder. As noted in Table 3, the orifice (No. 60 drill, .040" diameter) will increase the time required for full piston travel of the Control Drive with 1/8" pilot (40 psig supply pressure) to 25 seconds. This operating time may be decreased, up to the normal value indicated, by drilling the orifice to a larger diameter. To insert a speed control orifice, proceed as follows

1. Remove pilot valve stem by springing open pilot stem retaining spring (Figure 8) and allowing stem to drop out (do not scratch stem lands during this process).
2. Remove pilot valve by removing attaching screws (Figure 21).
3. Remove O ring gaskets from both upper and lower holes on pilot valve block.
4. Insert speed control orifice in each of the upper and lower holes
5. Replace O-ring gaskets.




FIGURE 9 - Cam A, Square Root Relation




FIGURE 10 - Cam B, Straight Line Relation




FIGURE 11 - Cam C, Square Relation




FIGURE 12 Drive Characteristics




FIGURE 13 Desired Control




FIGURE 14 Cam Characteristics

6 Reassemble pilot valve to valve block

7. Reassemble pilot valve stem in pilot valve and replace pilot stem retaining spring

Cam Characteristic Adjustment

This adjustment involves selecting or shaping the proper positioning cam in order to obtain that characteristic of piston position vs. control loading pressure which will afford the desired characteristic of controlled medium vs. control loading pressure. Positioning cams A, B, and C are furnished with each Positioner (the B cam is shipped assembled in place and the A and C cams are attached inside Positioner case). The characteristics for which the cams are shaped are listed in Table 1 and are shown in Figures 9, 10 and 11. The figures show a family of curves for each cam, each curve representing a Range Adjustment when used with that specific cam. Table 2 shows pressure values of the various control loading ranges equivalent to the control loading per cent value in Figures 9, 10 and 11.

If the system involves a single Drive, it is probable that the B, straight line, cam will be satisfactory. However, one of the other cams may be used to provide a more uniform controlled medium vs. loading pressure characteristic, providing stable control over a wide range of operation with a given gain or proportional band adjustment on the controller. The definition of "controlled medium used here is the rate of action of that medium (water, air, etc.) being controlled.

For a Control Drive which is an integral part of a complex control system, the cams provide a selection of characteristics which, together with the range adjustment, should afford close paralleling of the controlled medium vs. loading pressure characteristic. In order to match the inherent characteristics of the regulated device to that of a similar

Positioning Cam, Any Stroke	Piston Position (P) vs Control Loading, (L)	Fig. No
A	Square Root ($L \sqrt{P}$)	9
B	Straight Line (L, P)	10
C	Square ($L P^2$)	11

TABLE 1 Positioning Cam Characteristics

LOADING PRESSURE PER CENT VALUE	PRESSURE VALUE (PSIG)	
	Control System Ranges	
	3 27	3-15
0	3.0	3.0
10	5.4	4.2
20	7.8	5.4
30	10.2	6.6
40	12.6	7.8
50	15.0	9.0
60	17.4	10.2
70	19.8	11.4
80	22.2	12.6
90	24.6	13.8
100	27.0	15.0

TABLE 2 - Conversion Table for Control System Ranges

auxiliary, valve, variable speed control, etc., it may be practical to reduce the controlled medium vs. piston position characteristic of each device in the system to a straight line relationship with regard to control loading pressure. This straight line relationship is established by calibrating the Positioner with respect to the correct positioning cam by the following method

1. Use straight line cam, B, to determine the actual controlled medium vs. power operator piston position characteristic (see Figure 12). (Determine piston position by observing the position indicator.)

2. Decide upon the exact controlled medium vs. control loading pressure characteristic desired (see Figure 13).

3. From steps 1 and 2 above, determine the exact control loading pressure vs. piston position characteristic (see Figure 14).

4. Select the positioning cam whose characteristic curve, shown in Figures 9, 10 and 11, most closely matches the loading vs. position characteristic determined in step 3.

5. If necessary, set the range and zero adjustments to match the loading vs. position characteristic more accurately.

6. If the required characteristic cannot be matched by the above procedure, or if a more exact characteristic is required, alter the shape of the cam as described below

Cam Shaping Method: To assist in the alteration process, cams are marked with radial lines spaced for equal Drive piston position increments and concentric lines spaced for equal control loading pressure increments. The ten concentric lines on the cam correspond to the actual control loading pressure increments shown in Table 2 for the specific control system range being used. Alter the cam shape as follows

a. On the cam selected in step 4 above, locate, for each increment of control loading pressure (concentric lines) that Drive piston position (radial lines) required for the specific loading pressure, as determined in step 4. Refer to Figure 15 for the method of locating these points

b. A curve drawn thru the points located on the cam in step 6a above is the desired cam shape. Either alter cam or cut a new cam to this shape. Caution: There is danger of the cam follower becoming locked in case the cam rise is too steep. When a cam shape is required that includes such a rise, it is necessary to introduce sufficient angularity in the regulating device linkage to allow a less radical cam shape.




FIGURE 15 - Locating Points for Shaping Cam




FIGURE 16 Schematic of Positioner

DESCRIPTION OF OPERATION

The power unit of the Control drive is a double acting air cylinder and piston assembly (Figure 16). A differential applied across the piston from the Positioner produces movement of the piston. This movement is transmitted thru the piston rod to the Drive Lever which rotates the drive output shaft.

The Positioner consists essentially of two opposing forces balanced against each other. When the Positioner is balanced, the force exerted upward on the balance beam by the loading bellows is equal to the downward force exerted by the positioning spring. The force

exerted by the bellows depends upon the loading pressure established by the system in relation to the demand for the controlled medium. The force exerted by the positioning spring depends upon the position of the piston in the cylinder and the shape of the positioning cam. The Positioner drive arm is connected to the drive lever by means of the Positioner drive rod. Thus, for every position of the Drive, the Positioner drive arm assumes a corresponding position. The drive arm is geared to the positioning cam which is shaped to give the desired characteristic of piston position vs. control loading pressure.

When the forces exerted by the loading bellows and positioning spring (Figure 16) are balanced against each other, the balance beam holds the pilot valve stem in its "neutral" position (that is, the pilot valve stem lands are centered at the pilot ports), creating equal pressures (under no load condition only) on either side of the piston. Thus, the position of the Control Drive is maintained.

When the loading pressure increases or decreases, the force exerted on the balance beam by the loading bellows increases or decreases. Movement of the beam raises or lowers the pilot valve stem, increasing or decreasing the air pressure applied to either side of the piston. As the piston is moved by the differential in pressure thus created, positioning spring tension increases or decreases until (1) the forces exerted by the bellows and spring are again at balance, (2) the pilot valve stem returns to its "neutral" position, and (3) the piston assumes a new position.

Manual Operation

By proper setting of the supply and by-pass valves (see Figure 6) the Control Drive can be positioned manually with the hand lever. When the Drive is in manual operation, the hand lever can be set to lock the Drive in the desired position.

Electric Position Transmitter

The Electric Position Transmitter output is applied to a remote-mounted, voltmeter-type indicator for position indication. A drawing of the Electric Position Transmitter assembly, if provided, is included elsewhere in this Instruction Book.

Solenoid Valves

If Solenoid Valves are provided with the Control Drives, the valves are used to position the Drives at either or both extreme positions




FIGURE 17 - Control Drive with Strip Heater

of the Drive, that is, full open or full closed. A drawing of the Solenoid Valve Assembly is included elsewhere in this Instruction Book if the Valves are furnished with the Drive.

Heating Elements

Refer to Figure 17. For operating in out door applications, heating elements are available for installation within the Drive enclosure. Heating elements are recommended for ambient temperatures remaining below 32°F for extended periods. A thermostat automatically maintains the temperature at approximately 45°F.

Alarm Contacts

Electrical contacts are available to actuate alarm devices or to indicate the piston position for control purposes. A description of electrical contacts for the specific Control Drive is given on the applicable Specification.

Sheet in front of this Instruction Book. A drawing of the applicable switch assembly, if provided, is included elsewhere in this Instruction Book.

Air Failure Brake

Figure 18 shows the Air Failure Brake in automatic position (operating lever at AUTO) and full air supply pressure available to Control Drive.

In this position the air supply bellows is expanded causing the trigger lever to engage with the brake set lever. The tripping lever holds the two brake levers apart so they can not clamp onto the brake rod, thus the Control Drive is free to operate automatically.

In case of a supply air pressure failure with the operating lever in AUTO, the air supply bellows contracts and pulls the trigger lever out of engagement with the brake set lever. The




FIGURE 18 - Schematic of Air Failure Brake

brake set lever spring pulls the brake set lever and shaft counterclockwise, causing the tripping lever to release the brake levers so that they clamp onto the brake rod. The Control Drive is locked in position. Also, the brake set lever has opened the by-pass valve so that the pressure on both sides of the Control Drive piston cylinder is equal.

If a remote signal contact is furnished, air failure will cause the remote reset lever to close the contact. This lights a remote signal lamp to denote that the Brake is locked or that the Control Drive is on HAND.

After an air failure, the Control Drive may not be operated automatically again until the Brake has been reset, even though full supply air pressure is restored. The Brake may be reset manually with the operating lever with the pneumatic remote reset mechanism, if furnished.

When the operating lever is in the RESET position, the operating lever shaft gear has moved the reset shaft gear so that the manual reset cam has contacted the lower end of the brake set lever. This moves the brake set lever and shaft clockwise and raises the brake so that it may engage with the trigger lever. At the same time, the reset shaft gear has turned so that the manual brake cam has spread the brake levers apart, and the tripping lever falls between the brake levers. Also, the brake set lever releases the by-pass valve so that the valve closes, and the remote reset lever allows the remote contact to open turning off the remote signal lamp.

If full air supply pressure has been resumed so that the air supply bellows is extended when the operating lever is in the RESET position, the trigger lever will engage with the brake set lever. Then when the operating lever has been turned to AUTO, the Brake is reset and the Control Drive may be operated automatically. However, if full supply air pressure has not been resumed, the trigger and brake reset levers will not engage and the brake

levers will clamp onto the brake rod again when the operating lever is turned to AUTO.

The Brake may be reset from a remote point if a remote release mechanism is furnished. With the operating lever in AUTO position, air supply is applied under the remote reset piston when the remote release push button is open (held in). This causes the piston, piston rod cylinder and piston rod to move up. The piston rod turns the remote reset shaft so that the remote reset cam has contracted the lower end of the remote reset lever. This moves the brake set lever and shaft clockwise and raises the brake set lever so that it may engage with the trigger lever. Further action of the various levers and cams is the same as noted above for the RESET position of the operating brake cam. When the release push-button has been closed (released), the air pressure under the remote reset piston will bleed off so that the piston will resume its normal position at the bottom of the cylinder.

The Control Drive may be operated manually only if the Brake operating lever is in the MANUAL position and the Control Drive Positioner supply valve has been turned to HAND CLOSED (for the air supply has failed) so that the air supply is cut off and the air supply bellows has contracted. The Positioner by-pass valve, also, may be in its OPEN-HAND position at this time if desired.

When the Brake operating lever is in its MANUAL position, the lever shaft gear has turned the reset shaft gear so that the manual brake cam has spread the brake levers apart to free the brake rod. The brake set and remote reset levers remain in such a position, however, as to hold the by-pass valve open and the remote contact closed.

When the operating lever is in LOCK position, the brake levers are clamped onto the brake rod, the trigger lever is disengaged from the brake set lever, and the brake set and remote reset levers hold the by-pass valve open and the remote contact closed.

ROUTINE MAINTENANCE

1. Periodically check all air connections (while under pressure) for leakage with a soap-suds solution.

2. Maintain an air supply free of dirt, oil, or moisture.

3. Lubricate Drive shaft bearings (thru lubricating fittings) with a light grease at least once a year. To lubricate Drives with casings, remove top cover for access to fittings.

4. Apply penetrating oil to clevis pin and Drive stand pin areas to prevent the pins from freezing in the assembly. Frequency of this lubrication depends upon the operating conditions of each Drive.

5. For Control Drives equipped with an Air Failure Brake, whenever Drive is out of service, or at least once a year, test Air Failure Brake to make sure that it is working properly.

6. At least once a year, clean Positioner pilot valve stem and inner liners with a common solvent as follows

a. Lock Drive in position using hand lock lever.

b. Turn supply valve on Positioner to HAND-CLOSED position.

c. Remove pilot stem retaining spring from bottom of fixed pilot cap carefully to avoid bending spring (Figure 8). Remove pilot stem.

d. Remove fixed pilot cap and catch valve liners and spring. If valve liners stick in valve body, tap side of body to jar loose. If liners still stick in valve body, remove adjustable pilot cap and lock nut as a unit to avoid disturbing their positions relative to each other. Then push liners out with a pencil. Never use a metal rod

e. Clean liners and stem with solvent. Do not use files, reamers, or abrasives on stems or liners.

f. If adjustable pilot cap and locknut were removed, replace and turn assembly by hand until locknut is tight against pilot body. Replace two upper liners, spring, and two lower liners in valve block.

g. Replace fixed pilot cap and tighten hand tight against valve body. Replace pilot stem spring.

7. If Positioner supply and by pass valves begin to stick, remove valve as noted below and lubricate with Bailey Petcock Lubricant (Part No 19987-1). Lubricate the valve at least once a year. To remove valve, turn nut (Figure 8) out of pilot valve body without changing the position of the handle.

NOTE The valves are not interchangeable, either with each other or other Positioner valves. The valves and valve bodies are marked "1" and "2" to prevent mixup in reassembly.

8. Annually check filters in pilot valve body (Figure 21), replace if necessary.

9. Check Positioner and Control Drive adjustment annually.

10. Completely disassemble and clean Control Drive every year or two. Refer to "Corrective Maintenance", below.

11. Change grease in Positioner gear case once every two or three years. Remove Positioner from Drive (as noted in Figure 1) and fill case half full with Vulcanlube, Grade No. 1, supplied by C. H. Clark Oil Company of Cleveland, Ohio. Rotate gears to work grease into teeth.

CORRECTIVE MAINTENANCE

Removing Casing Access Panels

1. For Control Drives with casings, only the end access panels (Figure 2) are removable. To remove either of the panels.

a. Remove casing cover.

b. With one hand on each casing latch spring and with thumbs on outside of panel to hold it firm, push down on both springs until panel gives way easily.

c. Lift unlatched panel away from bottom of stand.

Type AC0608□□A Control Drive

Cylinder Diameter, Inches	Piston Stroke, Inches	Positioner Pilot Size, Inches	Supply Pressure, psig	Maximum Torque, *Ft. lbs.	Time for Full Piston Travel (Normal), *Seconds	Time for Full Piston Travel with 040" Orifice, *Seconds
6	8	1/8	40	280	12.0	25.0
6	8	1/8	50	400	10.0	25.0
6	8	3/16	40	280	6.0	25.0
6	8	3/16	50	400	5.0	25.0

*No Load

Table 3 - Control Drive Torque and Speed Control Data for Type AC0608□□A Control Drive

2. To replace panel, insert panel in bottom of stand and snap top of panel in place.

Removing Piston and Cylinder Assembly

1 Refer to Figure 1. Remove access panels from Drive casings outlined above (It is not necessary to remove side panels)

2 Disconnect air lines from top and bottom of cylinder.

3. Remove pin assembled thru piston clevis and Drive lever

4. Remove pin attaching cylinder to Drive stand and lift assembly out of stand.

Servicing Cylinder Assembly

1. Thoroughly clean piston and inside of cylinder. Then apply a coating of Molykote powder mixed to a thin paste with mineral oil to cylinder walls. Apply Vulcanlube Grade No 1 around outside surface of piston cup leathers. After assembly, apply 2 ounces of clear mineral oil to cylinder walls

NOTE The purpose of the lubricant is to protect the inside wall of the cylinder from rusting. The piston cup leathers are impregnated with a high temperature wax. This wax seals pores in the leather making them air tight and sealing the leather against oil and other liquids which do not act as solvents for the wax. Therefore, do not attempt to make cup leathers soft and more pliable. Replace leathers if they become hard and brittle and begin to crack

2 If, between overhaul periods, there is reason to believe that piston leathers are sticking to the cylinder wall causing jerky operation, or air is escaping from either side of the piston, remove 1/8 inch pipe plug from top flange and

spray a light mineral oil around inside of cylinder wall. Use a white mineral oil or liquid petrolatum. To perform this operation, transfer the Drive to manual operation and lock the Drive in position with piston at bottom of cylinder.

Removing Air Failure Brake Assembly

1. Refer to Figure 18. Set Brake operating lever in MANUAL position.

2. Remove all tubing connections at Brake and disconnect any wiring

3. Remove nut from bottom of brake rod.

4. Whichever is easier, either remove clevis pin inserted thru brake rod clevis and drive lever (so that brake rod is disassembled from Drive), or position Drive with piston all the way to bottom of cylinder so that brake rod may be swung out when Brake has been dismounted from stand.

5. Remove Brake operating lever handle. Disassemble bearing at each end of operating lever shaft. Remove right-hand bearing and slide left hand bearing out along shaft. Lift Brake thru slots in mounting brackets and slide Brake off brake rod.

6. To reassemble, perform the above disassembly steps in reverse order

Recalibration of Drive and Positioner

If the Control Drive has undergone complete maintenance and disassembly, it will be necessary to readjust the Drive in relation to the Positioner as outlined in steps 1 thru 13 below. This procedure will restore the Drive and Positioner to their original factory calibration. It may then be necessary to readapt the Drive to its particular application as described under 'Service Adjustments', page 12.

Refer to Figure 8 The adjustments below are based on the direct loading arrangement shown in Figure 16 (If the Drive is arranged for reverse loading, its movements and positions are opposite from those for direct loading applications) For direct loading application the position indicator normally SHUT when the piston is at the bottom of the cylinder and OPEN when the piston is at the top The words OPEN and SHUT used below refer to these positions Check these adjustments with linkage to the driven device disconnected from the Drive

1 Use B, straight line, positioning cam, shipped in place in the Positioner

2 Make supply air and control loading pressure connections to Drive at bottom of Drive stand (see Figures 1, 2, and 3). Refer to Table 3 for correct supply air pressure for the specific Drive.

3 Make certain that fixed pilot cap (Figure 8) is tightened securely and that the adjustable pilot cap and lock nut are screwed up tight, with one finger of the locknut engaged in a groove in the cap. If adjustable cap becomes unlocked or if pilot valve stem or pilot valve has been disassembled, refer to step 13 before proceeding with adjustment checks

4. Turn supply valve (Figure 6) to AUTO OPEN and by pass valve to CLOSED AUTO Set the control loading pressure at zero psig. Piston should move to SHUT position

5. If cam follower roller does not contact positioning cam at zero mark on cam with piston in SHUT position, disconnect Positioner drive rod and turn rod into or out of ball joint at either end of rod until Positioner drive arm assumes the position which places the follower exactly on zero mark Reconnect drive rod.

6. Set input loading pressure at 3 psig. Piston should remain in its SHUT position If piston begins to move away from its SHUT position, turn zero adjustment nut (Figure 8) clockwise (in half turn increments) to increase tension of positioning spring until piston just remains to SHUT position

7. Increase loading pressure to 3.5 psig Piston should begin to move away from shut position within 10 to 15 seconds If not, turn zero adjustment nut counterclockwise (in half turn increments) to decrease tension of positioning spring. Repeat steps 6 and 7 until correct results are obtained

NOTE for best operating results, when cam follower is at zero on cam, distance between top of spring beam, both at marks 1 and 5, and center of spring pivot on balance beam should be 4 1/2 inches, $\pm 1/16$ inch. Although this dimension is not critical, it is suggested that steps 5, 6, and 7 be repeated until dimension has been obtained. However, if any material has been removed from cam at zero point, it will be impossible to obtain this dimension

8 With Drive zero adjustment set properly (steps 5, 6, and 7) and 3 psig applied to loading bellows, balance beam should be mid way between balance beam stop If not, reset the stop to correct position

9 Set input loading pressure at maximum range value (15 or 27 psig). If piston does not move to its full OPEN position loosen clamp screw of range adjustment and move adjustment along spring beam until piston reaches OPEN position. Lock adjustment in place.

10. Decrease loading pressure to 14.5 or 26.5 psig Piston should move away from its OPEN position within 10 to 15 seconds If not, readjust range adjustment (step 7) to obtain correct result.

11 Set loading pressure at midrange value (9 or 15 psig) Piston should move to its mid travel position. If not, adjust pilot stem adjustment until piston position is correct.

12. Repeat steps 6 thru 11 until piston positions at minimum, maximum, and midrange loading pressures are correct

13. If adjustable pilot cap becomes unlocked or if pilot valve stem or liners are changed, valve ports on liners must be realigned with lands on pilot stem as outlined below (the following assumes that B cam is installed in Positioners)

a. Turn off supply air to Positioner Remove pipe plug at top of piston cylinder (Figure 19), and mount an accurate pressure gage in pipe plug hole.

b Set Positioner by pass valve to CLOSED-AUTO position and set the supply valve for OPEN AUTO position with hand lock lever in AUTO position

c. Make certain fixed pilot cap is tight and secured securely.

d. Apply midrange loading pressure (9 or 15 psig) to loading bellows. Pressure gage in cylinder should read within ± 2 psig of one half supply pressure (25 psig if supply pressure is 50 psig). If gage reading is in correct, disengage the finger of the locknut that is in place in the groove of the adjustable pilot cap (Figure 8). Adjust the pilot cap until gage reads on half supply pressure. Turn lock nut down on adjustable cap until it is tight

against the pilot valve body then engage one of the locknut fingers in line with a corresponding groove in the adjustable pilot cap

e. Remove pressure gage and place plug in tapped hole in cylinder

f. Repeat steps 1 thru 12 to check Positioner adjustments

REPLACEMENT PARTS

Spare Parts Kits

The Spare Parts Kits shown in Figures 19 thru 26 should be carried in stock. Specify the Spare Parts Kit part number to order a complete kit.

Ordering Individual Parts

Figures 19 thru 26 are Parts Drawings of the Control Drive, Type AC0608□□A. Normally, these Drawings apply to the Drive furnished. However, there may be individual differences in specific Drives because of

a. design changes made since the printing of this Instruction Section, or

b. special design of the Drive to make it suitable for a special application

Therefore, when ordering parts, assure receipt of correct replacements by specifying the complete nomenclature and Serial Number (stamped on instrument nameplate) of the Drive for which parts are desired




FIGURE 21 Parts Drawing P92 11, Positioner Part No 5311450 □

Type AC0608□□□ Control Drive

ITEM	PART NO.	NAME	ITEM	PART NO.	NAME	ITEM	PART NO.	NAME
	CODE LABEL	QIVE NO ON LABEL	30	531143	ADJUST NG NUT	65	SEE TABLE	P LOT VALVE ASSY NCL
		WHEN ORDERING PIS	31	53 1438 1	EYE BOLT	65	53102 1	CAP FOR 3 PILOT VALVE
2	4	TEE SEE TABLE	32	53 44 1	ADJUST NG P VOT	65	53 18 5	CAP FOR 6 P LOT VALVE
		*SPRING SUPPORT	33	SEE TABLE	SPRING	65	53118 2	VALVE SEAT 2 REQ FOR 3 PILOT V
1	33 108 *	LEVER	35	SEE TABLE	STRAIGHT LINE CAM B	65B	53118 1	VALVE SEAT 2 REQ FOR 3 PILOT V
	6 52 1 2	F L HD STN STL SCR	36	53 1432 1	CAM HB	65C	53118 1	SLEEVE 2 REQ FOR 3 PILOT V NLY
	53 54	TUR ASSY SEE TABLE	4	53 408	CAM SHOT 2 P NCLN	66	53 1426	PILOT VALVE SPO
7	1 323 3	EXT STN STL SEMS 11 REQD	38	53 4 1	SPRING RETA NER	65E	53114 6	VALVE BODY
8	197227	SPECIAL HEX HD S R	39	531144 1	P LOT BEAM SPRING	65F	53648 1	CAP LOCK NUT
			40	53 875	SPRING RETA NER	65G	53 448	ADJ CAP
11	531168 1	POSITIONER DR ARM	41	5 16 18	HEX JAM STN STL NUT	66	10 32 3	EXT HD STN STL SEMS 3 REQD
	53 1810	SPEED CONTROL WASH	42	81165	NET SCR WASH	67	53 1 9	FILTER CAP 3 REQ
12	5 172 1 1	PILOT STEM GASKET	43	147164 37	RETAINING RING	68	53114 38 1	O RING GASKET 3 REQ
13	3 304	SEALING STRIP	44	53 1452 1	BELLOWS & TUBE ASSY	69	5311802	CONN PLUG 2 REQ
	53 407 1	COVER ASSY NCL	45	SEE TABLE	SQUARE CAM	70	5311408 2	L RING GASKET 3 REQ
14A	53 408	CUVFR	46	SEE TABLE	SQUARE ROOT CAM A	71	53218 39	FIL WASH & DISC ASSY 3 REQ
4B	53 1406 1	COVER SCR 2 REQ	47	5312314 1	REAR BRG COVER INCL	72	53130 6	F LTER CLIP 3 REQ
14C	98 73 6	RET RING 2 REQ	47A	5312313	GIL SEAL	73	5311417 1	FILTER SPR 3 REQ
	6 3245 16	RD HD STN STL SCREW 2 REQD	47B	5311421 2	NEEDLE BEAR NG	74	1/8 2 NPT	Q HD STD BRASS PIPE PL G
15	53 50 63	PLAIN STN STL WASH 2 REQD	5	SEE TABLE	NAMEPLATE	75	300 1	BALLY PLT COA LUBRICANT
	53 50 63	V HANDLE 2 REQ	52	NO WKL 5	RD HD STN STL THD FORM NG	76	SEE TABLE	BACKPLATE ASSY
19	53 1416	P LOT BEAM ASSY	53	NO 1 4 20	SCR TYPE L 4 REQD			
20	5311458 1	PILOT STEM SPRING	54	0 32x7 8	EXT RD HD SEMS STN STL			
2	1 4 703 5	RD HD STN STL SCREW 2 REQD	54	5318543 1	SP CAM MTG BRKT			
22	5311451 1	PILOT STEM ADJ SCR	56	10 32	HEX STN STL NUT			
	5312016 1	SEALING TUBE	58	5311070 1	TORS ON SPRING			
25	53 433	GEAR & SHAFT ASSY	59	5315164 1	SPRING			
26	SEE TABLE	P LOT STEM	60	53 2 8 2	LATCH			
27	53 1423 1	SPO BEAM ASSY INCL	61	4804 09 0 4102	SHK LR WASH STN STL 2 REQD			
27A	5311444 1	COMPO BRG 2 REQ	62	1531187 1	ELBOW			
3 B	53 1425 1	CAM ROLLER	63	SEE TABLE	PILOT V & BLK ASSY NCL			
* C	197184 15	RET RING 2 REQ	64	SEE TABLE	PILOT V BLK ASSY INCL			
* D	53 1446	CAM ROLLER PIN	64	SEE TABLE	PILOT V BLK ASSY INCL			
38	5311457 1	P LOT BEAM STOP	*A4	53 1401 1	VALVE NIT 2 REQ			
39	NO R 0 10	SHK LR WASH STN STL	64B	5311402 1	SPRING 2 REQ			

TABLE OF VARIABLE PARTS*


Plus the nr Part No.	USUAL USE	PILC SIZE	CAM STROKE	RANGE PSI	ITEMS 2 6 & 8B	ITEM 76	ITEM 26*	ITEM 33	ITEM 35	ITEM 45	ITEM 46	ITEM 51	ITEM 63	ITEM 64	ITEM 65
3 1450 1	DRIVE	1 8	FULL	3 27 or 5 25	OMIT	5311412 1	5311439 1	5311444 1	5311446 1	531 341	5311440 1	196900 1	5311597 1	5316050 1	53 4870
53 450 2	VALVE	1 8	HALF	3 27 or 5 25	1 REQ	5311412 1	5311439 1	5311444 1	5311796 1	5311768 1	5312226 1	196900 2	5311597 2	5316050 2	5314870
531 490 3	DRIVE	3 16	FULL	3 27 or 5 25	OMIT	531 412 1	5311827 1	5311844 1	5311448 1	5311314	53 1440 1	196900 3	5311597 3	5316050 3	5314880
53 490 4	DRIVE	1 8	FULL	3 15	OMIT	5311412 1	5311439 1	5318767 1	5311440 1	53 124 1	53 1440	196900 4	5311597 4	5316050 4	5314870
5311450 5	VALVE	8	HALF	3 15	1 REQ	53 1412 5	53 439	5318767 1	5311799 1	5311789 1	5312226 1	196900 5	53 1387 2	5316050 5	5314870 1
53 450 6	DRIVE	3 16	FULL	3 15	OMIT	53 1412 1	5311827 1	5318767 1	5311448 1	53 34	531 449	196900 6	5311597 3	5316050 6	534880 1
531145 7	DRIVE	8	FULL	3 27 or 5 25	OMIT	5311412 1	5314747 1	5311444 1	53 448 1	5311314 1	5311440 1	196900 7	5311597 4	5316050 7	5314870 1
531 450 8	DRIVE	1 8	HALF	3 15	1 REQ	53 1412 1	53 439	5318767 1	5311799 1	5311789 1	5312226 1	196900 8	5311597 5	5316050 8	5314870 1
* 1450 9	VALVE	3 16	BLANK	3 27 or 5 25	1 REQ	5311412 1	5311827 1	5311444 1	5320076 1	53200 8	5320076	196900 9	5311597 6	5316050 9	5314880
5311450 11	**	1 8	HALF	3 27 or 5 25	1 REQ	5311412 1	5311439 1	5311444 1	5311799 1	531 708	53 2226	196900 10	5311597 7	5316050 10	53 4870
5311450 12	VALVE	8	FULL	3 27 or 5 25	1 REQ	5311412 1	531 439	53 444	5311448	5311841 1	5311440 1	196900 11	5311597 8	5316050 11	5314880
531 450 13	VALVE	1 8	FULL	3 15	1 REQ	531 412 1	5311439 1	5318767 1	5311446 1	5311541 1	5311440 1	196900 12	5311597 9	5316050 12	5314870 1
5311450 14	DRIVE	1 8	FULL	3 15	OMIT	5321898 *	5314747 1	5316767 1	53 1448 1	531134	53 440 1	196900 13	5311597 10	5316050 13	53 4870
5311450 15	DRIVE	8	FULL	3 27 or 5 25	CM T	5321897 1	5314747 1	5321 444 1	5311446 1	5311241	5311448 1	196900 14	5311597 11	53 4050	5314870 1

SPARE PARTS KITS

KIT NO 75600													KIT NO 25600 2						KIT NO 25600 3					
FOR POSITIONER PART NOS 5311450 1 2 4 5 12 13													FOR POSITIONER PART NOS 5311450 3 6 9 10						FOR POSITIONER PART NOS 531 450 7 8 14 15					
1 8 PILOT SIZE													3 16 PILOT SIZE						1 8 PILOT SIZE					
QUANT Y	ITEM NO SEE NOTE 1												QUANT Y	ITEM NO SEE NOTE 1					QUANT Y	ITEM NO SEE NOTE				
1 EACH	20 45 4 15 4 10 54 94 70 236 80 3 7												1 EACH	U 45 4 15 4 10 54 94 70 236 80 3 7					2 EACH	27C 65B 65C				
2 EACH	33 SEE NOTE 2												2 EACH	33 SEE NOTE 2					2	33 SEE NOTE 2				
1 EACH	68 70 71 7												2 EACH	68 70 71 7					2 EACH	68 70 71 7				

- NOTES
 1 WHERE THE ITEM SPECIFIED IS A VARIABLE PART THE PART APPL CABLE TO THE POS TIONER LISTED IS INCLUDED IN KIT
 2 KIT INCLUDES RANGE SPRING 531 444 1 FCR 5 25 or 3 27 PSIG AND 5318767 1 FOR 3 15 PSIG)
 * FOR PISTON OPERATED VALVES SUBSTITUTE ITEM 5314747 1 FOR ITEM 5311439 1 IF HUNTING CYCLE OCCURS
 **DUAL OPERATOR
 ***SEE P LOT 5 26 COLUMN IN TABLE FOR APPLICABLE P LOT VALVE SIZE


List of Parts for Parts Drawing P92-11



ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	301795	CONTROL UNIT, TYP. ASSY	23	34 1/4 112	STRIP, RETAIN RING	19	301790	HAND OPER. LEVER
2	301796	STRIP, RETAIN RING	24	34 1/4 112	STRIP, RETAIN RING	20	301791	STRIP, RETAIN RING
3	301797	STRIP, RETAIN RING	25	34 1/4 112	STRIP, RETAIN RING	21	301792	STRIP, RETAIN RING
4	301798	STRIP, RETAIN RING	26	34 1/4 112	STRIP, RETAIN RING	22	301793	STRIP, RETAIN RING
5	301799	STRIP, RETAIN RING	27	34 1/4 112	STRIP, RETAIN RING	23	301794	STRIP, RETAIN RING
6	301800	STRIP, RETAIN RING	28	34 1/4 112	STRIP, RETAIN RING	24	301801	STRIP, RETAIN RING
7	301801	STRIP, RETAIN RING	29	34 1/4 112	STRIP, RETAIN RING	25	301802	STRIP, RETAIN RING
8	301802	STRIP, RETAIN RING	30	34 1/4 112	STRIP, RETAIN RING	26	301803	STRIP, RETAIN RING
9	301803	STRIP, RETAIN RING	31	34 1/4 112	STRIP, RETAIN RING	27	301804	STRIP, RETAIN RING
10	301804	STRIP, RETAIN RING	32	34 1/4 112	STRIP, RETAIN RING	28	301805	STRIP, RETAIN RING
11	301805	STRIP, RETAIN RING	33	34 1/4 112	STRIP, RETAIN RING	29	301806	STRIP, RETAIN RING
12	301806	STRIP, RETAIN RING	34	34 1/4 112	STRIP, RETAIN RING	30	301807	STRIP, RETAIN RING
13	301807	STRIP, RETAIN RING	35	34 1/4 112	STRIP, RETAIN RING	31	301808	STRIP, RETAIN RING
14	301808	STRIP, RETAIN RING	36	34 1/4 112	STRIP, RETAIN RING	32	301809	STRIP, RETAIN RING
15	301809	STRIP, RETAIN RING	37	34 1/4 112	STRIP, RETAIN RING	33	301810	STRIP, RETAIN RING
16	301810	STRIP, RETAIN RING	38	34 1/4 112	STRIP, RETAIN RING	34	301811	STRIP, RETAIN RING
17	301811	STRIP, RETAIN RING	39	34 1/4 112	STRIP, RETAIN RING	35	301812	STRIP, RETAIN RING
18	301812	STRIP, RETAIN RING	40	34 1/4 112	STRIP, RETAIN RING	36	301813	STRIP, RETAIN RING
19	301813	STRIP, RETAIN RING	41	34 1/4 112	STRIP, RETAIN RING	37	301814	STRIP, RETAIN RING
20	301814	STRIP, RETAIN RING	42	34 1/4 112	STRIP, RETAIN RING	38	301815	STRIP, RETAIN RING
21	301815	STRIP, RETAIN RING	43	34 1/4 112	STRIP, RETAIN RING	39	301816	STRIP, RETAIN RING
22	301816	STRIP, RETAIN RING	44	34 1/4 112	STRIP, RETAIN RING	40	301817	STRIP, RETAIN RING
23	301817	STRIP, RETAIN RING	45	34 1/4 112	STRIP, RETAIN RING	41	301818	STRIP, RETAIN RING
24	301818	STRIP, RETAIN RING	46	34 1/4 112	STRIP, RETAIN RING	42	301819	STRIP, RETAIN RING
25	301819	STRIP, RETAIN RING	47	34 1/4 112	STRIP, RETAIN RING	43	301820	STRIP, RETAIN RING
26	301820	STRIP, RETAIN RING	48	34 1/4 112	STRIP, RETAIN RING	44	301821	STRIP, RETAIN RING
27	301821	STRIP, RETAIN RING	49	34 1/4 112	STRIP, RETAIN RING	45	301822	STRIP, RETAIN RING
28	301822	STRIP, RETAIN RING	50	34 1/4 112	STRIP, RETAIN RING	46	301823	STRIP, RETAIN RING
29	301823	STRIP, RETAIN RING	51	34 1/4 112	STRIP, RETAIN RING	47	301824	STRIP, RETAIN RING
30	301824	STRIP, RETAIN RING	52	34 1/4 112	STRIP, RETAIN RING	48	301825	STRIP, RETAIN RING
31	301825	STRIP, RETAIN RING	53	34 1/4 112	STRIP, RETAIN RING	49	301826	STRIP, RETAIN RING
32	301826	STRIP, RETAIN RING	54	34 1/4 112	STRIP, RETAIN RING	50	301827	STRIP, RETAIN RING
33	301827	STRIP, RETAIN RING	55	34 1/4 112	STRIP, RETAIN RING	51	301828	STRIP, RETAIN RING
34	301828	STRIP, RETAIN RING	56	34 1/4 112	STRIP, RETAIN RING	52	301829	STRIP, RETAIN RING
35	301829	STRIP, RETAIN RING	57	34 1/4 112	STRIP, RETAIN RING	53	301830	STRIP, RETAIN RING
36	301830	STRIP, RETAIN RING	58	34 1/4 112	STRIP, RETAIN RING	54	301831	STRIP, RETAIN RING
37	301831	STRIP, RETAIN RING	59	34 1/4 112	STRIP, RETAIN RING	55	301832	STRIP, RETAIN RING
38	301832	STRIP, RETAIN RING	60	34 1/4 112	STRIP, RETAIN RING	56	301833	STRIP, RETAIN RING
39	301833	STRIP, RETAIN RING	61	34 1/4 112	STRIP, RETAIN RING	57	301834	STRIP, RETAIN RING
40	301834	STRIP, RETAIN RING	62	34 1/4 112	STRIP, RETAIN RING	58	301835	STRIP, RETAIN RING
41	301835	STRIP, RETAIN RING	63	34 1/4 112	STRIP, RETAIN RING	59	301836	STRIP, RETAIN RING
42	301836	STRIP, RETAIN RING	64	34 1/4 112	STRIP, RETAIN RING	60	301837	STRIP, RETAIN RING
43	301837	STRIP, RETAIN RING	65	34 1/4 112	STRIP, RETAIN RING	61	301838	STRIP, RETAIN RING
44	301838	STRIP, RETAIN RING	66	34 1/4 112	STRIP, RETAIN RING	62	301839	STRIP, RETAIN RING
45	301839	STRIP, RETAIN RING	67	34 1/4 112	STRIP, RETAIN RING	63	301840	STRIP, RETAIN RING
46	301840	STRIP, RETAIN RING	68	34 1/4 112	STRIP, RETAIN RING	64	301841	STRIP, RETAIN RING
47	301841	STRIP, RETAIN RING	69	34 1/4 112	STRIP, RETAIN RING	65	301842	STRIP, RETAIN RING
48	301842	STRIP, RETAIN RING	70	34 1/4 112	STRIP, RETAIN RING	66	301843	STRIP, RETAIN RING
49	301843	STRIP, RETAIN RING	71	34 1/4 112	STRIP, RETAIN RING	67	301844	STRIP, RETAIN RING
50	301844	STRIP, RETAIN RING	72	34 1/4 112	STRIP, RETAIN RING	68	301845	STRIP, RETAIN RING
51	301845	STRIP, RETAIN RING	73	34 1/4 112	STRIP, RETAIN RING	69	301846	STRIP, RETAIN RING
52	301846	STRIP, RETAIN RING	74	34 1/4 112	STRIP, RETAIN RING	70	301847	STRIP, RETAIN RING
53	301847	STRIP, RETAIN RING	75	34 1/4 112	STRIP, RETAIN RING	71	301848	STRIP, RETAIN RING
54	301848	STRIP, RETAIN RING	76	34 1/4 112	STRIP, RETAIN RING	72	301849	STRIP, RETAIN RING
55	301849	STRIP, RETAIN RING	77	34 1/4 112	STRIP, RETAIN RING	73	301850	STRIP, RETAIN RING
56	301850	STRIP, RETAIN RING	78	34 1/4 112	STRIP, RETAIN RING	74	301851	STRIP, RETAIN RING
57	301851	STRIP, RETAIN RING	79	34 1/4 112	STRIP, RETAIN RING	75	301852	STRIP, RETAIN RING
58	301852	STRIP, RETAIN RING	80	34 1/4 112	STRIP, RETAIN RING	76	301853	STRIP, RETAIN RING
59	301853	STRIP, RETAIN RING	81	34 1/4 112	STRIP, RETAIN RING	77	301854	STRIP, RETAIN RING
60	301854	STRIP, RETAIN RING	82	34 1/4 112	STRIP, RETAIN RING	78	301855	STRIP, RETAIN RING
61	301855	STRIP, RETAIN RING	83	34 1/4 112	STRIP, RETAIN RING	79	301856	STRIP, RETAIN RING
62	301856	STRIP, RETAIN RING	84	34 1/4 112	STRIP, RETAIN RING	80	301857	STRIP, RETAIN RING
63	301857	STRIP, RETAIN RING	85	34 1/4 112	STRIP, RETAIN RING	81	301858	STRIP, RETAIN RING
64	301858	STRIP, RETAIN RING	86	34 1/4 112	STRIP, RETAIN RING	82	301859	STRIP, RETAIN RING
65	301859	STRIP, RETAIN RING	87	34 1/4 112	STRIP, RETAIN RING	83	301860	STRIP, RETAIN RING
66	301860	STRIP, RETAIN RING	88	34 1/4 112	STRIP, RETAIN RING	84	301861	STRIP, RETAIN RING
67	301861	STRIP, RETAIN RING	89	34 1/4 112	STRIP, RETAIN RING	85	301862	STRIP, RETAIN RING
68	301862	STRIP, RETAIN RING	90	34 1/4 112	STRIP, RETAIN RING	86	301863	STRIP, RETAIN RING
69	301863	STRIP, RETAIN RING	91	34 1/4 112	STRIP, RETAIN RING	87	301864	STRIP, RETAIN RING
70	301864	STRIP, RETAIN RING	92	34 1/4 112	STRIP, RETAIN RING	88	301865	STRIP, RETAIN RING
71	301865	STRIP, RETAIN RING	93	34 1/4 112	STRIP, RETAIN RING	89	301866	STRIP, RETAIN RING
72	301866	STRIP, RETAIN RING	94	34 1/4 112	STRIP, RETAIN RING	90	301867	STRIP, RETAIN RING
73	301867	STRIP, RETAIN RING	95	34 1/4 112	STRIP, RETAIN RING	91	301868	STRIP, RETAIN RING
74	301868	STRIP, RETAIN RING	96	34 1/4 112	STRIP, RETAIN RING	92	301869	STRIP, RETAIN RING
75	301869	STRIP, RETAIN RING	97	34 1/4 112	STRIP, RETAIN RING	93	301870	STRIP, RETAIN RING
76	301870	STRIP, RETAIN RING	98	34 1/4 112	STRIP, RETAIN RING	94	301871	STRIP, RETAIN RING
77	301871	STRIP, RETAIN RING	99	34 1/4 112	STRIP, RETAIN RING	95	301872	STRIP, RETAIN RING
78	301872	STRIP, RETAIN RING	100	34 1/4 112	STRIP, RETAIN RING	96	301873	STRIP, RETAIN RING


91 25. Type AC0608PDA Control Drive and Stand Assembly

NOTES
 1. FOR DETAILS OF AIR CELL REFER TO A 608PDA
 2. SEE PART DRAWING P. 2
 3. FOR PART NUMBER AND OF TABLES REFER TO PUNTLINER
 4. SEE PARTS DRAWING NO. P92 II
 5. FOR DETAIL OF CAS. 4, ASSEMBLY SEE PARTS
 DRAWING NO. 26



ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	1943002	1 STRIP HEATER	9	194958	3 TERMINAL STRIP	15	C1 79 102	1 TINNERMAN SPEED NUT FLAT TYPE 3 REQD
2	5316458	2 SPACE SLEEVE 2 REQD	10	194928	1 FIBER BUSHING 2 REQD	16	1941401	3 SOLDERLESS TERMINAL
3	10 32x1	1 2 RD HD THD CUTTING SCR 2 REQD	11	82x8	4 RD HD SHEET METAL SCREW 2 REQD	17	5318366	10 FIBER GLASS INSULATION 8 3 REQD
4	NO 10	3 WASHER 3 REQD	12	R4524 0015	B M CO NO 11 CONDUIT 15 REQD	18	82x1	RD HD SHEET METAL SCREW 2 REQD
5	5316459	1 TUBE CLAMP PLATE	13	R2041 0250	B M CO NO 59 LEAD WIRE 4 REQD	19	6012345	1 DESIGNATION PLATE ASSEMBLY
6	195105	10 TUBE CLAMP 3 REQD	14	C1778 82	1 TINNERMAN SPEED NUT FLAT TYPE 4 REQD			
7	102x5	8 RD HD SHEET METAL SCREW 3 REQD						
8	662460	1 THERMOSWITCH						



FIGURE 23 - Parts Drawing P81-39, Strip Heater



ITEM	PART NO	DESCRIPTION
1	CODE LABEL	SPECIFY NUMBER WHEN ORDERING PARTS
2	535751 1	BODY
3	535199 1	VALVE ASSEMBLY
4	53016 1	COVER
5	535744 1	GASKET
6	19783 1	NUT
7	532488 1	GUIDL W ASHER
8	5313010 1	VALVE NUT
9	192179 1	BELLOWS
10	53710 2	WASHER
11	53736 1	SPACER
12	5313009 2	PUSH ROD
13	53211 1	ADAPTER WASHER (WITHOUT BLEED)
	53211 3	ADAPTER WASHER (WITH BLEED)
14	195158 1	CONNECTOR NUT
15	#1224 00	SHAKEPROOF LOCKWASHER
16	5313012 1	SPECIAL NUT
17	531311 1	PUSHBUTTON
18	8 32	HEX NUT
19	195158 2	CONNECTOR NUT 2 REQD
20	8 32 x 3, 8	ROUND HEAD SCREW, 4 REQD
21	19734 33	WASHER

FIGURE 24 Parts Drawing P99 116, Pushbutton, Part No 5315129 □

Type AC0608□□A Control Drive



ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	1961056	1 CODE LABEL	25	1206-00	CAD PLT STL SHKPRF LOCK WASHER 2 REQD	47	5312594	1 TRIGGER SPRING
2	5312598	1 SUPPORT PLATE				48	5312133	1 TRIGGER LEVER & PIVOT ASSY
3	5311774	1 DRIVING GEAR	40	1 8x1 4	1 TYPE 1 GROOVE PIN	49	5312619	1 PISTON FOLLOWER ASSY
4	197120	4 ELASTIC STOP NUT	27	10 32x9 16	FAN HD CAD PLT STL SCREW 2 REQD	50	5312190	1 SPRING HOLDER
5	5311783	1 CAM SHAFT	*28	5313724	1 RESET CONN LINK	51	531757	1 LOCK NUT
6	197164	25 TRUARC RETAINING RING	*29	5312608	1 RESET SPRING	52	5311779	1 BELLOWS END WASHER
7	5312816	1 MANUAL SHAFT ASSY	*31	5312607	1 RESET PISTON & GUIDE ASSY	53	5311771	1 TRIGGER BELLOWS ASSY
8	5313773	1 BRAKE LEVER ASSY 2 REQD	*32	5311428	3 O RING GASKET	54	5312738	1 TRIGGER BELLOWS SPRING
9	5311778	1 SPRING	*33	5313726	1 CUP PACKING	55	5313777	1 SPRING BUSHING
*10	5312815	1 RESET SHAFT ASSY	*35	10 32x3 1 4	FAN HD CAD PLT STL SCREW 4 REQD	56	5311777	1 SPRING ADJ. NUT
*11	1 16x1 2	2 COTTER PIN CAD PLT STL	*36	1 4 28	REG SF STN STL HEX 1AM NUT	57	49137 10	1 PIVOT SHAFT
*12	5311682	1 CLEVIS PIN	*37	1114 00	CAD PLT STL SHKPRF LOCK WASHER	58	19737 1	1 SNAP FASTENER 2 REQD
13	537345	2 BY PASS VALVE				59	5313185	1 SPACER
14	5311786	1 GEAR SHAFT	*38	5313725	1 RESET PISTON CLEVIS	61	6 32	1 HEX NUT 2 REQD
15	197164	18 TRUARC RET RING 2 REQD	39	5313813	1 SPRING RETAINING PLATE	62	1941187	1 MICRO SWITCH
16	5312598	1 TRIGGER SHAFT	40	1 16x3 4	2 COTTER PIN CAD PLT 2 REQD	63	661842	1 SWITCH INSULATOR
17	5312686	1 HOUSING	41	5311784	1 RATCHET SPRING	64	6 32x7 8	1 RD HD SCREW 2 REQD
*18	5312395	1 STRIP EXPANDER	42	5312603	1 RESET LEVERS & SHAFT	65	1206 00	1 SHKPRF LK WASH 2 REQD
*19	5318578	1 RESET CYL & FLG ASSY	*43	5313727	1 RESET CLEVIS PIN			
22	10 32x1 2	8 FAN HD CAD PLT SCR 4 REQD	44	10 32x3 8	8 FAN HD CAD PLT SCR 7 REQD			
23	1210 00	CAD PLT STL SHKPRF LOCK WASHER 13 REQD	*45	5312606	1 PISTON FOLLOWER PLATE			
24	6 32x5 16	FAN HD CAD PLT STL SCR 2 REQD	46	5313334	1 BOTTOM PLATE			


AIR FAILURE BRAKE	RELEASE	PARTS REQUIRED
PT NO 5312600 1	REMOTE	ITEMS 1 THRU 58
*PT NO 5312600 2	MANUAL	ITEMS 1 THRU 59 EXCEPT THOSE MARKED BY ASTERISK

SPARE PARTS KITS PART NUMBERS

256120 1 FOR AIR FAILURE BRAKE 5312600 1	
QUANTITY	ITEM NO
1	32
1	35
1	47
1	53

256120 2 FOR AIR FAILURE BRAKE 5312600 2	
QUANTITY	ITEM NO
1	47
1	53

FIGURE 25 - Parts Drawing P81-65, Air Failure Brake, Part No 5312600-□



NADJULSTABLE ONE MAX STOP

REMOTE OPERATED M4 OR MAX STOPS

PARTS REQUIRED TO ADD MAXIMUM OR MINIMUM STOP TO AC0608□□□ AC0616P□□ AND AC1016P□□ DRIVES WHEN AIR FAILURE BRAKE IS NOT PROVIDED

ITEM NO	PART NO	NAME
1	531320	STOP TUBE
2	531259	SUPPORT PLATE
3	531334	BOTTOM PLATE
4	531797	TRUNNION SHAFT
5	531185	TRUNNION SHAFT
6	531398	ROD & CLEVIS ASSY
7	531382	CLEVIS PIN
8	531256	HOUSING

PARTS REQUIRED TO ADD REMOTE OPERATED MAXIMUM AND OR MINIMUM STOP TO AC0608□□□ AC0616P□□ AND AC1016P□□ DRIVES WHEN AIR FAILURE BRAKE IS NOT PROVIDED

ITEM NO	PART NO	NAME	ITEM NO	PART NO	NAME
1	531706	STOP TUBE	16	66153	SHAFT RETAINER
2	531259	SUPPORT PLATE	17	531179	BELLOWS END WASHER
3	531334	BOTTOM PLATE	18	537612	CONNECTOR ASSY
4	531259	TRUNNION SHAFT	19	531252	LOWER BEARING 2 REQD
5	531185	TRUNNION SHAFT	20	194158	CONNECTOR NUT 4 REQD
6	531709	ROD & CLEVIS ASSY	21	53 2621	PUSH ROD ASSY
7	531382	CLEVIS PIN	22	194118	ELBOW CONN
8	531256	HOUSING	23	195174	INVERTED TEE CONN *SEE NOTE
9	53175	LOCK NUT	24	3 16 O D	FLASH NICKEL PLATED COPPER TUBING 1/8 REQD *SEE NOTE
10	531252	BELLOWS SUPPORT	25	1941187	MICRO SWITCH
11	531255	BELLOWS ASSY			
12	531259	SPRING RETAINING PLATE			
13	531924	SHAFT & HUB ASSY			
14	531366	STOP PIN			
15	531172	SPRING			

NOTE ITEMS 23 & 24 ARE REQUIRED ONLY WHEN BOTH MINIMUM AND MAXIMUM STOPS ARE USED

FIGURE 26 Parts Drawing P81 43, Accessories