


Product Instruction M22-10



**Recorder or Indicator
Type CE**

Bailey Babcock & Wilcox

WARNING

DO NOT INSTALL MAINTAIN OR OPERATE THIS EQUIPMENT WITHOUT READING UNDERSTANDING AND FOLLOWING PROPER **Bailey Babcock & Wilcox** INSTRUCTIONS AND MANUALS OTHERWISE INJURY OR DAMAGE MAY RESULT

INDEX

	<u>Page</u>
Installation	3
Adjustment and Calibration	5
General Description	8
Explanation of Nomenclature	9
Replacement Parts	9

LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
1	Typical Assembly of Type CE Air Flow Meter	3
2	Mounting Dimensions	4
3	Recommended Piping Connections at Boiler Settings and Ducts	6
4	Recommended Piping Connections from Boiler or Duct to Recorder or Indicator	7
5	Typical Calibration Outfit	8
6	Parts Drawing M61 5, Type CE Displacer Mechanism	10
7	Parts Drawing M61 15, Type CE Diaphragm and Air Flow Beam Assembly	11
8	Parts Drawing G99 5 Rectangular Case Assembly	12
9	Parts Drawing G99 35, Chart Plate and Chart Drive	13

CROSS REFERENCES

Installation of Orifices and Flow Nozzles

Instruction Section G 33 I

Type CE Meters




FIGURE 1 Typical Assembly of Type CE Air Flow Meter

INSTALLATION

The parabolic displacer assembly and air flow beam (Figure 6) are factory calibrated and marked with the Recorder or Indicator serial number before shipment. The displacer is packed in a separate carton. The air flow beam and all remaining parts are packed inside the Recorder or Indicator case. After installing the Recorder or Indicator, check calibration as outlined on page 5.

Mounting

1. Remove all parts and packing from Recorder or Indicator case.
2. Mount Recorder or indicator as shown in Figure 2. Level instrument from left to right and from front to back. Then fasten securely.
3. Assemble drop link to beam as shown in Figure 1. Moving parts must be free of friction.
4. Make certain reservoir is free from dirt or dust accumulations. Correct amount of

mercury is shipped in a plastic container and tagged with Recorder or Indicator serial number. Slowly pour mercury into reservoir.

WARNING. Due to toxic properties of mercury, care must be used when filling the reservoir. Do not spill mercury.

5. Insert displacer in reservoir (see Figure 1).

Chart and Recording Pen (Type CE35 Recorder)

1. Remove chart clamp nut (Figure 9) and raise pen lifter.
2. Place chart on chart plate so edges fit under chart plate tabs. Make certain that correct chart is used. (Chart number is listed on nameplate inside Recorder case and on the Specification Sheet in front of this Instruction Book.)

Type CE Meters

2. Attach mating plug to a cord from power source.

3 If Recorder or Indicator is located in a damp or dusty location, remove plug and make power connection at terminal blocks inside case near conduit hole Use 3/4-inch flexible conduit. Install a switch to turn power off and on.

Internal Illumination

1. If Recorder or Indicator is equipped

with fluorescent lighting, the starter and lamp are packed separately For best results, operate lighting system within voltage limits specified on ballast.

2. Insert starter in receptacle provided in lamp socket (Figure 8). Securely place lamp in holder. If lamp starts slowly, reverse starter poles

3 If lamp fails to light, check for loose connections before replacing starter or lamp

ADJUSTMENT AND CALIBRATION

The Type CE Diaphragm Operated Air or Gas Flow Recorder or Indicator is factory calibrated and should require no further adjustment However, before placing in service, check calibration as outlined below Refer to Figure 1.

Calibration Check

1 Close shut off valves (if provided) and disconnect unions at connections H and L Pen or pointer should read zero chart or scale If not, check that beam rests against zero stop

a Make certain displacer does not rub against sides of reservoir

b If beam rests against stop, loosen two clamp screws (Figure 1) holding pen or pointer arm to yoke and set pen or pointer on zero chart or scale line Tighten screws

c If beam is not resting against stop, check beam and linkage mechanism for friction (Do not change zero stop setting to correct pen or pointer reading)

2. Connect Recorder or Indicator H connection to a calibration outfit similar to that shown in Figure 5

3. Check pen or pointer readings at three or four points over the given differential pressure range (such as 30, 50, 70, and 90%) To check readings between zero and 100% chart or scale, determine the applied differential pressure required to obtain desired chart or scale readings as follows

$(\% \text{ chart or scale reading desired})^2 \times \text{maximum differential pressure range value} = \text{applied differential pressure.}$

EXAMPLE To check pen or pointer reading at 40% chart or scale when the maximum range value is 5" H₂O, apply 8' H₂O.

$$(.4)^2 \times 5' \text{ H}_2\text{O} = 8' \text{ H}_2\text{O}$$

4. Apply correct differential pressure (determined in step 3, and note chart or scale readings


a. If average up and down readings be low 50% chart or scale are incorrect, turn balance weights IN slightly to decrease reading or OUT to increase reading Then apply zero differential and check that pen or pointer returns to zero chart or scale (refer to steps 1b and 1c)

b. If average up and down reading at 50% chart or scale is incorrect, ADD a few drops of mercury (with eye dropper) to reservoir to increase reading or REMOVE a few drops to decrease reading Then apply zero differential and check that pen or pointer returns to zero chart or scale (refer to step 1b and 1c).


c. If average up and down readings between 70 and 100% chart or scale are incorrect, it is necessary to make a range adjustment using the radius arm as outlined in step 5. Then repeat entire step 4 until correct chart or scale readings are obtained.

NOTE If a specific differential pressure range is not specified, the radius "R" is set at 1 1/2 inches.

5 To re establish radius 'R' (Figure 1) to give correct pen or pointer travel for instrument range



DRAFT CONNECTION THROUGH WATER WALL SETTING



DRAFT CONNECTION THROUGH BRICK SETTING

NOTE 2

FOR INSTALLATION THROUGH VERTICAL WALL OR HOLLOW WALL INSTALL P.P.E. SLEEVE PERPENDICULAR TO WALL AS SHOWN IN LOWER RIGHT ILLUSTRATION OR INSTALLATION THROUGH VERTICAL DUCT WALL INSTALL P.P.E. SLEEVE AT 45° TO WALL AS SHOWN AT VIEW D

NOTE 3

WHEN IT IS DESIRABLE TO CONNECT TWO INSTRUMENTS USE ONE INSTRUMENT AND ONE CONTROLLER TO ONE POINT IN CONNECTION THE SECOND LINE TO THE CROSS SHOWN DO NOT RUN THE SLEEVE DOWN AND THEN TEE OFF AT OR NEAR THE INSTRUMENTS

NOTE 4

IF ANY WHATEVER BUSH IS REQUIRED TO REDUCE DUCT TO SIZE OF CONNECTING P.P.E. USED IN THE INSTALLATION

NOTE 5

THE P.P.E. IS FROM THE TOP SHOWN SHOULD RUN AND BE TIGHT AS POSSIBLE TO METER FACE OR OTHER LINES AND MUST HAVE NO BRANCH CONNECTIONS TO OTHER EQUIPMENT

NOTE 6

ZINC PLATES WELDED TO P.P.E. SLEEVE TO KEEP SLEEVE FROM TURNING IN BRICK SETTING WHEN PLUG AT END OF SLEEVE IS REMOVED FOR CLEANING PLATES TO BE FURNISHED AND WELDED TO SLEEVE IN FIELD BY CUSTOMER

FIGURE 3 Recommended Piping Connections at Bailey Settings and Ducts

Type CE Meters

a. Loosen maximum travel stop. Apply differential corresponding to slightly more than maximum differential range value. Set stop so it just touches beam, tighten stop screw.

b. As a starting point, loosen radius screw and set radius "R" to equal 1 1/2 inches.


c. Apply differential corresponding to maximum range value. Loosen radius screw and position drive link to increase or decrease radius "R" until correct chart or scale reading

is obtained at 100% chart or scale, tighten stop screw.



d. Repeat steps 4 and 5 until correct chart readings are obtained.

6. With beam resting against zero stop, the mercury depth gage should just touch surface of mercury without denting it. If not, adjust mercury depth gage (shown in Figure 1) to desired setting for a future reference point.

7. To place instrument in service, connect unions (and open shut off valves if provided) below Recorder or Indicator case (Figure 1)



CONNECT ON FOR FURNACE ROOF OR TOP OF DUCT



NOTES

- 1. F CONNECT NG LINE S 75 FEET OR LESS N LENGTH USE 1/2 STANDARD STEEL P PE OR FOLLOW NG R SER 1/2 O D SOFT ANNEALED SEAMLESS COPPER TUB NG AND SUITABLE FITTINGS
- 2. F CONNECT NG LINE S LONGER THAN 75 FEET USE 1/2 STANDARD STEEL P PE OR FOLLOW NG R SER 1/2 O D SOFT ANNEALED SEAMLESS COPPER TUB NG AND SUITABLE FITTINGS
- 3. 2 FOR P PE USE 2 1/2 OR 3 TEES OR PLUGS DEPENDING ON P PE SIZE
- 4. R SER AT LEAST 2 FEET LONG S RECOMMENDED USE STEEL P PE SIZE PER NOTE WITH T.E. AT TOP OF R SER
- 5. USE 1/2 OR 3/4 UN ON DEPENDING ON P PE SIZE
- 6. IMPORTANT SLOPE P P NC OR TUB NG TO AVOID POCKETS OR LOW POINTS WHERE CONDENSATE CAN COLLECT IF LOW POINTS ARE UNAVOIDABLE INSTALL DR P POCKETS AT THESE POINTS T S SUGGESTED THAT A DR P POCKET BE INSTALLED AT POINT (A)

ALL P P NG MATERIAL NOTES APPLY EQUALLY TO BOTH LINES

TEES AND PLUGS SEE NOTE 2

SEE NOTE 6




FIGURE 4 Recommended Piping Connections from Boiler or Duct to Recorder or Indicator




FIGURE 5 Typical Calibration Outfit


GENERAL DESCRIPTION

The Type CE Diaphragm Operated Air or Gas Flow Recorder or Indicator (Figure 1) measures a pressure drop across an orifice or boiler and records or indicates the measurement in terms of flow on a uniformly graduated chart or scale

The Recorder or Indicator consists of a diaphragm mechanism connected to the pivot point of a beam by linkage. An increase in differential pressure applied to the diaphragm mechanism

moves the diaphragm. This motion is transmitted thru linkage to the balance beam and causes the beam to rotate. One end of the beam is attached to a yoke which is connected to the recording pen or indicating pointer. A parabolic displacer suspended from the other end of the beam extracts the square root function by varying the force required to lift it from a reservoir of mercury

EXPLANATION OF NOMENCLATURE



An "X" in any Nomenclature position indicates that the variation is special. An "X" as a suffix indicates that the Recorder or Indicator includes a special feature not covered by Nomenclature.

REPLACEMENT PARTS

Spare Parts Kits

The Spare Parts Kits shown in Figures 7 and 8 should be carried in stock. Specify the Spare Parts Kit part number to order a complete kit.

Ordering Individual Parts

Figures 6, 7, 8, and 9 are Parts Drawings of the Type CE Diaphragm Operated Gas Flow Recorder mechanism and case. Normally these drawings will apply to the instrument furnished. However, there may be individual differences in specific instruments because of

a. design changes made since the printing of this Instruction Section, or

b. special design of equipment furnished to make it suitable for specific application.

Therefore, when ordering parts, assure receipt of correct replacements by specifying on the order:

1. complete nomenclature and serial number (stamped on instrument nameplate) of equipment for which parts are desired, and

2. the Parts Drawing number which each part is illustrated. (The Parts Drawing Number is given in the Figure caption.)




FIGURE 6 Parts Drawing M61 5, Type CE Displacer Mechanism

Type CE Meters




FIGURE 7 Parts Drawing M61 15, Type CE Diaphragm and Air Flow Beam Assembly




FIGURE 9 Parts Drawing G92 35, Chart Plate and Chart Drive

Product Warranty

Bailey Meter Company warrants the products manufactured by it to be free from defects in material and workmanship and will repair or replace, at its option, free of charge, from its factory, such part or parts which prove defective within one year from date of shipment. In respect to any products which are not an integral part of a product manufactured by the Company, the warranty given by the manufacturer thereof shall apply.

Shipping Damage

We strongly recommend that you inspect and test your instrument as soon as you receive it. If the instrument is damaged or operates improperly, notify the carrier for inspection of the shipment. The carrier's claim agent will prepare a report of damage, a copy of which should be forwarded to your nearest Bailey District Office (see back cover for location). The District Office will then tell you how to have the instrument repaired or replaced.

Service

The Bailey Meter Company is vitally concerned that your Bailey instrument provides continued, fine performance. This instruction manual is designed to fully describe the correct installation, operation, and maintenance of your instrument under recommended conditions. If the need arises, factory-trained Service Engineers are on call for prompt, in-plant maintenance. Telephone or wire your nearby Bailey District Office to make arrangements for this service.

Replacement Parts and Supplies

Complete parts drawings and recommended spare parts kit information are included in this instruction manual. When replacement parts or supplies are required for maintenance of your Bailey instrument, contact your nearest Bailey District Office (see back cover for location). Always specify complete data on the instrument nameplate on your inquiry or order for parts. Common parts are available for shipment within 48 hours on a speed order basis.

**BAILEY METER COMPANY
HEADQUARTERS
Wickliffe, Ohio 44092**

U S A SALES OFFICES

California Los Angeles
California San Francisco
Colorado Denver
Connecticut New Haven
Florida Jacksonville
Georgia Atlanta
Illinois Chicago
Kentucky Louisville
Louisiana New Orleans
Maine Augusta
Maryland Baltimore
Massachusetts Boston
Michigan Detroit
Michigan Kamazoo
Minnesota St Paul
Missouri Kansas City
Missouri St Louis
North Carolina Charlotte
New Jersey East Orange
New York Buffalo
New York Syracuse
Ohio Cincinnati
Ohio Cleveland
Pennsylvania Philadelphia
Pennsylvania Pittsburgh
Texas Dallas
Texas Houston
Virginia Richmond
Washington Seattle
Wisconsin Milwaukee

**BAILEY METER COMPANY LIMITED
POINTE CLAUDE 730, QUEBEC**

Alberta Edmonton
British Columbia Vancouver
Manitoba Winnipeg
Nova Scotia Halifax
Ontario Ottawa
Ontario Toronto
Quebec Montreal

**BAILEY METER AUSTRALIA PTY LTD
REGENTS PARK NSW 2143**

New South Wales Sydney
Queensland Brisbane
South Australia Adelaide
Victoria Melbourne
Western Australia Perth

**BAILEY JAPAN COMPANY LTD
511 IBARAKI, NAYAMA CHO TAGATA GUN
SHIZUOKA KEN JAPAN**

INTERNATIONAL REPRESENTATIVES

Argentina Buenos Aires
Brazil Rio de Janeiro
Chile Santiago
England, Croydon
France Paris
India, New Delhi
Italy Milan
Japan, Tokyo
Mexico Mexico City DF
Puerto Rico San Juan
Spain Madrid
Taiwan Taipei
Turkey Ankara
And Other Provinces



a subsidiary of Babcock & Wilcox USA