

Application Module Implementation Guidelines

AM12-610

**Implementation
Application Module - 2**

***Application Module
Implementation Guidelines***

**AM12-610
Release 650
12/03**

Notices and Trademarks

Copyright 2003 by Honeywell International Inc.
Revision 5 December 5, 2003

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in its written agreement with and for its customers.

In no event is Honeywell liable to anyone for any indirect, special or consequential damages. The information and specifications in this document are subject to change without notice.

Honeywell and **TotalPlant** are registered trademarks of Honeywell International Inc.

Other brand or product names are trademarks of their respective owners.

Contacts

World Wide Web

The following Honeywell web sites may be of interest to Industry solutions customers.

Honeywell Organization	WWW Address (URL)
Corporate	http://www.honeywell.com
Industry Solutions	http://www.acs.honeywell.com
International	http://content.honeywell.com/global/

Telephone

Contact us by telephone at the numbers listed below.

	Organization	Phone Number
United States and Canada	Honeywell International Inc.	1-800-343-0228 Sales
	Industry Solutions	1-800-525-7439 Service
		1-800-822-7673 Technical Support
Asia Pacific	Honeywell Asia Pacific Inc. Hong Kong	(852) 23 31 9133
Europe	Honeywell PACE Brussels, Belgium	[32-2] 728-2711
Latin America	Honeywell International Inc. Sunrise, Florida U.S.A.	(954) 845-2600

Honeywell International
Process Solutions
2500 West Union Hills Drive
Phoenix, AZ 85027
1-800 343-0228

About This Publication

This publication provides guidelines for the implementation of Application Modules, including the allocation of AM memory, adding units to AMs, moving units between AMs, the AM Redundancy option, recovery from certain error conditions, obtaining AM processing-schedule information, AM checkpointing, the AM Redundancy option, custom software, CL extensions, and background CL.

This publication supports **TotalPlant** Solution (TPS) system network Release 650. TPS is the evolution of TDC 3000^X.

Table of Contents

Section 1 - INTRODUCTION.....	1
Summary of AM Implementation Tasks	1
Universal Personality Activities	1
Other AM Implementation Activities	2
References for Universal Personality Activities	3
AM Implementation Dependencies	5
AM PSDP Parameters.....	6
Section 2 - AM MEMORY ALLOCATION	7
Overview.....	7
AM NCF Configuration Tasks and Displays.....	8
AM Memory Sizes	10
How the AM User Memory Is Organized.....	12
Parameters for Monitoring AM Memory Use.....	14
AM User Memory Allocation—NCF Display.....	19
NCF Functional Adjustments—Background CL.....	21
NCF Functional Adjustments—CVB Size (point processors)	23
NCF Functional Adjustments—Redundancy Buffer.....	25
NCF Functional Adjustments —CVB Size For IPP	26
NCF Functional Adjustments—User Memory Reserved.....	26
NCF Functional Adjustments—External Load Modules.....	26
How to Estimate AM Memory.....	28
Optimizing CVB Size	32
AM Database Size.....	38
Section 3 - ADDING AND MOVING AM PROCESS UNITS	39
How to Add a New Unit to an AM.....	39
How to Move Units From One AM To Another.....	41
Section 4 - USER-CORRECTABLE “SOFTWARE” ERRORS	45
Error Message Format	45
Interpretation and Remedies	45
Section 5 - OBTAINING AM SCHEDULE INFORMATION.....	49
Initiating the AM Schedule Dumper.....	49
Interpreting the AM Schedule Printout	51
Format of the Cycle Loading Information	51

Format of the Point Scheduling Information	52
Additional Information About AM Point Scheduling	52
AM Overrun Diagnostic Display (SMCC).....	54
Section 6 - AM LOAD BALANCE TOOL	55
Overview.....	55
Background.....	55
Tool Location.....	55
Installation.....	55
Operating Instructions and Examples	56
Main Schematic - \$AMCYLD.....	56
Help Schematic - \$AMCYHLP.....	59
Cycle Report - AMnnLIST.XX File.....	60
Usage of the AM Load Balance Tool	61
Current Operation	61
New Operation—Ways to Use the AM Load Balance Tool	62
Error Handling	63
Section 7 - AM CHECKPOINTS.....	65
Establishing AM Checkpoint Volumes	65
Options and AM Checkpoints.....	65
How to Reserve User Memory for Future Options.....	66
How to Discover the Reason for Checkpoint Errors	67
Section 8 - AM REDUNDANCY OPTION	69
Installing and Configuring Redundant AMs.....	69
Loading of Redundant AMs.....	70
Operation of Redundant AMs.....	71
Overloads and Redundancy Buffer Size	71
Background CL in Redundant AMs.....	73
On-Line Migration of Redundant AMs.....	74
First AM Redundancy Upgrade after R611	74
Subsequent AM Redundancy Upgrades.....	76
Conditions to shutdown both AM nodes	77
Section 9 - CUSTOM SOFTWARE, CL EXTENSIONS, AND BACKGROUND CL	79
Directions Required for External Load Modules and CL Extensions.....	79
Overview of the Installation of External Load Modules	80
Node Configuration and External Load Modules Page.....	81
Node Configuration, AM User Memory Allocation Page.....	82
Loading of External Load Modules.....	82

Section 1 - INTRODUCTION

This introduction summarizes the Application Module (AM) implementation tasks, lists publications that you will refer to, to implement AMs, and describes implementation dependencies.

Summary of AM Implementation Tasks

Universal Personality Activities

The Universal Personality activities listed below may be affected by the implementation of an AM or must be used to implement an AM.

See “Other AM Implementation Activities” for references to instructions for each of these activities.

Activities named in THIS TYPEFACE are activated by targets on the Universal Personality Main Menu.

- **UNIT NAMES**—The process units defined for each AM data point is established in this activity.
- **AREA NAMES**—The area name and descriptor for any units with AM points that are assigned to an area are established in this activity.
- **LCN NODES**—The AMs on the LCN and redundant AM partners are defined in this activity. Also, this activity has a role in the allocation of AM memory and the implementation of custom software and background CL programs.
- **VOLUME CONFIGURATION**—The AM checkpoint volume, &5np, is established in this activity. This volume must have adequate storage space to accommodate the checkpoint data for all AMs on the LCN. Please refer to Section 6, AM Checkpoints, in this publication before you configure any AM checkpoint volumes.
- **APPLICATION MODULE**—AM data points are built in this activity.
- **PICTURE EDITOR, FREE FORMAT LOGS, BUTTON CONFIGURATION**—Any of pictures, logs, and buttons built by these activities can access AM points, once the points are built and loaded.
- **HM HISTORY GROUPS**—AM data point values for which continuous history is to be collected are defined in this activity, by assigning them to specific HM history groups.
- **AREA DATA BASE**—This activity defines how and where data for data points, including AM data points are used and displayed in a given process area. The area database is the database loaded into a Universal Station, so that database defines the process area monitored and controlled through the US.
- **Control Language (CL)**—Use this language to prepare user-written programs to accomplish data acquisition and control functions that cannot be accomplished by the standard AM data points and algorithms.

Other AM Implementation Activities

- Estimating AM memory used by AM data points and AM memory allocation—AM performance can be enhanced through these activities. Information and instructions for them are in Section 2 of this publication.
- Adding and moving AM process units—As your process changes, your unit allocations to AMs may need to change. Information and instructions for these activities are in Section 3 of this publication.
- Scheduling the processing of AM points for best performance—If you spread out the point-processing load in your AMs, you will attain better performance and reduce the chance that processing of a point will be delayed because of a processing overload. Information and instructions for displaying and printing of AM point scheduling information are in Section 5 of this publication.
- Establishing AM checkpoint volumes and considering the impact on them of AM options—Section 6 of this publication provides guidelines for establishing the size of AM checkpoint volumes, the effect of AM options on the size of those volumes, the effect of reserved AM memory on those volumes, and information about saving AM checkpoints on removable media (cartridges or floppies).
- Implementing redundant AMs—For applications that require high reliability, AMs can be implemented as redundant partners. Section 7 of this publication provides information for the implementation and use of redundant AMs.
- Implementing Background CL and custom software—You can prepare CL programs that run in the background on an AM, that is programs that run when the AM is not busy with point processing or other activities. Also, custom software, usually custom application software can be provided by Honeywell for your AMs. Section 8 of this publication provides guidelines for the implementation of these functions.

References for Universal Personality Activities

- UNIT NAMES and AREA NAMES

Network Form Instructions in the *Implementation/Startup & Reconfiguration - 1 binder*

Network Data Entry in the *Implementation/Startup & Reconfiguration - 1 binder*

- LCN NODES

Network Form Instructions in the *Implementation/Startup & Reconfiguration - 1 binder*

Network Data Entry in the *Implementation/Startup & Reconfiguration - 1 binder*

Sections 2 and 8 in this publication.

- VOLUME CONFIGURATION

Section 6 of this publication and Section 7 of the *Engineer's Reference Manual* in the *Implementation/Startup & Reconfiguration - 1 binder*.

- APPLICATION MODULE

Application Module Control Functions in the *Implementation/Application Module - 1 binder*

Application Module Algorithm Engineering Data in the *Implementation/Application Module - 1 binder*

Application Module Parameter Reference Dictionary in the *Implementation/Application Module - 2 binder*

Data Entity Builder Manual in the *Implementation/Engineering Operations - 1 binder*

- NETWORK INTERFACE MODULE

Logic Manager Control Functions in the *Implementation/Logic Manager binder*

Logic Manager Parameter Reference Dictionary in the *Implementation/Logic Manager binder*

Data Entity Builder Manual in the *Implementation/Engineering Operations - 1 binder*

- PICTURE EDITOR, FREE FORMAT LOGS, BUTTON CONFIGURATION

Instructions for these activities are in binders 1 and 2 of *Implementation/ Engineering Operations*

- HM HISTORY GROUPS

HM History Group Form Instructions in the *Implementation/Engineering Operations - 1* binder.

Data Entity Builder Manual in the *Implementation/Engineering Operations - 1* binder

- AREA DATA BASE

Area Form Instructions in the *Implementation/Engineering Operations - 1* binder

Data Entity Builder Manual in the *Implementation/Engineering Operations - 1* binder

- CONTROL LANGUAGE (CL)

CL/AM publications in the *Implementation/Application Module - 2 & 3* binders

Data Entity Builder Manual in the *Implementation/Engineering Operations - 1* binder

The *Engineer's Reference Manual* in the *Implementation/Startup & Reconfiguration - 2* binder is a reference and guidelines manual that is useful in all implementation activities.

AM Implementation Dependencies

Figure 1-1 shows which Application Module implementation tasks depend on information entered in other tasks. This figure does not necessarily dictate the order in which the tasks must be completed, but it does show the dependencies that must be satisfied before an AM can be fully operational.




Figure 1-1 — Application Module Implementation Dependencies

3653

AM PSDP Parameters

Every node on the LCN has a processor Status Data Point (PSDP) that contains a number of parameters. These parameters reflect important performance status and memory-use values.

PSDP parameters have been added to determine the points which take the longest time to execute. These parameters will display and maintain the point names and CL block names that took the longest time to process by the Fast/Slow Point Processors. Another parameter of the AM PSDP is used to switch the collection of the other parameters ON or OFF. The switch parameter will not switch off the saving of the point name and CL block name that is used for the crash statistics.

A list of these parameters and additional information on the use of the AM PSDP parameters is provided in subsection AM PSDPs, of the *Engineer's Reference Manual*.

Section 2 - AM MEMORY ALLOCATION

Overview

Introduction

Engineers, who design the **TotalPlant** Solution (TPS) system configuration, including the Application Module configuration, can influence the allocation of the AM's memory and thereby affect the AM's point capacity.

This section provides guidelines for the allocation of AM memory and how to interpret the AM processor status data point (PSDP) parameters that are used to monitor AM memory allocation.

Background

Data points in Application Modules require differing amounts of memory, as determined by the point types and the options selected for the points. For example, an AM regulatory point with the following options uses much more memory than a simple flag point with minimal options:

- PV and control algorithms
- CL blocks
- Custom data segments

Unlike the NIM and HG, AM points reside entirely in the AM where they are processed.

AM points can fetch data from and store data to other AMs, NIMs, and HGs, requiring memory buffers to store the data until it is used in point processing.

The AM buffers must be made large enough to accommodate the largest amount of data exchanged on a single point-processing cycle. Larger memory buffers leave less memory for data points.

AM NCF Configuration Tasks and Displays

NCF tasks

The following AM configuration is performed through the Network Configuration File (NCF):

- configure custom functions,
- configure background functions,
- specify optional runtime extensions (such as those used when reading and writing to text files resident on the History Module or removable media),
- verify or modify the amount of AM memory available for various tasks and functions,
- specify additional custom software that may be loaded into an AM.

User Memory Allocation Display

One of the major AM configuration tasks that you will need to perform is allocating AM user memory. User memory allocation is the overall purpose of page 2 of the AM's NCF Node Configuration display. Figure 2-1 is an example of NCF page 2.

APPLICATION MODULE NODE		20 Mar	04:21:25	L
PAGE 2 OF 3		ON-LINE		
NODE	40	USER MEMORY ALLOCATION		
FUNCTIONAL ADJUSTMENTS:			MEMORY USED (WORDS)	
# BACKGROUND CL TASKS	<input type="text" value="2"/>		66200	
# CONCURRENT DATA ACCESSES FROM BACKGROUND CL	<input type="text" value="2"/>		2100	
BACKGROUND TASK STACK SIZE	<input type="text" value="25000"/>			
CVB SIZE FOR FAST & SLOW POINT PROCESSORS	<input type="text" value="10000"/>		170000	
REDUNDANCY BUFFER INCREASE (# OF 32KW BLOCKS)	<input type="text" value="1"/>		32768	
INCLUDE INTERNETWORK POINT PROCESSOR?	<input checked="" type="checkbox"/> YES <input type="checkbox"/> NO	<input type="text" value="2000"/>	44050	
CVB SIZE FOR IPP	<input type="text" value="1"/>		32768	
USER MEMORY RESERVED (# OF 32KW BLOCKS)			608256	
EXTERNAL LOAD MODULES CODE (ROUNDUP FROM NEXT PAGE)			120832	
EXTERNAL LOAD MODULES POOL1 (FROM NEXT PAGE)			-----	
TOTAL MEMORY FOR FUNCTIONAL ADJUSTMENTS			1076974	
CURRENT DATA BASE SIZE (AMMEMTOT)		136149.0		
ROOM LEFT FOR DATA BASE GROWTH		807422.0		
TOTAL USER MEMORY AFTER SOFTWARE OPTIONS (AMMEMAOP)		2020540.		
F1=CHECK	F3=SET OFFLINE	F5=ABORT	F9=PACK NCF	
F2=INSTALL	F4=PRINT			

53664

Figure 2-1 User Memory Allocation Display—NCF Page 2

**External Load
Module Display**

Another major AM configuration task is to specify the optional software (called EXTERNAL LOAD MODULES) that you can load into an AM. Figure 2-2 is an example of that NCF page.

```

22 Mar 16:27:39 L
APPLICATION MODULE NODE PAGE 3 OF 3 ON-LINE

NODE 40

ENTER EXTERNAL LOAD MODULE NAMES & ASSOCIATED PERSONALITY-TYPES:
NAME --- PERS. NAME --- PERS. NAME --- PERS. NAME --- PERS.
FILE AMO
CONV AMO
AMCL02 AMO
AMCL04 AMO
AMCL05 AMO
AMCL01 AMO

USE DEFAULT PERSONALITY TYPE? YES NO

AM0
ADDITIONAL MODULE MEMORY (WORDS) 442944

TOTAL (MODULES PLUS ADDITIONAL MEMORY) 729088

FURTHER EXTERNAL DIRECTIVES? YES NO
F1=CHECK F3=SET OFFLINE F5=ABORT F7=NEXT ITEM F9=PACK NCF
F2=INSTALL F4=PRINT

```

33686

Figure 2-2 External Load Module Display—NCF Page 3

AM Memory Sizes

Description	<p>The total amount of memory in an AM can range from 3 Mw to 16 Mw (Mw = one million words).</p> <p>The amount of user memory available in an AM (PSDP parameter AMMEMAOP) is a function of the total AM memory size.</p>
Available User Memory	<p>Table 2-1 shows how the AM memory available to the user is related to the total AM memory size.</p> <p>NOTE: Options such as AM redundancy and K4LCN processor reduce available AM user memory (see Figure 2-3, 2-4 for additional information).</p> <p>NOTE: AM's maximum memory used is dependent on the hardware used. For example, the AM memory with:</p> <ul style="list-style-type: none">the HPK2/HMPU processors uses a maximum of 7 Mw,the K2LCN processor uses a maximum of 7 3/4 Mw, andthe K4LCN processor exists in 4 Mw, 8 Mw, and 16 Mw sizes only. <p>The available AM user memory with 7 3/4 Mw is 5,786,245 words.</p> <p>NOTE: The AM 16 Mw K4LCN has a special user-memory requirement regarding the checkpoint buffer size for the largest unit (MEMCKPT).</p> <p>If the AM point database is very large in only one unit, point building may get out-of-memory errors even when a large amount of user memory is available (1-2 Mw of MEMFREE). This condition is due to a hardware constraint that restricts the checkpoint buffer for the largest unit to a portion of the lower 8 Mw of memory only.</p> <p>This out-of-memory condition will not occur on other memory sizes of AM K4LCN, or if the point database is distributed across multiple units. When this condition occurs, the free memory remains available for other AM optional uses other than point building.</p> <p>NOTE: With R650, the AM/CL Process Changes function allows you to journal the process changes made by AM/CL programs. When the AM/CL Process Change function is activated, the AM may use more unit memory and CPU time, and the AM and memory is allocated from AM user memory.</p> <p>See Appendix J in <i>AM/CL Reference Manual</i> for more information on the Journal AM/CL Process Changes.</p>

NOTE: Memory mapping is different for an A^XM.

NOTE: The A^XM available user memory for the: 6 Mw A^XM corresponds to the 3 Mw AM; 7 Mw A^XM corresponds to the 4 Mw AM; 8 Mw A^XM corresponds to the 5 Mw AM; and 16 Mw A^XM is 11,058,224 words.


Table 2-1 Available AM User Memories

Total AM Memory Size	Available AM User Memory (R500)
3.0 Mw	1,016,358 words
4.0 Mw	2,020,545 words (2,009,435 for K4LCN)
5.0 Mw	3,024,731 words
6.0 Mw	4,028,918 words
7.0 Mw (HPK2/HMPU maximum)	5,033,105 words
7.75 Mw (K2LCN maximum)	5,786,245 words
8.0 Mw	6,037,291 words (6,020,211 for K4LCN)
16.0 Mw	14,070,784 words (14,045,430 for K4LCN)

Exceeding available user memory The total AM memory used increases with each point loaded into the AM and with each CL block linked to a point. If one of these operations results in the total memory used exceeding the total user memory available, the operation is aborted and an error message is generated.

How the AM User Memory Is Organized

Conceptual diagram The following diagram is a conceptual view of the AM's user memory. The actual structure is not as shown here.




NCF configuration For purpose of NCF configuration, the AM user memory is divided into the four sections described in Table 2-2.

Table 2-2 Sections of AM User Memory

Section	Description
1. Total Memory for Functional Adjustments	Configured on NCF page 2 of the AM's LCN Node configuration. These entries can be changed from the NCF display while the AM is on-line. In order for the changes to take effect, the NCF must then be installed and the AM (or redundant AM pair) restarted.
2. Memory for Software Options	<u>K4LCN Processor Option</u> If the AM uses the K4LCN processor, then space for memory management will be required depending on the amount of memory present on the board. The following K4LCN memory sizes are available: <ul style="list-style-type: none"> • 4 meg K4LCN requires ≈12,000 words • 8 meg K4LCN requires ≈18,000 words • 16 meg K4LCN requires ≈26,000 words <u>AM Redundancy Option</u> Redundant AMs require the following memory: <ul style="list-style-type: none"> • 157,000 words (fast/slow processor buffers), plus an additional • 22,000 words if using the AM redundancy Internetwork Point Processor (IPP) option.
3. Current Database Size	Memory required for AM points, CL programs, custom data segments, and checkpoint buffers. This memory is allocated through the DEB and CL compiler while the AM is on-line.
4. Available Unused Memory	Memory that remains unused after the other three sections are allocated—user memory that is available and not allocated. This memory is described in some displays as “room left for database growth.

Conceptual diagram Figure 2-3 is a conceptual representation of the AM user memory. As you can see in the diagram, the more memory the user allocates to “Additional Functional Adjustments” in the NCF configuration, the less memory there is available for database.



Shaded areas are available to the user and in some cases the amount is user configurable.


7412

Figure 2-3 Conceptual Diagram of AM User Memory

Parameters for Monitoring AM Memory Use

Description AM Processor Status Data Point parameters are available to monitor AM memory use. Some of the parameters are shown on page 2 of the AM’s NCF display—the User Memory Allocation display.

Correlating PSDP parameters to AM user memory Figure 2-4 correlates the AM user memory with the parameters available on the NCF User Memory Allocation display.



Shaded areas are available to the user and in some cases the amount is user configurable.

33687

33687


Figure 2-4 Diagram Correlating AM Memory to NCF Parameters

Memory allocation parameters

Since several of the AM memory allocation parameters can be modified when configuring the AM NCF, you can use the Application Module NCF display to check their values.

The following functional adjustments memory allocation parameters can be viewed on the following NCF display and are described in Table 2-3.

	<u>PSDP Parameter</u>
CVB SIZE FOR FAST AND SLOW PROCESSORS	MEMCVBLM
REDUNDANCY BUFFER INCREASE (# OF 32KW BLOCKS)	AMDATA(48)
CVB SIZE FOR IPP	MIPCVBLM
TOTAL MEMORY FOR FUNCTIONAL ADJUSTMENTS	AMMEMADJ
CURRENT DATA BASE SIZE	AMMEMTOT
ROOM LEFT FOR DATA BASE GROWTH	MEMFREE
TOTAL USER MEMORY AFTER SOFTWARE OPTIONS	AMMEMAOP



53664

Figure 2-5 User Memory Allocation—NCF Display

Parameter definition Table 2-3 describes the Processor Status Data Point (PSDP) parameters that allow you to monitor AM memory use.

Table 2-3 AM PSDP Parameters for Memory Use

Parameter	Description
AMMEMAOP	TOTAL USER MEMORY AFTER SOFTWARE OPTIONS (based on available memory size and software options)
AMMEMADJ	TOTAL MEMORY FOR FUNCTIONAL ADJUSTMENTS
AMMEMTOT	CURRENT DATABASE SIZE—the sum of the following: <ul style="list-style-type: none"> <li data-bbox="370 722 1472 877">• Point Data (TMEMPTS) The point size plus eleven words for each point (Reference Subsection 2.12 of this manual.). Also add the space for the Custom Data Segments attached to any points (Reference Appendix B.2.5, in the <i>CL/AM Reference Manual</i>). (Default=approximately 1800 words per unit when using the NULL/STARTUP checkpoint.) <li data-bbox="370 888 1472 1020">• Largest Checkpoint Buffer (MEMCKPT) Space for the largest unit—1.03 times the Point Data item for the largest unit. CL blocks, reference lists, and custom data descriptions do not need to be included. (Default=approximately 6000 words when using the NULL/STARTUP checkpoint.) <li data-bbox="370 1031 1472 1186">• CL Blocks (TMEMCL) The sizes for these are defined in B.2.3 in the <i>CL/AM Reference Manual</i>. Remember that each CL block requires the same space for each unit that uses it. Reference lists require space on each point to which the block is linked. (Default=zero words per unit when using the NULL/STARTUP checkpoints.) <li data-bbox="370 1197 1472 1352">• Custom Data Descriptors (TMEMCDPN) The sizes for these are defined in Appendix B, Section 2.5 of the <i>CL/AM Reference Manual</i>. Remember that AM custom data descriptions require space only once in a given AM—they are shared among points and units. (Default=approximately 1200 words per unit when using the NULL/STARTUP checkpoint.) <li data-bbox="370 1362 792 1404">• Custom System Data (TMEMCS) <li data-bbox="370 1415 935 1446">• Adjustment for next AM restart (MEMADJNX) <li data-bbox="370 1457 1472 1572">• A variable (without a PSDP parameter) for alarm buffers, buffers for fast custom parameters, and the optional extension for fast external CDS fetch (AMCL04). The number is approximately 46000 words plus the memory impact of the optional AMCL04. (Reference G.3 of the <i>CL/AM Reference Manual</i>)
MEMFREE	ROOM LEFT FOR DATABASE GROWTH (MEMFREE=AMMEMAOP-AMMEMADJ-AMMEMTOT)

Table 2-3 AM PSDP Parameters for Memory Use, continued

Parameter	Description
MEMCVBLM	<p>Current Value Buffer (CVB) SIZE FOR FAST AND SLOW PROCESSORS</p> <p>The current size for each of the 10 Fast Point Processor (FPP) and Slow Point Processor (SPP) CVBs (and related buffers). You can change this value so that the size of the CVBs changes the next time the AM is reloaded. Default=34,000.</p> <p>If you change the CVB size in MEMCVBLM, the total FPP/SPP CVB allocation is 17*MEMCVBLM. (Note: CUB allocation is included in total memory for functional adjustments.)</p>
MEMCVBTH	<p>The user-changeable alarm threshold for CVBs used by FPP and SPP. Default=1600.</p> <p>If the portion of an FPP/SPP CVB used by the system becomes larger than the value in MEMCVBTH, an alarm is generated. This alarm indicates that it is possible that the MEMCVBLM value may soon be exceeded.</p> <p>If the MEMCVBLM value is exceeded, prefetch and poststore data is lost, a (simulated) communication error occurs, and another alarm is generated. The first alarm (the MEMCVBTH alarm) indicates that the CVB size needs to be changed, less of the dynamic heap should be used (such as by deleting points, CL blocks, CDSs, and references to other nodes), or the threshold in MEMCVBTH is too low.</p>
MCVBMAXC	<p>The largest amount of memory used by an FPP/SPP CVB during the current hour. This parameter can be changed only by the system. It is used to evaluate the use of dynamic heap during actual operation.</p>
MEMCVBMX	<p>The largest amount of memory used by an FPP/SPP CVB since the last time the AM was loaded or its value was reset by the engineer. It also is used to evaluate the use of dynamic heap during actual operation.</p>
MIPCVBLM	<p>CVB SIZE FOR IPP</p> <p>If the Internetwork Point Processor has been configured in the AM, this parameter sets the sizes for each of the two IPP CVBs (and related buffers). You can change this value so that the size of the CVBs changes the next time the AM is reloaded. Default=18,000.</p> <p>If you change the value in MIPCVBLM, the total IPP CVB allocation is 9*MIPCVBLM.</p>
MIPCVBMX	<p>The largest amount of memory used by an IPP CVB since the last time the AM was loaded, or its value was reset by the user. Used to evaluate use of dynamic heap during operation.</p>
REDBFZ	<p>This parameter for the secondary AM returns the redundancy buffer size.</p>

PSDP point name

The PSDP point name is \$PRSTSnn, where nn is the AM's LCN node number. For example, to read the value of parameter MEMCVBMX in node forty, you would enter \$PRSTS40.MEMCVBMX.



REFERENCE—Section 22 of the *Engineer's Reference Manual* defines additional AM PSDP parameters.



REFERENCE—You can see AM PSDP parameter values (and you can change the values in certain parameters) by *building a schematic* that accesses the point. For one way to do this, see the example of “a display to read and store in system variables” (abstract ACC_RSS_1), in the following manual:

Actors Manual
Implementation/Engineering Operations - 2 binder.

Also, these AM PSDP parameters can be viewed and modified from some of the toolkit displays such as DATAHNG. See the following manual:

“System Performance Displays”
Engineer's Reference Manual
Implementation/Startup & Reconfiguration - 2 binder.

AM User Memory Allocation—NCF Display

Description

The AM's User Memory Allocation NCF display shows the memory totals indicating how much AM memory the user currently has allocated:

Total Memory for Functional Adjustments (AMMEMADJ)	1076974
+ Current Database Size (AMMEMTOT)	136149.0
+ Room Left for Database Growth (MEMFREE)	<u>807422.0</u>
= Total User Memory After Software Options (AMMEMAOP)	2020545.

The lower part of the display summarizes how you have used the memory available to you. (The AMMEMAOP value shown on the display may differ slightly from the above calculation, due to rounding. The difference is not of any great concern.)

Example

Figure 2-6 is an example of the AM's User Memory Allocation NCF display.




Figure 2-6 User Memory Allocation Display with Highlighted Areas

Functional

The user can make entries that affect the total for functional adjustments.

adjustments

The user's entries allocate or "use up" the remaining available user memory. The larger the value configured for any particular functional adjustment entry, the less memory is available for other functional adjustment entries.

As shown below, if you add up all the numbers in the right hand column of the User Memory Allocation display, you will notice that they equal the total for functional adjustments.

# Background CL tasks	66200
# Concurrent Data Accesses From Background CL	2100
CVB size for Fast or Slow Point Processors	170000
Redundant Buffer Increase (# of 32KW Blocks)	32768
Include Internetwork Point Processor? YES	44050
User Memory Reserved (# of 32KW Blocks)	32768
External Load Modules Code(Roundup From Next Page)	608256
External Load Module POOL1 (From Next Page)	<u>120832</u>
Total Memory For Functional Adjustments	1076974

ATTENTION

If network configuration is performed on-line with an AM that is in the "OK" processing state, the memory allocation of your AM is checked to ensure that your allocation does not exceed the memory available in your AM. A warning message appears if available memory is exceeded.

If the configuration is performed off-line, the configurator does not "know" what the available AM memory is. It is possible for you to configure an incorrect amount off-line and not be able to start your AM because the amount of total user memory has been exceeded.

Refer to Table 2-1 if you configure your AM off-line.

NCF Functional Adjustments—Background CL

Description

The background CL function is part of the standard AM product. CL programs that run in background will execute only if there is available AM processor time.

The first three entries for the functional adjustments relate to the background CL capability in your AM:

- # Background CL Tasks
- # Concurrent Data Accesses From Background CL
- Background Task Stack Size

The entries default to zero in the NCF, implying that you must make an entry if you plan to use background CL programs. If you accept the entries of zero that means you do not plan to use background CL.

Number of Background Tasks

Because a background task may be delayed by a request from data in another module (for example, SET A = TIC21243.PV, where TIC21243 is a tag in a Process Manager), and because a background task is allocated only 50 milliseconds to execute when processing time is available, it is possible that the task will not run to completion. For other points to execute their background tasks, more than one background CL task should be configured.

The actual number of background tasks to configure is a tradeoff between memory and whether your CL blocks get executed. If the number is too small, the task queue will fill up and your background CL may not execute as quickly as desired; if the number is too large, you may not have sufficient memory for your other functions.

To use the background CL function, you must enter a minimum of 1. To determine if you need a larger number, consider the following:

- The amount of AM memory available.
- The number of background programs you are writing.
- Whether any software packages require background CL.

ATTENTION

Software packages such as SPQCII. require a minimum number of background tasks. Be sure to include the amount specified for your packages in your calculations.

Concurrent data accesses from background CL

After determining how many background tasks are needed, you then determine the entry for concurrent data accesses from background CL. This entry specifies the total number of background CL initiated off-node data access requests or tasks that can be in progress at a given point in time.

The following calculation determines how much internal AM memory it will take to support additional programs to fetch/store off-node point.parameter data (data access):

$$\# \text{ concurrent data accesses from background CL}[\text{BKGDAREA}] * 1050 \text{ words}$$

Background task stack size

The Background Task Stack Size NCF entry specifies the size of the runtime stack for all the background CL tasks:

Range = 700 to 32000 words (32 kw)

Default = 25000

Typical Entry = 25000

Changing the background stack size requires an on-line NCF change, then an AM restart for it to take effect.

With foreground CL programs, the stack size is fixed at 15 kw, but dynamically allocated. In background CL, the stack size is adjustable by you through the NCF, but during runtime it becomes a fixed allocation.

Determining adequate stack size


The Processor Status Data Point parameter BKGSTACK returns the background stack size. The value, however, is the value you configured in the NCF display. To determine whether your stack size is adequate you need to monitor whether any stack overflows occur.

Calculation to determine background CL memory

The memory calculation for background CL is as follows:

$$\# \text{ background CL tasks } [\text{BKGTASKS}] * \text{ background task stack size } [\text{BKGSTACK}] + 16200$$

The 16200 is the AM internal memory it takes to support the background tasks (2000) plus memory support for CDS read/write (14200).



REFERENCE—Section 7, “AM Checkpoints” of this manual provides additional information on background CL in redundant AMs.

NCF Functional Adjustments—CVB Size (point processors)

CVBs

Prefetched and poststored data is held in Current Value Buffers (CVBs), which are the dynamic portion of heap memory. Users can change the size of the CVBs, based on an estimate of the prefetched and poststored data that is required on any processing cycle. If the CVBs are bigger, the dynamic area is bigger and less room is left for static data.

A functional adjustment entry in the AM NCF display is used to change the CVB size for fast point processors (FPPs) and slow point processors (SPPs).

Fast point processor

A point that is scheduled to run on the current processing cycle and that requires data from another node causes the fast point-processor to prefetch the data one cycle earlier (IPP off-node data is fetched on the current cycle). If the same point is to store data in another node, the data is poststored by the fast and IPP point-processor on the next cycle.

Areas of memory

The AM memory includes these basic areas:

- Fixed—Contains programs and functions and changes only on software releases.
- Stack—Memory assigned to run AM tasks. Most of this is assigned when the AM is released, however, some stack space is assigned from heap at AM startup (background CL/IPP).
- Heap—The remainder of the AM's memory. User memory is located in Heap. (The maximum amount of memory available for the heap is fixed, but the actual amount in use can dynamically change.)

Dynamic heap

The dynamic part of memory is heap that is used for LCN communications and when functions are executed in the AM.

The dynamic portion of heap is used by the system when points or CL blocks fetch or store values from or to another node.

The “system” portion of heap is reserved for the system and is not available to users. The remainder of heap is configuration dependent, and consists of an area for storage of dynamic data and an area for static data.

Conceptual overview of memory

The following figure provides a conceptual view of the entire AM memory, including the heap.




Figure 2-7 Conceptual Overview of AM Memory Including Heap

Estimating CVB Size There are various ways to estimate how many points you can build and the current value buffer size needed.

NCF Functional Adjustments—Redundancy Buffer


Redundancy Buffer In an AM redundant pair, the data from the primary AM is transferred to the secondary AM through a buffer called the redundancy buffer.

This buffer size has a base value of 122880 words. Unless a buffer overload occurs, the size of this buffer does not need to be increased.

Estimating buffer size increase In the event of a redundancy buffer overload, an AM crash or resynchronization (copying the primary AM's database to the secondary) may occur.

You need to determine whether or not the redundancy buffer size specified in the NCF should be increased to prevent an overload of the buffer.

AM Redundancy AM Redundancy is a purchased option for AMs with 68020 HMPU/AMR microprocessors, and 68040 K4LCN/EAMR. AM Redundancy includes hardware and software that allow a secondary AM to back up the operation of the primary AM. To do this, all of the application data in the primary AM is transferred to the secondary AM, where an exact copy of the data is maintained to be used if the primary AM should become inoperative.



REFERENCE—Section 7 “AM Checkpoints” of this manual provides additional information on redundancy buffer overloads and the redundancy buffer size.

NCF Functional Adjustments —CVB Size For IPP

IPP The AM can access data from one LCN to another through the Network Gateway. If internetwork access is desired with foreground programs, then the internetwork point processor (IPP) is required.

Configuration To implement the IPP, the following configuration is required:

- The AM must be configured with the internetwork capability. Selecting YES for the internetwork point processor (IPP) NCF configuration permits internetwork data access from assigned points.
- Some amount of user memory must be allocated for the IPP current value buffer.

NCF Functional Adjustments—User Memory Reserved

Description You can reserve memory for future software options with this NCF entry.



REFERENCE—Section 6, “Main Schematic” shows you how to reserve AM memory for future options.

NCF Functional Adjustments—External Load Modules

Definition Two lines in the User Memory Allocation of page 2 of the NCF display apply to software options (External Load Modules) defined on NCF page 3. When loaded into the AM, External Load Modules become part of the loaded AM personality.

Code entries The sum of just the External Load Module code entries on NCF page 2 equals the ADDITIONAL MODULE MEMORY (in Figure 2-8 this value is 729088). External Load Modules become part of the configuration-dependent portion of heap (POOL2), as indicated by this NCF entry on page 2 of the NCF display:

EXTERNAL LOAD MODULES CODE (ROUNDUP FROM NEXT PAGE)

```

22 Mar 16:27:39 1
APPLICATION MODULE NODE PAGE 3 OF 3 ON-LINE
NODE 40
ENTER EXTERNAL LOAD MODULE NAMES & ASSOCIATED PERSONALITY-TYPES:
NAME --- PERS. NAME --- PERS. NAME --- PERS. NAME --- PERS.
FILE AMO
CONV AMO
AMCL02 AMO
AMCL04 AMO
AMCL05 AMO
AMCL01 AMO

USE DEFAULT PERSONALITY TYPE? YES NO
ADDITIONAL MODULE MEMORY (WORDS) AMO 442944
TOTAL (MODULES PLUS ADDITIONAL MEMORY) 729088

FURTHER EXTERNAL DIRECTIVES? YES NO
F1=CHECK F3=SET OFFLINE F5=ABORT F7=NEXT ITEM F9=PACK NCF
F2=INSTALL F4=PRINT

```

33686

Figure 2-8 External Load Module Display—NCF Page 3

POOL1

This line on NCF page 2 is part of the total memory for functional adjustments:

EXTERNAL LOAD MODULES POOL1(FROM NEXT PAGE)

The above line means that part of the available user memory is going to be used by the system portion of the heap (POOL1). The value is automatically calculated by the system, and is done in order to have enough memory to run your External Load Module software options.



REFERENCE—Section 8 of this manual provides additional information on External Load Modules.

How to Estimate AM Memory

Requirements

To determine how many points can be built in an AM, you need to know these three things:

- The total amount of user memory available.
- The number of units configured for the AM (can be determined from your configuration data).
- The average size of each type of point.

Estimating size of point

Table 2-4 provides information needed to estimate the average size of each AM point. The table provides only an estimate. Each point has many different memory segments that are counted as "fixed;" and many optional items have more than one segment.

ATTENTION

You can save considerable time and minimize calculation errors by using a spreadsheet program on a personal computer to do the several calculations described in this section.

CAUTION

If more than fifteen adjacent units are configured with only one point built in each unit, the AM can "hang" while trying to display points. This can happen when using either ORGANIZATIONAL SUMMARIES under the System Menu, or LIST ENTITIES IN MODULE under the DEB.

The best solution is to have more than one point per unit. Alternatively, have units with one point interleaved with units that have more than one point.

Table 2-4 AM Point-Size Estimator

Point Type	Segment	Size in Words
Flag	Fixed	151
Numeric	Fixed	147
Timer	Fixed	149 General Inputs 13+ no_gi*12 General Outputs 4+ no_go*12 Prefetch/Poststore 4+ no_offnode*15 Minimum=170
Counter	Fixed	224 General Inputs 13+ no_gi*12 General Outputs 4+ no_go*12 Prefetch/Poststore 4+ no_offnode*15 Minimum=245
Regulatory	Fixed	193 (see note 2) Ratio and Bias 15 Target Value 10 PV Filter 6 PV Base 41+ no_P*3 Setpoint 12 Control Base 53+ no_X*3 General Inputs 13+ no_gi*12 General Outputs 4+ no_go*12 Control Inputs 4+ no_ci*10 PV Inputs 4+ no_pi*11 Control Outputs 3+ no_co*13 Prefetch/Poststore 4+ no_offnode*15 CL 4+ no_CL*7 (see note 1) PV Algorithms DataAcq 3 MidOf3 4 HiLoAvg 4 GenLin 56 Totalizer 16 FlowComp EqA=15, EqB=21, EqC=23, EqD=23, EqE=25 Summer EqA=7, EqB=7 + no_p*2 (23 wds, max) MulDiv EqA=15, EqB=35, EqC=35 SumProd EqA=23, EqB=35 VdtLdLag EqA=41, EqB=101, EqC=101, EqD=101

Table 2-4 AM Point-Size Estimator, continued

Point Type	Segment	Size in Words
Regulatory, continued	Control Algorithms	
	Pid	29
	PidErfb	31
	PidFF	36
	LeadLag	20
	AutoMan	9
	RatioCtl	11
	MulDiv	23
	RampSoak	64
	IncrSum	26
	OrSel	4
	Switch	4
	CL	3
	Summer	EqA=7, EqB=7 + no_x*2 (15 wds, max)
	Rolling Average Algo- rithm	21 + 2* no_rolling average samples (see note 3) 4+ no_swh*29
	Misc. Segments	15
Switch	4+ no_cds*2 (see note 1)	
Switch Alarm	2+ no_pkg*4	
CDS	Minimum=193	
Pkgname		
Custom	Fixed	139
	CL	4+ no_cl*7 (see note 1)
	Prefetch/Poststore	4+ no_offnode*15
	CDS	4+ no_cds*2 (see note 1)
	PkgName	2+ no_pkgs*4 Minimum=153
Switch	Fixed	143
	CL	4+ no_cl*7 (see note 1)
	Prefetch/Poststore	4+ no_offnode*15
	Switch Segment	4+ no_switch*29
	Switch Alarm	15
	CDS	4+ no_cds*2 (see note 1)
	PkgName	2+ no_pkgs*4 Minimum=205

- Note 1: This table does not include the sizes of CL blocks and custom data segments. These are provided in B.2 "CL/CDS Capacities" in the *CL/AM Reference Manual*.
- Note 2: AM regulatory points are computed differently than the other points. All items after fixed size are optional.
- Note 3: With R640, the AM user memory space is twenty-one words plus the words for two times the number of rolling average samples. The AM checkpoint space in the snapshot buffer and on the HM checkpoint space is twenty-one words but does not require space for the sample buffer.

Table 2-4 AM Point-Size Estimator, continued

LEGEND:

no_x: Number of x inputs
no_p: Number of P inputs
no_gi: Number of general-input connections (8 max)
no_go: Number of general-output connections (8 max)
no_ci: Number of control-input connections (8 max)
no_co: Number of control-output connections (8 max)
no_offnode: Number of references to parameters in another node, rounded up to the nearest multiple of 3. Off-node control-output connections take 5 off-node references in the prefetch/poststore segment. A point in a different unit in the same node must be considered as an off-node point.
no_switch: Number of Switches — Minimum of 1
no_cl: Number of CL blocks
no_cds: Number of CDSs
no_pkg: Number of CL packages
EqA – EqE: Equation A, B, C, D, or E

Example

As an example of the use of Table 2-4, consider a regulatory point with a Summer PV algorithm using equation B and two PV inputs, a PID control algorithm, and one control output. The average size is as follows:

Fixed		193
PV Base	= 41 + 2*3	= 47
Control Base	= 53 + 1*3	= 56
PV Input	= 4 + 2*11	= 26
Control Output	= 3 + 1*13	= 16
PV Summer	= 7 + 2*2	= 11
Pid		29
Setpoint		<u>12</u>
	TOTAL	390 words

If all connections are to points in another node (off node):

$$\begin{aligned} \text{Prefetch/Poststore} &= 4 + (5 + 2, \text{ rounded up to a multiple of } 3) * 15 \\ &= 4 + 9 * 15 = 139. \\ 390 + 139 &= 529 \text{ words.} \end{aligned}$$

Optimizing CVB Size

Purpose

If there was some assurance that the greatest use of FPP/SPP CVB memory that could ever occur in an AM had already occurred and that value was in MEMCVBMX, you could set MEMCVBLM to that value, change MEMCVBTH to a value below MEMCVBLM by some safe amount, checkpoint, and reload the AM. This is not likely though, because points and CL structures can be added at any time. They are two methods for estimating the best value for the CVB size. The value is then entered into the AM's NCF display.

Method 1

One way to estimate the best value for the FPP/SPP CVB size is to build the database, load and run the AM long enough for all points to be processed, then evaluate the memory-allocation data. Figure 2-9 shows this process.




Figure 2-9 A Method for Estimating Memory-Allocation Values

ATTENTION

If you try to increase the value in MEMCVBLM for an AM whose static heap is as full with configuration data as it can be, the new value is rejected. In such a case, you have to delete units, points, or CL structures, increase MEMCVBLM, checkpoint, and reload the AM.

Method 2

Another method for estimating the maximum CVB size is to evaluate the points that refer to points in other nodes. Table 2-5 shows the number of CVB words required for each type of prefetched and poststored data.

Table 2-5 CVB Words vs Data Types

Prefetched or Poststored Data Type	CVB Words Used (see Note 1)	
Inputs related to control-output connections	15	
PV fetched by a control or PV-input connection	8	
Real Value input or output by CL, control, or general I/O	4 (single value)	$2*n + 4$ (array) (see Note 2)
Enumeration value	9 (single value)	$2*n + 4$ (array) (see Note 2)
Parameter ID	3	
Entity ID	6 (single value)	$4*n + 6$ (array) (see Note 2)
Boolean value	3 (single value)	$n + 3$ (array) (see Note 2)
Integer value	3	
Time value	5 (single value)	$3*n + 5$ (array) (see Note 2)
String value	3 + 1 per 2 characters	
Note 1. For any output (poststore), add five words to the result.		
Note 2. CL prefetches an entire array; n represents the number of elements in the array. For array poststores, individual elements are stored.		

**Method 2 example—
single point
estimate**

Consider the following processing example of the AM point in Figure 2-10:

- If TC100 is scheduled to be processed once each second, its PV input is prefetched from T101 and stored in a CVB one cycle (one-half second) before TC100 is processed. Because TC100's OP value can be initialized by FRC200, additional information is prefetched from FRC200 and stored in the CVB.
- One cycle after TC100 is processed, its OP value is poststored in FRC200 after having been stored in the CVB; therefore, the CVB has to hold the prefetched data until the next time TC100 is processed, while it is also holding the poststored information from TC100's last processing pass.

Now we apply the values in Table 2-4 to this example:

Inputs related to the control-output (OP) connection	= 15
The PV input	= 8
The real-number output (OP)	= <u>9</u>
(5 added because it is an output)	
CVB words for this point	= 32




Figure 2-10 Example of Estimating Memory-Allocation Values

**Method 2 example—
estimate for entire
AM**

To estimate the maximum CVB needed for the entire AM, evaluate the AM process database, as in the following example.

If the fully configured AM is to do 150 prefetches and poststores for each processing interval, and 30% of these are inputs related to control-output connections, 50% are PV inputs, and 20% store real-number outputs, then the CVB needed is calculated as follows:

$$\text{CVB} = 150 * (30\% * 15 + 50\% * 8 + 20\% * 9) = 1545 \text{ words.}$$

This value does not include unusual processing, such as process-special and CL fetches and stores caused by some alarm condition. So to be safe, MEMCVBLM might be set to 2000 words.

ATTENTION

Remember that data transfers within the same AM do not require prefetches and poststores, so they do not use CVBs.

ATTENTION

Increasing the CVB size reduces the static heap available for configuration data. Decreasing the FPP/SPP CVB size increases the risk of threshold (MEMCVBTH) alarms, and worse, it increases the risk of losing FPP/SPP prefetched and poststored data. Decreasing the IPP CVB size increases the possibility of IPP processing overruns.

If you have ample memory for your data points and CL structures and if you never experience FPP/SPP CVB alarms and have few or no IPP CVB overrun alarms, there is no need to change the CVB size.

Procedure

Table 2-6 describes the procedure to change the CBV size.

Table 2-6 Procedure to Change CVB Size

Step	Action
1	Specify a backup NCF pathname on the default volume pathnames display.
2	On the Engineering Main Menu, select LCN NODES RESULT: The LCN Node Configuration display appears.
3	Select the node number of the AM whose MEMCVBLM and/or MIPCVBLM value is to be changed (may need to press [PAGE FWD]) RESULT: The Application Module Node display appears.
4	Select MODIFY NODES. RESULT: Page 2 of the Application Module Node display appears.
5	To change MEMCVBLM, key in a new value in the port labeled CVB SIZE FOR FAST & SLOW POINT PROCESSORS, and press [ENTER]. To change MIPCVBLM, key in a new value in the port labeled CVB SIZE FOR IPP, and press [ENTER]. RESULT: The AM Node display reappears with the new value in blue (cyan). If there are errors in the value you entered, they are noted in red. The values in the MEMORY USED column also change.
6	Hold [CTL] and press [F1] to run the checker. RESULT: The "Modify Node" display appears with instructions for installing and loading the change you just made.
7	Follow the instructions, including shutting down and reloading the AM). RESULT: PSDP parameters MEMCVBLM and MIPCVBLM assume the current values, and the memory reserved for CVBs changes accordingly.

AM Database Size

Description

The AM database size is determined by the following:

- Point Data,
- Largest Checkpoint Buffer,
- CL Blocks, and
- Custom Data Descriptors.

Example

Assume that the average number of words per point is 300, including a factor for shared and unshared CL blocks and custom data descriptions (This assumes some regulatory control points, some simpler points, and a few points with little CL.)

Further assume for the purpose of the calculation of the checkpoint snapshot buffer size, that all units in the AM are the same size.

Then the following list indicates the number of points that would fit into a 3 Mw AM as a function of the number of units:

Number of Units	Total Number Of 300-Word Points*	Number of Units	Total Number of 300-Word Points*
1	732	11	1239
2	972	12	1236
3	1113	15	1219
4	1150	16	1218
5	1188	30	1165
6	1212	45	1082
9	1239	62	980
10	1240		

*Assumes an equal number of points per unit.

ATTENTION

Clearly, the above example is a simplification. The number of points that can fit into an AM depends on the following additional factors:

- The average complexity of the points, including CL and custom data use.
- The number of units (small impact).
- The size of the largest unit (large impact).

Section 3 - ADDING AND MOVING AM PROCESS UNITS

This section provides guidelines for adding units to an AM, and for moving units from one AM to another.

How to Add a New Unit to an AM

WARNING

If more than fifteen adjacent units are configured with only one point built in each unit, the AM can “hang” while trying to display points. This can happen when using either ORGANIZATIONAL SUMMARIES under the System Menu, or LIST ENTITIES IN MODULE under the DEB.

The best solution is to have more than one point per unit. Alternatively, have units with one point interleaved with units that have more than one point.

New units are added to an AM by adding the unit in Network Configuration (UNIT NAMES and LCN NODES), and then restarting the AM with the revised NCF, using the checkpoint last saved for the AM as the data source.

Previous to R600, to add a unit to an AM, you had to delete the AM node and then add the node back with the desired changes. With R600, you can now add or delete units and change the startup mode without first deleting the node and then re-adding the AM node. This is done by first selecting the existing “Modify Node” target and then making the desired change.

After the desired changes have been made on-line and installed, the node and other affected nodes must be reloaded. Refer to *Network Data Entry*, Table 7-25 to delete an AM and *Network Data Entry*, Table 7-24 to add an AM.

When an AM is started the first time, before any checkpoint files with user data are available, you use the null-checkpoint volume supplied by Honeywell. This creates the node directory for this AM (&Znn), but no unit directories (&Fuu) exist yet. The &Fuu directories and checkpoint files for configured units are created the first time a checkpoint is saved for the AM.

Use the following steps to add the new unit directory (the AM's checkpoint volume will have to be large enough to accept the new directory—see Section 6). In these steps,

uu is the unit index. The index is the position you configured on the Unit Names Display, not your Unit ID. For example, if BB was the third unit configured on the Unit Names Display, the index is 03 (for uu = 100, enter 00).

np is the node pair number for the HM that contains the node directory (&Znn) for the AM.

1. Use the Command Processor to create the checkpoint directory for the new unit. This is the form of the command line:

```
CD NET>&5np> &Fuu
```

2. Copy the master checkpoint file for this unit from the &AMC cartridge or floppy.

```
CP $Fn>&AMC>AM0uuMAS.CP NET>&Fuu>= -V
```

3. NULL checkpoints are write protected on the distribution media. They must be unprotected or the checkpoint will fail.

```
UNPROT NET>&Fuu>*.*
```

4. Reconfigure the network to establish the new unit (see *Network Data Entry* in the *Implementation/Startup & Reconfiguration - 1* binder). Then use the AM Status display to shutdown and reload the AM, using the last checkpoint saved for this AM as the data source for reloading (use any one, or the restart options—hot, cold, warm, or no processing). The remaining checkpoint files for the new unit are established in your new &Fuu directory.

How to Move Units From One AM To Another

WARNING

Moving units requires caution. For example, if you use AMCL05, the AM Extension for Off-Logical-Node-Access, and subsequently move a unit containing any of the involved references off-physical-node (to another AM), the AM will not be able to perform the references. At startup, you will get one or both of the following status messages indicating the units with invalid references.

Bad Direct References on unit: xx (most likely message)

Bad Indirect References on unit: xx

You may also get a WARNING node status, depending on the nature of the reference. If the situation is not corrected, you will get configuration errors at run time. If this error occurs, you will have to unlink the CL, relink the CL, checkpoint, and reload the AM.

Previous to R600, to add a unit to an AM, you had to delete the AM node and then add the node back with the desired changes. With R600, you can now add or delete units and change the startup mode without first deleting the node and then re-adding the AM node. This is done by first selecting the existing “Modify Node” target and then making the desired change.

After the desired changes have been made on-line and installed, the node and other affected nodes must be reloaded. Refer to *Network Data Entry*, Table 7-25 to delete an AM and *Network Data Entry*, Table 7-24 to add an AM.

If you move a unit from one AM to another, the old checkpoint files can be used to reload the AMs. Use the procedures that follow.

On a system without HMs—After the system is restarted with the new NCF, when you reload the AM from a removable medium, a prompter requests the checkpoint medium that contains the "new" unit. You should then mount the cartridge or floppy that has the checkpoint from the AM where the unit previously resided and continue the loading process.

On an HM-based system

- **Case 1:** The original AM checkpoint volume and the new AM checkpoint volume reside on the same physical HM.

Action: None.I

- **Case 2:** The original AM checkpoint volume and the new AM checkpoint volume reside on different physical HMs. Note: For this case, be **sure** that you delete the unit from the original AM—the system does not check for duplicate unit numbers in AMs that have checkpoint volumes on different HMs.

Action: Use the Command Processor to move the unit's checkpoint directory from the original AM's checkpoint volume to the new AM's checkpoint volume (the new AM's volume will have to be large enough to accept the new directory—see Section 6). Use steps 1 through 5, below, to do this.

WARNING

In the following procedure, be very sure that you use the correct unit index (uu). If you enter a wrong number, you might move the wrong checkpoint or you might delete the wrong checkpoint.

In the following steps,

uu is the unit index. The index is the position you configured on the Unit Names Display, not your Unit ID. For example, if BB was the third unit configured on the Unit Names Display, the index is 03 or 003 (for uu = 100, enter 00).

np is the node pair number for the original HM, and mp is the node pair number for the new HM.

1. Use the AM Status Display to do a demand checkpoint (SAVE DATA) to a cartridge or floppy.

WARNING

The next step deletes the HM copy of the checkpoint (database). Until you restore the checkpoint on the new HM (step 5), you will be completely dependent on the checkpoint copy on your cartridge or floppy. For additional security, make a backup copy of the checkpoint on another cartridge or floppy, before going on to step 2.

2. On the original HM, delete all the files in the directory with the checkpoint for this unit. This is the form of the command line:

```
DL NET>&Fuu>*.*
```

3. Delete the directory from which you just deleted the files.

```
DD NET>&Fuu>
```

4. Create a checkpoint directory for the unit on the new HM.

```
CD NET>&5mp> &Fuu
```

5. Copy the checkpoint from the removable medium to the new directory on the new HM.

CP &Fn>&Fuu>*. * NET>&Fuu>=

NOTE

If different versions of the same custom data segment (CDS) exist in two different units in the same AM (because one of the units has been moved into this AM), on startup, the points with the older segments are alarmed, and those segments are deleted. If this occurs, to reestablish a valid database, you must rebuild the points affected, reattaching the proper segment.

Section 4 - USER-CORRECTABLE “SOFTWARE” ERRORS

This section provides guidelines for recovering from errors reported in the real-time journal by AM software tasks.

There are several errors that can occur while an AM is being loaded or while it is on-line. The error messages contain the word SOFTWARE, but these errors are not problems in the software. They are conditions that can often be corrected by the user.

Error Message Format

The error messages are real-time journal messages. They are printed (journalized) on a printer in this form:

(time)(node type/number)(task name)SOFTWARE(three hex nos.)(4 decimal nos.)

In most cases, an auxiliary status message containing additional information appears on the Auxiliary Status display and also is journalized preceding the error message.

Interpretation and Remedies

Table 4-1 — Errors and Remedies

Task Name	Leading Decimal Digits	Meaning	Remedy
B\$IPP B\$EVD B\$NST L\$CLL data_access B\$PRSTS	419 121 195 or 309 29, 41, or 45 14, (integer),0, 13501 224	AM ran out of memory during a load.	Add memory to the AM (see Section 2) or change Network Config. to reduce the number of units.
B\$NST	336 and the last decimal digit is 4	Master file for a unit is missing from the HM during a load.	Determine the missing file and copy from a cartridge or floppy to the HM.
B\$NST L\$CLL	336 and the last decimal digit is 5 37 or 38	Time out while waiting for a volume to be mounted during a load. File required for a load is missing.	Start over Determine missing file and copy to startup medium (cartridge, floppy, or HM).

Table 4-1 — Errors and Remedies, continued

Task Name	Leading Decimal Digits	Meaning	Remedy
L\$CLL	49	Invalid CL catalog encountered during a load.	Start over using valid catalog.
B\$RED_TASK	239	Primary-Secondary personality revision/ version mismatch	Restart both primary and secondary with same personality version/revision.
B\$RED_TASK	240	Redundancy hardware failure	Replace AMR board in primary AM, or replace AMR board in secondary AM.
B\$RED_TASK	241	LCN failure	Refer to <i>LCN Guidelines</i> in the <i>LCN Site Planning & Installation</i> binder.
(Any Task)	252	Redundancy hardware failure	1st check AMR board in secondary AM, then check AMR in primary AM.
B\$RED_TASK	245	Redundancy hardware failure on start up	1st check AMR board in secondary AM, then check AMR in primary AM.
B\$RED_TASK	347	Primary and secondary memories do not compare.	1st check AMR board in secondary AM, then check AMR in primary AM.
B\$RED_TASK	238	Resynchronization during secondary startup	Try the startup again.
B\$RED_TASK	250	Secondary buffer overflowing repeatedly	Add to redundancy buffer size (see 7.1.3.1).
Data_Access	265	Primary switchover during secondary startup	Restart both primary and secondary.

Table 4-1— Errors and Remedies, continued

Task Name	Leading Decimal Digits	Meaning	Remedy
B\$NST or B\$RED_TASK	266	Primary and secondary memory mismatch	Check memory boards in primary and secondary.
B\$RED_TASK	296	Repeated redundancy bus errors	Check AMR board in secondary AM.
B\$RED_TASK	242, 1, -5, 17	Secondary ROM full error	Check AMR board in secondary AM.
B\$NST	389	Illegal node config., 68000 microprocessor used in one of the redundant AMs.	If the boards are different, replace the older microprocessor with an MPU or K4LCN board.
B\$NST	335, and the last two decimal digits are 19	File for unit referenced in master file missing during a load.	Retry, use backup checkpoint, or call Honeywell.
B\$PRSTS	226	Point-processor overrun.	AM is overloaded. Either reduce the load by setting points inactive, or reconfigure the AM with fewer units.
B\$PRSTS	227	CL block in an infinite loop or point-processor overrun	If you can't determine which CL block has an infinite loop, call Honeywell. If you have a processor overrun, see the remedy above.
data_access	26,0,0,13705	During startup, a CDS's rev. code doesn't match an existing CDS.	Call Honeywell.
data_access	16,(intgr.),0,13503 or 4,(integer),0,1309 or 4,(intgr.),0,13098	Unrecoverable file error during a load	Copy DSD files from \$ASY floppy to HM and retry. (For a system with no HMs, retry with a new &ASY cartridge or floppy.)

Table 4-1— Errors and Remedies, continued

Task Name	Leading Decimal Digits	Meaning	Remedy
data_access	15,(intgr.),0,13502 or No DSD (integer) or 4,(intgr.),0,13096 or 4,(intgr.),0,13099	DSD file required for a load is missing.	Copy DSD files from \$ASY floppy to HM and retry. (For a system with no HMs, retry with a new &ASY cartridge or floppy.)
data_access	15,(intgr.),0,23903	File DUPLICAT.SP missing from &ASY vol.	Reload a US with Operator Personality or Eng. Personality to recreate the missing file.
data_access	16,(intgr.),0,23905 or 16,(intgr.),0,23907 or 18,(intgr.),0,23909	Unrecoverable file error during a load.	Delete the DUPLICAT.SP file from &ASY and reload a US with Operator Personality or Eng. Personality to recreate DUPLICAT.SP on &ASY.
data_access	4,(intgr.),(intgr.), 29306	File DUPLICAT.SP is wrong version	Delete the DUPLICAT.SP file from &ASY and reload a US with Operator Personality or Eng. Personality to recreate DUPLICAT.SP on &ASY.

Section 5 - OBTAINING AM SCHEDULE INFORMATION

This section provides instructions for obtaining a report that you can use to analyze AM point scheduling.

Initiating the AM Schedule Dumper

An AM Schedule Dumper is available to provide you with a printed or displayed report that provides cycle-loading and scheduling information for the data points in an AM unit. The report shows loading information for each processing cycle and it shows the processing order (schedule) for each point on each processing cycle. You can use the information in the report to determine if you should rearrange processing schedules or if you need to adjust processing-cycle loading. Refer to 2.2.1 in *Application Module Control Functions*, in the *Implementation/Application Module - 1* binder, for information on AM point-processing schedules and processing-cycle loading.

The dumper places the report in a file in a user-specified volume on an HM. You can use the Command Processor Print command to display or to print the content of the report.

NOTE

With R600, a new tool is provided called the **AM Load Balance Tool**. This tool will analyze the information in the AM Schedule Dumper file and provide a composite set of results for all units in the AM. The AM Load Balance Tool provides a graphical representation of point loading per cycle on a specified AM, thus making the current process easier. Additional information on how this new tool works is provided in Section 6 of this document.

Perform the following steps to dump the schedule information for a unit in an AM:

1. In the following PSDP parameter, store a complete pathname that points to a new file you want to create, on one of your HM user volumes or directories; (see 22.1 in the *Engineer's Reference Manual* for a method for using a schematic display to do this):

```
$PRSTSnn.AMSCHDMP(uu)
```

where nn is the AM node number and uu is the unit index number (not the unit name). You can see a list of the unit index numbers and the unit names through the UNIT NAMES pick on the Engineering Main Menu. Use 00 as the unit index number to dump the schedule information for all units.

The pathname is in this form (schedule dumps to a removable medium are not allowed).

```
NET>usrv>file.zz
```

As soon as the pathname is stored, the schedule for the unit named begins to be dumped into the user file. An operator message is generated if any errors are detected during the dump operation, and a message is generated when the dump is complete. You can see these messages by pressing the MSG SUMM key on the Operator's Keyboard of a US that is running the Operator Personality and has an area to which the AM unit is assigned.

- To display or print the schedule information, execute a Command Processor Print command (see 5.21 in *Command Processor Operation*, in the *Implementation/Startup & Reconfiguration - 1* binder).

The following figure shows the form and content of the schedule report




Figure 5-1 — Schedule Report

Interpreting the AM Schedule Printout

The Schedule Data Base printout is organized by units. For each unit, the information is divided into two major parts.

- Cycle Loading Information—tabular information that shows the number of points that will be accessed on each processing cycle.
- Point Scheduling Information—lists that show the individual points that are assigned to each of the processing threads by frequency and by cycle.

Format of the Cycle Loading Information

There are three sets of cycle loading tables. One each for FAST, MINUTE, and HOUR processing. The cycle processing tables are further organized into four sets of three columns each.

Columns headed “FAST” contain cycle numbers

- 0-239 for two minutes of 1-second to 2-minute FPP processor threads, and
- 0-23 for two minutes of 5-second to 2-minute IPP processor threads.

Columns headed “MINUTE” contain cycle numbers

- 0-59 for one hour of 1S-minute to 1-hour SPP processor threads, and
- 0-59 for one hour of 5-minute to 1-hour IPP processor threads.

Columns headed HOUR contain cycle numbers

- 0-23 for 24 hours of 8-hour to 24-hour SPP or IPP processor threads.

The columns headed “FPP” or “SPP” contain the counts of total number of points of that type that are processed on that cycle. For example, the first entry for FPP in the “FAST” cycles portion shows the total number of 1-second to 2-minute points for FPP Cycle 0, while the first entry under SPP in the “MINUTE” cycles portion shows the total number of 1S-minute to 1-hour points for SPP Cycle 0.

The columns headed “IPP” contain the counts of total number of points of that type that are processed on that cycle. For example, the first entry for IPP in the “FAST” cycles portion shows the total number of 5-second points to 2-minute points for IPP Cycle 0, while the first entry for IPP in the “MINUTE” cycles portion shows the total number of 5-minute to 1-hour points for IPP Cycle 0.

Format of the Point Scheduling Information

The point scheduling lists consist of three columns of point names listed in processing order from left to right and top to bottom. They are organized by threads (1-second through 24-hour types) and by cycle within the thread type.

For example, the 1-second threads are subdivided into cycles 0 and 1, while the 5-second threads are subdivided into cycles 0 through 9 for FPP points and cycles 0 and 1 for IPP points. FPP and IPP points are both listed, but IPP points are differentiated by a "*" prefix. The process special thread and IPP process special thread show snapshots of the thread contents at the time the dump is requested, and may contain points for units other than the unit requested.

Note that only those cycles that have points assigned will be shown on this printout.

Additional Information About AM Point Scheduling

The automatic scheduling of point processing with multiple units in the same AM is independent on a per unit basis. With multiple units where each unit has one AM point scheduled at a one-second frequency, all of these points would execute on the same cycle (zero). The reason for this separation of unit scheduling is that AM unit databases can be moved to or from other AMs and this separation is required to maintain the unit database order.

The schedule dumper is a tool that tells you how many AM points are processed during a one-half second (fast processor), five-seconds (internetwork processor/IPP), and a minute or hour (slow processor/IPP). The BEFAFT parameter option of CYCLE can be used so NORMCYCL parameter can specify the processing cycle.

The NORMCYCL definition in the AM Parameter Dictionary shows the base number of cycles for FPP is 240 within a two-minute period, 24 cycles for IPP within the same two-minute period, and two cycles for SPP with the same two-minute period. The faster FPP points repeat their periodic scheduling within this 240 cycles (for example: the 120 one-minute cycles would repeat twice within the two-minute period).

The SPP one-minute points repeat twice within the 240 FPP cycles, the SPP two-minute points execute once within this 240 cycles and the larger SPP periods would process only a portion of their points within this 240 cycles. The SPP point scheduling is spread across the one-half second periods during the FPP two minutes and will remain on a particular one-half second cycle until a point rebuild or scheduling change happens. You cannot easily determine the SPP points processed at each FPP one-half second.

There is a time relationship between SPP and FPP because the FPP processor executes the scheduling to initiate point processing for both FPP and SPP a one-half second before the actual processing occurs.

Both SPP and FPP scheduling starts at the same absolute time (AM reload time), however, the actual execution of processing (algorithms and CLs) on FPP and SPP points does not occur at the same time. You can tell the AVERAGE points per second SCHEDULED on SPP and FPP by looking at parameter PRAVGC, however, this is not the same as the actual points which completed processing in the same one-half second. What points get scheduled by FPP to a particular one-half second can change for reasons other than point rebuilding and may affect the processing average (such as: process special PPS requests and point activation PTEXECST status).

The faster IPP points repeat their periodic scheduling within these same FPP 240 cycles (for example: the 12 one-minute cycles would repeat twice in a two-minute period). IPP point scheduling is independent of FPP and SPP scheduling (the cycles are not synchronized).

There are Data Entity Builder (DEB) AM point building tools that allow users to override the AMs automatic assignment to the least loaded cycle in the schedule (BEFAFT, BEFAFTID, NORMCYCL). The NORMCYCL option has a one-half second resolution for FPP, a five-second, one-minute, and one-hour resolution for IPP, and a one-minute and one-hour resolution for SPP. For the SPP cycle assignment the AM automatically assigns the SPP points to the same one-half second cycles used by FPP.

You can relate cycle PSDP parameter values to clock time. The PRMCYCL, PRMXCYCP, PRMNCYCC, and PRMNCYCP start counting when the AM is loaded. the values reset to zero when the AM is shutdown and reloaded, however, the values continue to count on a failover to a redundant AM. The absolute time for the AM load can be seen in the Event History for AM node load or can be displayed on the AM NODE "Status Detail" display page but is not available as a parameter.

You should be able to attach absolute processing cycle to a real system time by

- dividing the cycle value by 7200 (the number of cycles in an hour),
- then add the quotient (number of hours) to the AM reload time hours,
- convert the cycles remainder to minutes (divide by 120 [the number cycles in a minute]), and
- then add to the reload time minutes.

Subtracting these quotient and remainder times from current time should also approximate the AM reload time within the hour. The AM system cycle counter is continuously updated and would roll over at 4294967295 cycles (or 24855 days). The PRMNCYCC, PRMNCYCP, and other PSDP values are converted to a 24-hour value (or 172800 cycles).

AM Overrun Diagnostic Display (SMCC)

A display called "AM OVERRUN DIAGNOSTIC" is provided in the SMCC main menu. This display may be called if an AM has failed and it will show the point name and CL block name (if applicable) that the AM was processing at the time of the failure.

In addition, new PSDP parameters have been added to determine the points, which take the longest time to execute. Separate lists will be maintained for the fast and slow point processors. The longest running CL block name along with its associated point will also be saved. Another parameter of the AM PSDP is used to switch the collection of the other parameters ON or OFF. The switch parameter will not switch off the saving of the point name and CL block name that is used for the crash statistics.

A running AM may be diagnosed by using the AMDIAGNS display from the Toolkit set of schematics directory TLK1. Additional information on the use of this Toolkit is provided in the "System Performance Display" section of the *Engineer's Reference Manual*.

Additional information on the use of the SMCC AM Overrun Diagnostic display is provided in the "Using SMCC Displays" section of the *Maintenance Test Operations Manual*.

Section 6 - AM LOAD BALANCE TOOL

Section 6

This section provides the user with a graphical representation of the point loading per cycle on a specified AM.

Overview

Background

Currently, the AM point build uses the schedule point period to load the point processor cycles. This is done on a per unit basis and is only visible through the AM utility function Schedule Dumper for one unit at a time. If a request for all AM units is made to the Schedule Dumper tool, then the schedule information is provided to a file unit by unit, individually.

With R600, the AM Load Balance Tool will analyze the information in the AM Schedule Dumper file and provide a composite set of results for all units in the AM. This tool provides a graphical representation of point loading per cycle on a specified AM, thereby making the current process easier.

Tool Location

The AM Load Balance Tool is found on the &C3 cartridge in the TLK2 directory of the R600 general release.

Installation

Installation instructions for the AM Load Balance Tool are included as an electronic text file (AMCYHLP.XI) in the tool software, TLK2 directory.

Operating Instructions and Examples

This subsection describes and gives examples of the schematics and the cycle report that make up the AM Load Balance Tool.

Main Schematic - \$AMCYLD

The following display is an example of the Main Schematic used to operate the AM Load Balance Tool. The numbered screen selections and targets on this example correspond with the descriptive information on the next page.




Figure 6-1— Example of the Main Schematic - \$AMCYLD

Main Schematic—Screen Selection and Target Information

The following information is numbered to correspond with each of the screen selections and targets on the Main Schematic example on the previous page.

1. **SELECT AM** target—when the display is invoked for the very first time, only the SELECT AM target will be active.
2. **ANALYZE AM** target—after a valid AM node number has been entered, the ANALYZE AM target will become active.

In the following example, because the schedule dump file does not exist, the user will be prompted to enter the UNIT index and the AM Schedule Dumper file will then be created and analyzed.

Enter AM Unit Index (00=ALL): 04 Jun 98 10:39:27 9

\$AMCYLD AM CYCLE LOADING HELP SELECT AM
ANALYZE AM

AM Node Number: 29
Message: AM SCHEDULE DUMP FILE DOES NOT EXIST
AMSCHDMP Filename: NET>AMLD>AM29LOAD.XX 0 00:00:00

17475

In the following example, because the AM Schedule Dumper file already exists, the user will be asked whether they wish to create a new AM Schedule Dumper file or use the existing one.

Create NEW File? (1=YES,0=NO) 04 Jun 98 10:37:26 9

\$AMCYLD AM CYCLE LOADING HELP SELECT AM
ANALYZE AM

AM Node Number: 29
Message: AM SCHEDULE DUMP FILE EXISTS
AMSCHDMP Filename: NET>AMLD>AM29LOAD.XX Jun/04/98 10:22:38

17476

NOTE:The creation of the AM Schedule Dumper file for **all** units could take up to **5** minutes.

3. **CREATE REPORT FOR CYCLE xxx** target—after the Schedule Dumper file has been created, the CREATE REPORT FOR CYCLE xxx target will become active. This can be used to give a specific cycle's points. The points on the most heavily loaded cycle will be the default contents of the AMnnLIST.XX file. An example of AMnnLIST.XX file is shown on the following page.

4. **CYCLE** Target—a user can select a specific cycle using the CYCLE target, or can choose one by one using the left and right targets. This value of the CYCLE is what is used in the CREATE REPORT FOR CYCLE xxx target.
5. **PERCENT COMPLETE** graph—the PERCENT COMPLETE graph will only be shown while the ANALYZE AM target and the CREATE REPORT FOR CYCLE xxx target are being executed.
6. **DISPLAY REPORT FOR CYCLE xxx** or **PRINT REPORT FOR CYCLE xxx** Targets—by selecting the DISPLAY REPORT FOR CYCLE xxx or PRINT REPORT FOR CYCLE xxx targets, you can view the report file (AMnnLIST.XX) for the given cycle. The current report may be a different cycle than the value shown in the CYCLE target. See Figure 6-3 for an example of this report. The targets will not be active until the point list is available.
7. **TIME STAMP**—the timestamp of the AM Schedule Dumper file is provided to the user to show when the last AM Schedule Dump was created. The user can then decide if they need to create a new schedule dump.
8. **HELP** Target— selecting the HELP target on the Main Schematic will bring up the Help Schematic. This Schematic provides a good overview on how the AM Load Balance Tool operates.

Help Schematic - \$AMCYHLP

The following display is an example of the Help Schematic; it is obtained by selecting the HELP target on the Main Schematic. This schematic provides an overview on how the AM Load Balance Tool operates.

Once at the Help Display, the PRIOR display button or the RETURN target will return the user to the Main Schematic.

The screenshot displays the 'AM CYCLE LOADING HELP' interface. At the top center is the title 'AM CYCLE LOADING HELP' and at the top right is a 'RETURN' button. On the left side, there are several target buttons: 'SELECT AM', 'ANALYZE AM', 'CREATE REPORT FOR CYCLE XXX', 'DISPLAY REPORT FOR CYCLE XXX', 'PRINT REPORT FOR CYCLE XXX', 'CYCLE', and '<' and '>' buttons. To the right of these buttons is a list of descriptions for each target.

Target	Description
SELECT AM	- Select this target to choose a valid AM node.
ANALYZE AM	- Select this target to create and analyze the AM Schedule Dumper file. A cycle Loading Graph will then be created. The most heavily loaded cycle will be blinking.
CREATE REPORT FOR CYCLE XXX	- Select this target to list the points on a specific cycle. The default report will be the points on the most loaded cycle. The value for cycle can be modified by selecting the CYCLE target.
DISPLAY REPORT FOR CYCLE XXX	- Select this target to display the list of points on the specified cycle. Replaces current schematic and required PRIOR button to return.
PRINT REPORT FOR CYCLE XXX	- Select this target to print the list of points on the specified cycle. User will be prompted for printer number.
CYCLE	- Select this target to enter a specific cycle (0-239).
< >	- Select these targets to change the cycle value by 1 (<) or +1 (>).

17477

Figure 6-2 —Example of the Help Schematic - \$AMCYHLP

Cycle Report - AMnnLIST.XX File

The following file is an example of the AM Load Balance Tool cycle report.

The AMnnLIST.XX file contains a list of tagnames that exist on a specified AM cycle. The user creates this file by selecting the CREATE REPORT FOR CYCLE xxx target. The contents of this file are obtained by using the DISPLAY REPORT FOR CYCLE xxx target or PRINT REPORT FOR CYCLE xxx target.

```
AM CYCLE LOADING POINT LIST
AM NODE 29 , CYCLE 110
NO. POINT                STATUS  PERIOD  CYCLE
--  -----                -
1  AMTREND10                1SEC   0
2  HEAPFREEMODE_19         1SEC   0
3  R520TIM                 INACTIVE 2SEC   0
4  545_AM01                2SEC   0
5  AMNULLP7                5SEC   0
6  R520REG                 INACTIVE 5SEC   0
7  CEE2                    10SEC  0
8  545_AM04                INACTIVE 10SEC  0
9  AMTREND9                1MIN   110
10 AMNULLP1                INACTIVE 2MIN   110
END OF AM CYCLE LOADING POINT LIST
```

Figure 6-3 —Example of a Cycle Report - AMnnLIST.XX File

Usage of the AM Load Balance Tool

Current Operation

Currently, the engineer builds many points to different units in AM 29. These points have periods of 1 SEC, 2 SEC, 5 SEC, 10 SEC, etc. Over time, the engineer begins to notice that the AM gets overruns during certain times, every several minutes. The engineer suspects that the scheduling of points is the problem and decides to do a schedule dump of the AM for all of the units.

The PERFMENU schematic called DATAHNG is used by the engineer to type in the parameter \$PRSTSnn.AMSCHDMP(0) and give the parameter the value of NET>TEST>AM29LOAD.XX as its pathname. An index of 0 says to create the schedule file for all of the units in the AM. Laboriously, the engineer looks at the AM29LOAD.XX schedule dumper file and tries to decide what cycles are overloaded.

After hours spent figuring out what cycles the points need to be changed to, the engineer inactivates and rebuilds all of the points that need to be changed. He may need to modify the parameter BEFAFT to CYCLE, and the parameter NORMCYCL on all of the points that need to be changed. The engineer then activates the points and monitors the performance of the AM. This process is repeated as necessary.

New Operation—Ways to Use the AM Load Balance Tool

With R600, some suggested uses for the AM Load Balance Tool are depicted in the following examples.

Example 1—The engineer uses the AM Load Balance schematic tool to create a graphical AM cycle loading picture. First, the engineer calls up the schematic (\$AMCYLD) and selects the SELECT AM target and chooses AM 29. Next he creates the schedule dumper file for all units by selecting the ANALYZE AM target. The engineer gives a unit index of 0 (all units) to create and analyze the AM schedule dumper file that will produce the graphical AM cycle loading picture. After looking at the graphical picture, the engineer decides that the AM loading cycle is not the problem and no further analysis of the cycle load is necessary.

Example 2—After creating and analyzing the AM schedule dumper file with the schematic tool, the tool notifies the engineer that Cycle 0 is the most loaded cycle with 31 points. The engineer decides to see which points are on Cycle 0 by first selecting Cycle 0 above the bar graph, and then selecting the CREATE REPORT FOR CYCLE 0 target. Now the engineer selects the DISPLAY REPORT FOR CYCLE 0 target to view which of the points are on Cycle 0.

Example 3—After printing the list of points on Cycle 0 by using the PRINT REPORT FOR CYCLE 0 target, the engineer determines that by moving the 1 second points named FC101 and FC102 from Cycle 0 to Cycle 1, the AM will be less loaded on Cycle 0. He then inactivates FC101 and FC102, reconstitutes them, modifies their BEFAFT parameter value to CYCLE and their NORMCYCL parameter value to 1, then reloads and reactivates the points. The engineer observes that the problem with the AM overruns is now gone.

Error Handling

The following table provides a list of error messages that might be produced by the AM Load Balance Tool application. They appear on the \$AMCYLD schematic, next to the text “Message:”

Table 6-1 – Error Messages

Error Message	Meaning	Remedy
ERR1: READING FILE DIRECTORY/TIMESTAMP	Schedule Dump directory has been deleted, or HM has been powered off or failed.	Recreate the AMLD (or other) directory and then create a new Schedule Dump file by selecting the ANALYZE AM target. If HM problem, restart History Module.
ERR2: ERROR OPENING FILE	HM has been powered off or has failed.	Restart History Module.
ERR3: ERROR READING FILE RECORD	HM has been powered off or has failed.	Restart History Module.
ERR4: ERROR READING FIELD-CYCLE NUMBER	Data in the Schedule Dump file has been deleted or corrupted.	Create a new Schedule Dump file by selecting the ANALYZE AM target.
ERR5: ERROR READING FIELD-CYCLE DATA	Data in the Schedule Dump file has been deleted or corrupted.	Create a new Schedule Dump file by selecting the ANALYZE AM target.
AM SCHEDULE DUMP FILE DOES NOT EXIST	The Schedule Dump file has not yet been created for this AM.	Select the ANALYZE AM target and enter a unit index to create a new AM Schedule Dump file.
AM SCHEDULE DUMP FILE OPEN - PLEASE CLOSE	The Schedule Dump file is in use by another station.	Close the Schedule Dump file and try your operation again.
NODE xx is NOT an AM	The node entered after selecting the SELECT AM target is not the node number of an AM.	Select a valid AM node number at the SELECT AM target.
NODE yy is NOT ON NET	The node entered after selecting the SELECT AM target is not online.	Load the desired AM node, or select a valid AM node number.

Section 7 - AM CHECKPOINTS

This section provides guidelines for establishing AM checkpoint volumes, determining options available, and tells how to reserve user memory for future options.

Establishing AM Checkpoint Volumes

Like other checkpoint volumes, AM checkpoints can exist on removable media (cartridges or floppy disks) and on HMs. General guidelines and information on checkpointing are provided in Section 21 of the *Engineer's Reference Manual*.

The table labeled "HM Volume Size Estimator" in Section 7 of the *Engineer's Reference Manual* defines how to estimate the size of AM checkpoint volumes. A significant factor in the size of such volumes is the amount of user memory in the AM. You should note that the user memory sizes in this table are expressed in kb rather than words, and therefore are approximately twice the values given under Section 2 of these *Application Module Implementation Guidelines*. Also note that each AM checkpoint volume on an HM must be large enough to simultaneously store the checkpoints for all the AMs it serves.

If you add memory to an existing AM, you must use the table in Section 7 of the *Engineer's Reference Manual* to re-estimate the AM checkpoint volume size, and if the existing volume is not large enough, you will have to use Network Configuration to reconfigure the HM volumes (see *Network Data Entry* in the *Implementation/Startup & Reconfiguration - 1* binder).

Usually, demand checkpoints (requested through the SAVE DATA target on the AM Status Display) for a single AM with up to 3 Mw of memory can be saved on floppy diskettes, but checkpoints for 4 Mw AMs, particularly if they have a single, large unit, may not fit on floppies. It is also possible that cartridges will be required for 3 Mw AMs, especially if there is only one unit in the AM and the predominant use is for CL programs. For storage of demand checkpoints, cartridge disk drives should be made available in such situations, and for any AMs with larger than 3 Mw memories.

Options and AM Checkpoints

Purchased options for AMs are AM memory size (2, 3, and 4 Mw) and AM Redundancy.

If the memory size of an existing AM is increased, unless the HM volume that is to store checkpoints for that AM is already sufficiently large, you will need to use Network Configuration to reconfigure the volume size. The calculation of the volume space (volume & 5np) needed for an AM checkpoint is defined in the table labeled "HM Volume Size Estimator" in Section 7 of the *Engineer's Reference Manual*.

Adding the AM Redundancy option to an existing AM reduces available user space by 157,000 or 179,000 words (see "NCF Functional Adjustments—Redundancy Buffer"). If this option is added without adding memory, you may not be able to reload the checkpoint data for this AM, because there is insufficient user memory. To avoid this problem, you can reserve user memory for future options as described below.

How to Reserve User Memory for Future Options

PSDP parameter RESRVMEM (for more information about PSDPs, refer to Section 22 in the *Engineer's Reference Manual*) is used to change the amount of reserved memory. Initially, this parameter contains 0, which specifies no reserved user memory. Do this to reserve user memory in blocks of 32 kw:

1. On the Engineering Main Menu, select LCN NODES. The LCN Node Configuration display appears. Note that a backup NCF pathname is required.
2. Select the node number for the AM whose RESRVMEM value is to be changed (you may need to press PAGE FWD). The Application Module Node display appears.
3. Select MODIFY NODES. Page 2 of the Application Module Node display appears (Figure 2-3).
4. To change RESRVMEM, key in a new value in the port labeled USER MEMORY RESERVED (# OF 32KW BLOCKS), and press ENTER. The Application Module Node display should reappear with the new value in blue (cyan). If there are errors in the value you entered, they are noted in red. Note that the values in the MEMORY USED (WORDS) column also change.

The value entered will allocate reserved memory as follows:

0 = no reserved memory	5 = 160 kw to be reserved	10 = 320 kw to be reserved
1 = 32 kw to be reserved	6 = 192 kw to be reserved	11 = 352 kw to be reserved
2 = 64 kw to be reserved	7 = 224 kw to be reserved	12 = 384 kw to be reserved
3 = 96 kw to be reserved	8 = 256 kw to be reserved	
4 = 128 kw to be reserved	9 = 288 kw to be reserved	

Note that the sum of the value in RESRVMEM and the value AMDATA(48) (see "Overloads and Redundancy Buffer Size in the next section) cannot be larger than 12. If this AM doesn't have the redundancy option, AMDATA(48) contains 0.

5. Hold CTL and press F1 (F1=Check). A Modify Node display appears with instructions for installing and loading the change you just made. Follow those instructions (they include shutting down and reloading the AM). The PSDP parameter RESRVMEM assumes the current value, and the memory reserved for CVBs changes accordingly.

How to Discover the Reason for Checkpoint Errors

The AM PSDP parameter CPFMERR contains the secondary status code from a File Manager error during a checkpoint. See heading 4.10 in the *Control Language/Application Module Reference Manual* for a complete list of File Manager error codes.

NOTE

If the AM is shut down during a checkpoint cycle, it will go to the FAIL state rather than to the QUALIFIED state (in order to ensure a clean checkpoint termination).

Section 8 - AM REDUNDANCY OPTION

This section provides guidelines for installing and configuring, loading, and the operation of redundant AMs.

AM Redundancy is a purchased option for AMs with AMR/HMPU, EAMR/K4LCN Redundancy and processor boards only. AM Redundancy includes hardware and software that allow a secondary AM to back up the operation of the primary AM. To do this, all of the application data in the primary AM is transferred to the secondary AM, where an exact copy of the data is maintained to be used if the primary AM should become inoperative.

When a hardware fault is detected in the primary AM, the secondary AM takes over within approximately five seconds. No external accesses to the AM are lost during the transfer (failover).

When valid data is stored in the secondary AM, the primary and secondary are said to be synchronized. Communication errors and processing overloads are rare, but should they occur, the AM pair is automatically resynchronized. An automatic memory checker compares the data in the secondary with that in the primary and should they not compare the secondary fails, which generates an alarm.

Installing and Configuring Redundant AMs

Instructions for installing and interconnecting redundant AMs is provided in Appendix A of the *LCN System Installation* manual in the *LCN Installation* binder. Each AM in a redundant pair includes an AM Redundancy board (AMR) that connects to the HMPU board or an EAMR extended redundancy board (EAMR) that connects to the K4LCN board through a ribbon cable that is visible at the front of the chassis. The AMR boards in each AM are interconnected by two ribbon cables that are visible at the rear of the chassis.

AM Redundancy requires the following memory in redundant AMs: 157,000 words (fast/slow processor buffers), plus an additional 22,000 words for the AM redundancy Internetwork Point Processor (IPP) option if used.

You define the redundant AM pairs in the LCN Node Configuration activity in Network Configuration (see *Network Form Instructions* and *Network Data Entry* in the *Implementation/Startup & Reconfiguration - 1* binder).

Loading of Redundant AMs

The AM Status Display is used to load, shut down, and reload both AMs. First load the primary AM using the appropriate type of load (hot, cold, warm, or no processing). Then load the secondary. For the secondary, use any of the load options (which you use, makes no difference). When redundancy is in effect, the primary's status is OK and the secondary's status is BACKUP.

The On-line Migration of Redundant AMs function (Refer to Subsection 8.5) allows the user to upgrade the redundant AMs without having to shutdown both the primary and secondary AM nodes together. The user *will* have to shutdown one AM node, load it with the new version of the software and then do a fail-over to allow this node (with new software) to become a new primary AM node. Then the old primary node is loaded as the new secondary AM node.

NOTE

The EAMR redundancy board must be installed before loading a K4LCN AM node that is configured as redundant through the LCN Node Configuration. The AM load will abort and produce a status notification message if the K4LCN AM node is loaded without the required redundancy hardware.

To load a redundant AM,

1. From any US, at the SYSTEM STATUS DISPLAY, SHUTDOWN the PRIMARY AM. The current secondary becomes the primary. The new primary AM displays WARNING as the redundant AM does not exist.
2. Select LOAD SELECT target and press ENTER.
3. Wait until the COMPLETED LOADING message is displayed.
4. Select RETURN target. The current primary AM database is transferred to the secondary over the redundancy hardware and this may take several minutes. When this is completed, the node status shows WARNING and the STATUS DETAIL or Event History - Notification Status shows AM Redundancy as WARNING: SECONDARY IS AN UPGRADE.
5. Shutdown the primary AM. The current upgrade secondary becomes the primary. Its node status shows WARNING and the STATUS DETAIL or Event History - Notification Status displays WARNING: PRIMARY HAS NO BACKUP. Select LOAD SELECT target and press ENTER.
6. After the COMPLETED LOADING message is displayed. Select RETURN target. The current primary AM database is transferred to the secondary AM over the redundancy hardware and this may take several minutes. The node status displays OK and BACKUP and the STATUS DETAIL or Event History - Notification Status shows AM REDUNDANCY OK: AM REDUNDANCY STATUS TRACKING.

NOTE

The AM External Load Modules (i.e. AMCL02, FILE, CONV, etc) can be upgraded independently of AM software releases. Refer section 9 CUSTOM SOFTWARE, CL EXTENSIONS, AND BACKGROUND CL for more information.

Operation of Redundant AMs

Unless an overload occurs, a properly configured redundant AM pair with appropriate status runs without further intervention.

Occasional errors may occur that cause loss of synchronization for a few seconds while the secondary AM's data is being refreshed. The value in PSDP parameter REDINOP (redundancy in operation) is False during resynchronization. PSDP parameter RESYNCS(1) contains a count of all resynchronizations since the secondary AM was last started. Other values in the RESYNCS array define the causes of resynchronization. These parameters are defined under 22.3 in the *Engineer's Reference Manual*.

Under some conditions, a redundancy buffer that stores data being transferred to the secondary can be overloaded. A normal, temporary overload causes resynchronization, but the following conditions cause a heavy overload, which may cause the secondary AM to fail (crash).

- DEB reloading of points with CL blocks with many references to other physical nodes. Approximately 5000 such references while normal processing is taking place for other points can cause a heavy overload and failure of the secondary AM.
- Storage of a large number of values by a CL block or several CL blocks on one cycle. Storage of approximately 6000 "on point" values to CDS parameters combined with normal point processing could cause an overload.

If more than five overloads occur within ten minutes, the secondary AM fails (crashes).

Overloads and Redundancy Buffer Size

You may be able to reduce the number of redundancy buffer overloads (see 8.3) by increasing the size of the redundancy buffer, which decreases user memory (for more information, refer to 2.2).

The default value for redundancy buffer size is 122,880 words. The current size is in PSDP parameter REDBFZ in the secondary AM.

PSDP parameter AMDATA(48) in the secondary AM contains an integer that represents the amount of additional redundancy buffer currently in use. Initially the value in the parameter is 0. Do this to increase size of the redundancy buffer (in blocks of 32 kw):

1. On the Engineering Main Menu, select LCN NODES. The LCN Node Configuration display appears. Note that a backup NCF pathname entry is required.
2. Select the node number for the AM whose RESRVMEM value is to be changed (you may need to press PAGE FWD). The Application Module Node display appears.
3. Select MODIFY NODES. Page 2 of the Application Module Node display appears (Figure 2-2).

4. To change AMDATA(48), key in a new value in the port labeled REDUNDANCY BUFFER INCREASE (# OF 32KW BLOCKS), and press ENTER. The Application Module Node display should reappear with the new value in blue (cyan). If there are errors in the value you entered, they are noted in red. Note that the values in the MEMORY USED (WORDS) column also change.

The value entered will add buffer memory as follows:

0 = 0 kw to be added	11 = 352 kw to be added
1 = 32 kw to be added	12 = 384 kw to be added
2 = 64 kw to be added	13 = 418 kw to be added
3 = 96 kw to be added	14 = 448 kw to be added
4 = 128 kw to be added	15 = 480 kw to be added
5 = 160 kw to be added	16 = 512 kw to be added
6 = 192 kw to be added	17 = 544 kw to be added
7 = 224 kw to be added	18 = 576 kw to be added
8 = 256 kw to be added	19 = 608 kw to be added
9 = 288 kw to be added	20 = 640 kw to be added
10 = 320 kw to be added	

Note that the sum of the value in AMDATA(48) and the value RESRVMEM (see “How to Reserve User Memory for Future Options” presented earlier in this document) cannot be larger than 12.

5. Hold CTL and press F1 (F1=Check). A Modify Node display appears with instructions for installing and loading the change you just made. Follow those instructions (they include shutting down and reloading the AM). PSDP parameters AMDATA(48) and REDFBSZ assume the current values, and the memory reserved for the redundancy buffer changes accordingly.

Background CL in Redundant AMs

When switchover from primary to secondary occurs in redundant AMs, there is a significant difference between background and foreground CL programs. Runtime software has built-in protection for foreground CLs. It provides a smooth transition during switchover, protecting database integrity and preserving the sequence of program actions. Background CL does not have the same protection.

After a switchover from primary to secondary, all running background CLs restart from the beginning. CL stores that were done in the primary may not have taken place in the secondary before switchover, and if this is a problem, the user must provide protection.

For example, assume a primary background CL is in the middle of a sequence of stores to on-node parameters when switchover occurs. The stores are done in real time in the primary, and into a list for the secondary, where they are performed after a time lag. Therefore, without specific programming by the user, there is no way to know how many, if any, of the parameters were stored in the secondary's database. Another potential problem is that when a switchover forces a background CL to restart at the beginning, sequence-critical functions in the background program may be forced out of the required sequence.

If your process would be harmed by loss of data and disruption of sequence that could occur if your background CL programs restart as a result of switchover, you have two choices. You must either implement the critical programs in foreground CL, or you must include logic in the background programs to protect the system if switchover occurs.

The following is one possible technique that you can adapt and use to program for redundancy in background CL. In a Redundant AM CL program, the primary can communicate synchronization data to the secondary through CDS parameters. This synchronization data can be a code that indicates to the secondary where it should resume execution after a switchover. If a switchover occurs, the running background programs will restart. There is a CL Built-In function, `BKG_Switchover_Restart` (described in the CL/AM Reference Manual), that can be used by a background CL program to determine if it started as a result of switchover. The program can use this function to establish that a switchover occurred, and then the program can test the synchronization data in the CDS parameters to determine at what point in the CL it should resume execution.

As an example, consider the situation mentioned above where a background CL program includes a sequence of on-node stores. To provide switchover protection, you could have the program set the code "3" in a CDS parameter just before the sequence of stores is started, and change the code to "4" when the sequence is completed. After a switchover restart (determined from the `BKG_Switchover_Restart` function), the program can check the code. If the code is "3," it is known that the switchover occurred during the sequence of stores and that it is possible that some were completed while others were not. The secondary would resume execution at the beginning of the sequence of stores. If the code is "4," the program would resume after the sequence of stores. Using this technique, the primary can pass the location of "safe" restart points to the secondary during execution of the program.

Another technique that may be helpful to you is the `Multiple_Move_Parameter` function that is provided in the custom set `AMCL01`. This function allows you to do multiple stores to a particular unit without interruption. For information on the `Multiple_Move_Parameter` function, refer to subsection F.4 of the CL/AM Reference Manual. Subsection F.4.4 discusses data integrity issues.

On-Line Migration of Redundant AMs

Prior to R611 release, updating any AM software release (maintenance release, point release, functional release, or major release) would require that both the AM processors be shutdown together and both loaded with the new version of the software.

From R611 onwards, with the on-line migration of redundant AMs package, the user can update the software revisions without needing to shutdown both primary and secondary AM nodes at the same time. The user *will* have to shutdown one AM node, load it with the new version of the software and then do a fail-over to allow this node (with new software) to become a new primary AM node. Then the old primary node is loaded as the new secondary AM node.

First AM Redundancy Upgrade after R611

The first time this on-line migration feature is used the following needs to be considered.

- From R611 release onwards, when the user loads an AM for the first time both AMs must be shutdown.
- If the current AM software is the version below R600, then both primary and secondary must be shutdown to load this release.
- If the current loaded AM software is at or above R600 and below R611, then shutting down the secondary and loading R611 will load AM media but not any external load modules (They will be copied from the primary on this first load only. Thereafter, they are loaded every time from the load media.). To ensure the external load modules are current after the first failover to make R611 the running primary, an additional load of R611 and failover and reload of the secondary is needed.

NOTE

If the current loaded AM software is at or above R611 then, refer to 'Subsequent AM Redundancy Upgrades'.

Summary of how the migration procedure will load a different version of the AM software is as follows.

- Shutdown and load the secondary with latest release software
- The System Status Display primary shows OK and the secondary load status shows WARNING and AM Redundancy Status Detail shows SECONDARY IS AN UPGRADE
- Shutdown primary and failover to upgraded node. The status shows WARNING and AM Redundancy Status Detail shows PRIMARY HAS NO BACKUP
- Load secondary with latest software
- The secondary load node status shows BACKUP and AM Redundancy Status Detail shows AM REDUNDANCY STATUS TRACKING
- If the secondary load node status shows WARNING and AM Redundancy Status Detail shows SECONDARY IS AN UPGRADE, then external load modules are an upgrade and the failover and reload of a secondary needs to be done one more time so that the status is OK for primary and BACKUP for secondary
- Should a failure of the secondary occur during the upgrade look at the EVENT HISTORY/STATUS NOTIFICATION of the failed secondary for reason of the failure. Then correct the condition and retry.

NOTE

Refer to the *Customer Release Guide* for the actual procedure of upgrading.

The primary AM is loaded, and the AM database and external load modules (SETS) are loaded from the media selected by the operator/engineer. The System Status Display shows the AM node in WARNING state and a status detail as THE PRIMARY HAS NO BACKUP.

After the on-line migration of redundant AMs changes are loaded in the primary AM, and the secondary AM is loaded with the same release of software. The AM database and external load modules (SETS) are loaded from the primary AM through the redundancy channel. The System Status Display shows the primary as OK and secondary as BACKUP.

NOTE

The next time the user needs to upgrade the AM, the following procedure should be used.

Subsequent AM Redundancy Upgrades

The requirements for the subsequent migration feature are similar to that of the existing HG/NIM maintenance releases.

Summary of how the migration procedure will load a different version of the AM software is as follows.

- Shutdown and load the secondary with latest release software
- The System Status Display primary shows OK and the secondary load status shows WARNING and AM Redundancy Status Detail shows SECONDARY IS AN UPGRADE
- Shutdown primary and failover to upgraded node. The status shows WARNING and AM Redundancy Status Detail shows PRIMARY HAS NO BACKUP
- Load secondary with latest software
- The secondary load node status shows BACKUP and AM Redundancy Status Detail shows AM REDUNDANCY STATUS TRACKING
- Should a failure of the secondary occur during the upgrade look at the EVENT HISTORY/STATUS NOTIFICATION of the failed secondary for reason of the failure. Then correct the condition and retry.

NOTE

Refer to the *Customer Release Guide* for the actual procedure of upgrading.

The secondary AM may be loaded with a different release of software provided that the primary, as a minimum, has the on-line migration of redundant AMs functionality.

The System Status Display shows the primary as OK, the secondary state as WARNING and a backup status detail of THE SECONDARY IS AN UPGRADE. After doing a fail-over, the System Status Display shows the old primary AM node in QUALIFY state and the upgraded primary AM node in WARNING state and a status detail shows THE PRIMARY HAS NO BACKUP. Reloading the secondary with the same release of software as on the primary results in the AM database and external load module (SETS) loading from the primary AM through the redundancy channel. The System Status Display shows the primary as OK and secondary as BACKUP.

The fail-over and reload may be repeated to get the AM node numbers back to the original LCN primary/secondary node number pair used before the upgrade. The removable media can be used to upgrade the load modules.

NOTE

To avoid unnecessary reloading of nodes, we suggest that you shut down the primary AM first and reload it with the new release.

Conditions to shutdown both AM nodes

The following conditions require that both the AM nodes be shutdown and restarted while upgrading the software release.

- The very first release to implement the on-line migration of redundant AMs package, i.e., migrating to R611.
- Migrating from R6xx to R700.
- Any changes in the AM that exceeds the available space and causes the current AM redundant memory boundary to move/increase.
- Any changes in the AM External Load Modules that exceeds the available space and causes the current custom system's memory boundary to move.
- Any Customer initiated NCF change which causes the current AM configuration to change such as Background CL Tasks, Concurrent Data Accesses from Background CL, Background Task Stack Size, CVB Size, Redundancy Buffer Increase, Include Internetwork Point Processor, IPP CVB Size, User Memory Reserved, External Load Modules (Sets), or External Load Directives.

NOTE

This function is not applicable to AxM and APP nodes as only the regular AM nodes can be redundant.

Section 9 - CUSTOM SOFTWARE, CL EXTENSIONS, AND BACKGROUND CL

This section provides guidelines for the installation and loading of AM custom software, CL extensions, and background CL blocks.

AM custom software is optional software, purchased from Honeywell, and provided as external load modules. CL extensions consist of a set of subroutines that enable the movement of data between CL/AM blocks and History Modules. Background CL blocks are CL blocks that, while inserted at a defined place in the point-processing structure, run in the “background” and unlike all other CL blocks, are not required to complete execution before processing of the next AM point can begin.

Documentation for AM custom software, including information about use of AM resources, is provided by the custom software developers. For more information about background CL blocks, refer to Section 4 in *Application Module Control Functions* in the *Implementation/Application Module - 1* binder. For more information about CL extensions, refer to Appendix C in the *Control Language/Application Module Reference Manual* in the *Implementation/Application Module - 2* binder.

Directions Required for External Load Modules and CL Extensions

The following Honeywell-provided directories contain files required to support AM custom software in external load modules and to support CL extensions:

- **&CUS**—contains files FILE.LO and CONV.LO, which are CL-extensions files. This directory may also contain external load modules for AM custom software such as AMCL01 or AMCL02.
- **&CLX**—contains the set-definition file FILE.SF, which describes to the CL Compiler, the added CL routines. This directory may also contain set-definition files for AM custom software such as AMCL01 or AMCL02.

&CUS and **&CLX** can be on an HM or on removable media (cartridges or floppies). If on an HM, they must be in a volume, usually a user volume, that has sufficient storage capacity. The standard files that provide and support the CL extensions are provided in directories **&CUS** and **&CLX** on the software media provided by Honeywell. These directories are provided on the following media:

- Application Module Cartridge **&CR3**
- Floppy diskette 51152058, CL File R/W Option Packaging (**&AMS**).

If you need to use the CL Extensions, you should copy the content of directories **&CUS** and **&CLX** to an HM, and you should enter **NET>&CUS>** in the EXT LOAD MODULE port on the Universal Personality’s Modify Default Volume Pathnames display.

With only CL Extensions files in the two directories, they occupy memory as follows:

- &CUS; 464 sectors = 116 kb
- &CLX; 33 sectors = 8.3 kb
- A combined total of 124.3 kb

If &CUS contains custom software, the documentation provided with that software advises you of the size of directory &CUS. The guidelines for user-volume configuration in Section 7 of the *Engineer's Reference Manual* recommend the inclusion of enough space in at least one user volume to accommodate directories &CUS and &CLX.

Overview of the Installation of External Load Modules

External load modules are provided separately from the **TotalPlant** Solution (TPS) system software. They typically contain software that is sold and developed by Honeywell IAC as custom software. The major installation steps are as follows:

1. Have the external load modules available on removable media (cartridges or floppy diskettes) or load them into an HM. A sufficiently large user volume must exist on the HM to accept these modules. The modules are stored in a directory in that volume whose name typically is &CUS. You can add this directory to a volume with the Utilities' Create Directory (CD) command (for more information, refer to 5.6 in *Command Processor Operation* in the *Implementation/Startup & Reconfiguration - 1* binder).
2. In the Modify Default Volume Pathnames display, enter a pathname that points to the volume that contains the external load modules. The default pathname is NET>&CUS>.
3. Enter data related to the external load modules in the node configuration displays for the nodes that are to use them. This modifies the NCF workfile.
4. Install the modified NCF.
5. To make the modified NCF effective, shut down (if necessary) the affected nodes and (re)load them.

This installation is normally accomplished on the system with the affected nodes, with the Configurator in the on-line mode. You can use the Configurator in the off-line mode to create a work file for another system, but integrity checks that are accomplished in the on-line mode are not accomplished in the off-line mode.

More detail about installing external load modules and background CL routines is provided in the remainder of this section.

NOTE

The AM External Load Modules (i.e. AMCL02, FILE, CONV, etc) can be upgraded independently of AM software releases.

Node Configuration and External Load Modules Page

On the Engineering Main Menu, select LCN NODES, then page forward as necessary to find and select a node. Page 1 of the Node Configuration display appears.

The PAGE FWD and PAGE BACK keys move forward or backward through the multiple pages of the Node Configuration display for the selected node (two pages for most nodes, three pages for AMs). To select another node, hold CTL and press PAGE BACK. Then, on the Select Desired Node display, select another node.

If you are adding a node not yet known to the NCF, you can enter appropriate data on any page of the Node Configuration display. If you are modifying an existing node, to get to page 2, select MODIFY NODE and then page forward to page 2. You can go to page 1, but you cannot make changes on that page (it is already configured).

NOTE

Note that with R600, changes can now be made to the AM and the US Nodes on page 1 of the Node Configuration Display.

Figure 9-1 provides a simulation of the external load modules page with notation that shows the help messages that appear in the prompter region at the bottom of the page when you place the cursor in one of the ports and press HELP. To cancel the help message, press CANCEL.

For application and customs software, the names of the external load modules, applicable personalities, and information about additional module memory values are provided in the documentation provided with the custom software. For Background CL Routines, refer to Section 4 in *Application Module Control Functions* in the *Implementation/Application Module - I* binder.

To enter data, select a port, key in the data, and press ENTER. Necessary calculations then take place and totals are displayed. When you are satisfied with the data, hold CTL and press F1 to start the Checker. After a successful check,

- if the Configurator is in the on-line mode, the Installation Instructions display for the selected node appears (Figure 9-3). You can then install the modified NCF by holding CTL and pressing F2. Then follow the installation instructions to make the modified NCF effective.
- if the Configurator is in the off-line mode, the current display remains. You can then copy file NCF.WF from directory &ASY onto a removable medium and install that NCF on the target system.

Node Configuration, AM User Memory Allocation Page

Figure 9-2 shows a simulation of AM Node Configuration page 2, the AM User Memory Allocation page, that shows the help messages that appear when you place the cursor in one of the ports and press HELP.

Loading of External Load Modules

After you have made the external load modules available on a storage medium (typically in a &CUS directory in a user volume), and in the LCN Node Configuration you have defined external load modules to be loaded in an AM, each time the AM is loaded with the personality associated with one or more of the external load modules, those modules are included in software that is loaded.

As the external load modules are loaded, checks are made to ensure that the module versions are valid, that the personality type is correct, and that interdependencies between modules are satisfied. If errors are found, the load is incomplete or it fails. Information about such errors can be found on the node status displays and in the Auxiliary Node Status for the node, which is accessed through the Event History Retrieval display.

With R611, with the on-line migration of redundant AMs package installed in the redundant AMs, the secondary AM can be loaded with a different release of external load modules even if the AM software is not upgraded.

NOTE

Refer to the section AM Redundancy Option for upgrading the AM software.

To upgrade the external load modules,

1. Press the SYSTEM STATUS button.
2. Select the node.
3. Press the NODE STATUS DETAIL button.
4. Select the required node.
5. Select AUTO LOAD or MANUAL LOAD.
6. Press Enter. The external load modules are loaded with the AM personality and are loaded at the same time and from the same media as the AM (e.g.: If load program comes from the NET then &CUS on the NET will contain the load media LO files for the AM load. If the AM is loaded from removable media then the &CUS LO files must be on removable media). If the program source is to be loaded from the NET refer to step 7. If the program source is to be loaded from the removable media refer to step 8.

7. Select DEFAULT for the program source on the load of the secondary. The program source is loaded from the NET. The AM database and external load module (SETS) are loaded from the primary AM through the redundancy channel.
8. Select ALTERNATE - REMOVABLE MEDIA for the program source on the load of the secondary. The Program Source is loaded from the media selected by the operator/engineer. The AM database is copied from the primary AM (through the redundancy hardware). The external load modules (SETS) are loaded from the media selected by the operator/engineer. (The external load modules are not updated through the redundancy channel, as the version/revision/ size/location may be different from the primary external load modules).
9. External load modules are upgraded with the AM by putting the released external load module on the media used to load the AM. On a redundant AM after R611, the updated external load modules are loaded on the secondary AM first then, a failover of primary to secondary activates the upgraded external load modules. (Prior to the AM migration change, external load modules were loaded only on the primary AM, then copied to the secondary through redundancy). An exception to this is the first time migration of redundant AMs. The first time migration on redundant AMs may require additional load steps and failovers to upgrade external load modules (Refer Section 8 AM Redundancy Option for information on first time migration).

NOTE

All the configured external load modules (not just the one being upgraded) must be available on the removable media. All external load modules used by an AM need to be on the load media when either the non-redundant/primary /or secondary is loaded.

A comparison is made between the revision of the external load modules just loaded into the secondary with those in the primary.

- If the revision of the external load modules matches, the System Status Display shows the primary as OK and secondary as BACKUP.
- If the revision of the external load modules is different on the secondary, then the secondary will be flagged as an upgrade even though the AM software may be the same revision. The System Status Display shows the primary as OK, the secondary state as WARNING and the backup status detail as THE SECONDARY IS AN UPGRADE.
- After doing a fail-over, the System Status Display shows the old primary AM node in QUALIFY state and the upgraded primary AM node in WARNING state and the Status Detail shows THE PRIMARY HAS NO BACKUP.
- On reloading the secondary with the same release of software and the same revision of external load modules as that of the primary, the AM database and external load module (SETS) is loaded from the primary AM through the redundancy channel.
- The System Status Display shows the primary as OK and secondary as BACKUP.

After you key in data and push ENTER, the Configurator uses the EXT LOAD MODULE pathame on the Default Pathnames display to find the named module(s). For all modules found, the module sizes are added, the Additional Module Memory value is added, and the total is displayed here (for each personality, as applicable).

DD/MM/YY HH:MM:SS 1

PAGE 3 OF 3 ON-LINE

NODE 1

ENTER EXTERNAL LOAD MODULE NAMES & ASSOCIATED PERSONALITY TYPES:

NAME	---	PERS	NAME	---	PERS	NAME	---	PERS	NAME	---	PERS

USE DEFAULT PERSONALITY TYPE? YES NO

AMMO

ADDITIONAL MODULE MEMORY (WORDS)

TOTAL (MODULES PLUS ADDITIONAL MEMORY)

FURTHER EXTERNAL DIRECTIVES? YES NO

F1-CHECK F2-SET OFFLINE F5-ABORT F7-NEXT ITEM F9-PACK NCF
F2=INSTALL F4=PRINT

Help message:
 ENTER LOAD MODULE NAME &
 ENTER SIZE OF ANY
 ADDITIONAL MEMORY TO BE
 RESERVED FOR THIS NODE.

Help message:
 ENTER LOAD MODULE NAME &
 PERSONALITY THAT NEED TH
 MODULE: PERSONALITIES
 ARE: US: OPR,ENG,UP HM
 HGO,HMI AM: AMO NIM:
 NMO

3654

Figure 9-1 — Node Configuration, External Load Module Page

Viewing Help Messages

Place the cursor in a port and press HELP. The Help message appears in the prompter region at the bottom of the display.

1. ENTER # CL BACKGROUND TASKS. RANGE 0-10. MEMORY USED INCLUDES STACK SIZE. NOTE: (MEMORY ALLOTS 16200 + # CL BACKGROUND TASKS * CL BACKGROUND TASK SIZE WORDS)
2. ENTER # CONCURRENT DATA ACCESSES FROM BACKGROUND CL. RANGE 0-4. MUST = AT LEAST 1 IF # BACKGROUND TASKS >0. NOTE: (MEMORY ALLOTS 1050 WORDS * # CONCURRENT DATA ACCESSES)
3. ENTER CL BACKGROUND TASK SIZE (IN WORDS). DEFAULT IS 25000. RANGE IS 700-32000.
4. ENTER CURRENT VALUE BUFFER SIZE FOR FAST OR SLOW POINT PROCESSOR (IN WORDS). DEFAULT IS 2000. RANGE IS 2000-32700.
5. ENTER # ADDITIONAL 32KW BLOCKS IN REDUNDANCY BUFFER. RANGE 0-20. (REDUNDANCY BUFFER INCREASE + USER MEMORY RESERVED) <=20
6. SELECT YES TO PERMIT INTERNETWORK DATA ACCESS FROM ASSIGNED POINTS. NOTE: (MEMORY ALLOTS 9 * CVB FOR IPP + 21505 IPP OPTION MEMORY)
7. ENTER CURRENT VALUE BUFFER SIZE FOR IPP (IN WORDS, RANGE IS 2000-32700).
8. ENTER # 32KW BLOCKS RESERVED FOR FUTURE USE. RANGE = 0-12. (REDUNDANCY BUFFER INCREASE + USER MEMORY RESERVED) <=20




Figure 9-2 — Node Configuration, AM User Memory-Allocation Page

```
18 Aug 89 15:45:29 1
PAGE 1 OF 1 MOD US 01

1. INSTALL THE CHANGES IN NCF (F2)

THE FOLLOWING STEPS OUTLINE THE PROCEDURE FOR LOADING THE CHANGES
INTO THE NETWORK. YOU MAY INSTALL OTHER CHANGES BEFORE PERFORMING
THESE STEPS.

Loader Directive changes affect only the node being modified.
Complete the next step to install the new directives.

2. For this node:
  a. SHUTDOWN the node
  b. LOAD the node using the NCF installed in the previous step.

F5=ABORT
F2=INSTALL F4=PRINT
```

3657

Figure 9-3 — Node Configuration, Installation Instructions Page

FAX Transmittal

FAX No.: (602) 313-4212

TO: Information Development

Total FAX pages: _____
(including this page)

Reader Comments

Title of Document: **Application Module Implementation Guidelines**

Document Number: **AM12-610 R650**

Issue Date: **12/03**

Comments: _____

Recommendations: _____

FROM:

Name: _____ **Date:** _____

Title: _____

Company: _____

Address: _____

City: _____ **State:** _____ **ZIP:** _____

Telephone: _____ **FAX:** _____

FOR ADDITIONAL ASSISTANCE:

Write	Call
Honeywell International Process Solutions 2500 West Union Hills Drive Phoenix, AZ 85027	Technical Assistance Center (TAC) 1-800-343-0228 (available in the 48 contiguous states) OR E-mail us at: pst@honeywell.com

Honeywell

Process Solutions

2500 West Union Hills Drive
Phoenix, AZ 85053-3095